



Version 1.0





Secure it!

Reduce the risk of furniture tip-over accidents





WARNING: ENSURE THE WALL STRAP IS ATTACHED TO AVOID SERIOUS INJURY.

To avoid any serious or fatal injury, a wall strap has been provided with this product to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Fixing devices are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.

Recommended weight capacity: 20kg per Shelf

Tips to further reduce the risk of furniture tip-over accidents:

- Discourage children from climbing or hanging on furniture.
- Keep your heaviest items in the bottom drawers or shelves.
- Do not place TVs or heavy items on top of the furniture.
- Use locking devices on drawers to discourage small children from using them as steps.













Wall attachment guide



For plasterboard (without available wood stud)

Securing method:Self drilling plasterboard anchor.



For plasterboard (with available wood stud)

Securing method:
Screw inserted directly into





For masonry wall

Securing method: Solid wall: Plug with screw Hollow wall: Spring toggle

Please seek professional advice if you are in doubt of what fixing device to use.

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture to help create a home you'll love!



Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for your chance to win a \$250 Fantastic Furniture Gift Card!


@fantasticfurniture




Assembly checklist



Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the compenents before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasterners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.



What you need

to assemble the product






Other tools you need:

Phillips head screwdriver; Mallet.

Parts list

2x Side Panels (P1); Top Panel (P2); Bottom Panel (P3); 2x Shelf Panels (P4); 3x Door Panels (P5); 3x Back Panels (P6)



Hardware pack



16 x Long Screws (H1)



4 x Wood Dowels M6 x 25 (H6)



1 x Flat Washer (H11)



3 x Magnet With Legs (H2)



16 x Stickers (H7)



6 x Rectractable Door Studs (H3)



4 x Dowel Plugs (H8)



3 x Handles (H4)



1 x Webbing (H9)



6 x Pan Head Screws #6 × 16.5 (H5)



1 x Pan Head Screw M3.5 × 12 (H10)




3 x Magnet Plates (H12)




6 x Screws M3.5 x 12 (H13)





Fix 3x Magnet With Legs (H2) to Top Panel (P2) and 2x Shelf Panels (P4) as per Detail A.


Step 2




Fix 6x Rectractable Door Studs (H3) to 3x Door Panels (P5) as per Detail A. Fix 3x Magnet Plates (H12) to 3x Door Panels (P5) with 6x Screws M3.5 × 12 as per Detail B. Tighten with a phillips head screwdriver.










Fix 3 \times Handles (H4) to 3 \times Door Panels (P5) with 6 \times Pan Head Screws #6 \times 16.5 (H5) as per Detail A. Tighten with a phillips head screwdriver.


Step 4





Attach Top Panel (P2), Bottom Panel (P3) and 2x Shelf Panels (P4) to Side Panel (P1) with 8x Long Screws (H1). Tighten with a phillips head screwdriver.






Slide 3x Back Panels (P6) into grooves of Top Panel (P2), Bottom Panel (P3) and 2x Shelf Panels (P4).


Step 6


You will need			
And the state of t			
8 x Long Screws (H1)	Phillips head screwdriver		



Attach Side Panel (P1) to Top Panel (P2), Bottom Panel (P3) and 2x Shelf Panels (P4) with 8x Long Screws (H1). Tighten with a phillips head screwdriver.










Insert 3x Door Panels (P5) into place as per Detail A and Detail B.

Step 8








Place 16x Stickers (H7) to cover screws.





You will need			
	AIIII		
1 x Webbing (H9)	1 x Pan Head Screw M3.5 x 12 (H10)	1 x Flat Washer (H11)	Phillips head screwdriver



Attach the Webbing (H9) to the unit using the Flat Washer (H11) and Pan Head Screw (H10). We strongly advise that you secure the unit to a wall using the Webbing provided, to prevent the unit from toppling.


Step 10







Move furniture to its final position, then connect the end of the Webbing (H9) to the wall, ensuring it is firmly attached. Seek advice from a qualified trades person on how to attach this to your specific wall. Screws and wall plugs are not supplied. Please use appropriate fixtures for your wall.










To stack multiple units together please use 4x Wood Dowels (H6) as per Detail A and align unit to connect. For individual units please use 4x Dowel Plugs (H8) as per Detail B.

Step 12



Job complete!

In the interest of our environment please dispose of all packaging thoughfully.

