


Version 1.0





Secure it!

Reduce the risk of furniture tip-over accidents





WARNING: ENSURE THE WALL STRAP IS ATTACHED TO AVOID SERIOUS INJURY OR DEATH.

To avoid any serious or fatal injury, a wall strap has been provided with this product to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Fixing devices are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.

Recommended weight capacity: 20kg per Shelf

To reduce the risk of furniture tipover:




- Do not allow children to stand, climb or hang on furniture. It may topple and cause serious injury or death.
- Do not place toys or other child appealing items on top of this furniture, and place heaviest items towards the bottom of the furniture.




- Do not open more than one drawer at the time.
- Anchoring this product to a wall or other suitable surface is recommended.
 Check anchors regularly.
- Avoid putting a TV on this product.

Wall attachment guide




For plasterboard (without available wood stud)

Securing method:Self drilling plasterboard anchor.



For plasterboard (with available wood stud)

Securing method: Screw inserted directly into stud.





For masonry wall

Securing method: Solid wall: Plug with screw Hollow wall: Spring toggle

Please seek professional advice if you are in doubt of what fixing device to use.

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture to help create a home you'll love!



Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for your chance to win a \$250 Fantastic Furniture Gift Card!

@fantasticfurniture




Assembly checklist



Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the compenents before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky itmes such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasterners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.



What you need

to assemble the product







Other tools you need:

Phillips head screwdriver; Mallet.


Parts list

2x Side Panels (P1);


2x Shelf Panels 1 (P2);

2x Shelf Panels 2 (P3);


3x Back Panels (P4)



Hardware pack




| You will need | | |
|-------------------------|---------------------------|--|
| | | |
| 8 x Long Screws (H1) | Phillips head screwdriver | |



Attach 2x Shelf Panels 1 (P2) and 2x Shelf Panels 2 (P3) to the Side Panel (P1) with 8x Long Screws (H1). Tighten with a phillips head screwdriver.


Step 2



Slide 3x Back Panels (P4) into grooves of 2x Shelf Panels 1 (P2) and 2x Shelf Panels 2 (P3).





| You will need | | |
|-------------------------|---------------------------|--|
| | | |
| 8 x Long Screws (H1) | Phillips head screwdriver | |



Fix Side Panel (P1) to main assembly with 8x Long Screws (H1) and tighten with a phillips head screwdriver.

Step 4






Place 16x Stickers (H2) to cover screws.




| You will need | | | | |
|---------------------|--|-------------------------|---------------------------|--|
| | AIIII | | | |
| 1 x Webbing (H5) | 1 x Pan Head Screw M3.5 x 12 (H6) | 1 x Flat Washer (H7) | Phillips head screwdriver | |




Attach the Webbing (H5) to the unit using the Flat Washer (H7) and Pan Head Screw (H6). We strongly advise that you secure the unit to a wall using the Webbing provided, to prevent the unit from toppling.


Step 6



Move furniture to its final position, then connect the end of the Webbing (H5) to the wall, ensuring it is firmly attached. Seek advice from a qualified trades person on how to attach this to your specific wall. Screws and wall plugs are not supplied. Please use appropriate fixtures for your wall.








To stack multiple units together please use 4x Wood Dowels (H3) and align unit to connect. For individual units please use 4x Dowel Plugs (H4).

Step 8



Job complete!

In the interest of our environment please dispose of all packaging thoughfully.

