

В

Required

Note: Assembly has two options: A or B



www.fantasticfurniture.com.au

Helpful bunk bed safety tips

Bunk beds should be checked periodically to ensure that the guardrail, ladder and other components are secure and in the correct position and all connectors are tight.

We recommend that children under the age of nine (9) do not use the upper bunk. Children should be discouraged from playing on the bunk bed.

No more than one occupant should use the upper bunk at any time (unless otherwise stated).

Bunk beds should be placed a minimum of 2 metres away from any ceiling fans to prevent any in jury to the upper bunk occupant.

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture to help create a home you'll love!



Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for your chance to win a \$250 Fantastic Furniture Gift Card!

@fantasticfurniture




Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighen all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.

What you need

to assemble the product



Other tools you need:

Flat head screwdriver, Phillips head screwdriver, Mallet (soft headed);

Parts list

Box 1:

1 x Headboard (P4);

1 x Footboard (P5);

Box 2:

1 x Front Board (P6);


Box 3:

1 x Back Lower Side Rail (P1);


- 2 x Back Support Panel (P2)
- 1 x Back Upper Side Rail (P3);
- 2 x Middle Bedbase (P10);

Box 4:

- 4 x Short Support Panel (P7);
- 8 x Long Support Panel (P8);
- 4 x Left and Right Bedbase (P9);
- 2 x Middle Bedbase (P10);



Hardware pack





P9


P10

P10


P9










Attach 4 x Short Support Panels (P7) to Headboard (P4) and Footboard (P5) by using $12 \times Bolts$ (H3).







Step 7 P4 Option A , b5 P2 Attach panel (P2) to panel (P1). P5 ۰P2 Option B P4 P2 Fantastic Furniture www.fantasticfurniture.com.au Page 9



Step 9 **Option A** You will need P9 P10 40 x Screws (H4) P10 P9 Phillips head screwdriver P10 P10 Make sure the inner space is square. Then attach 4 x Middle Base Panels (P10) and 4 x Left & Right Base Panels (P9) to the bunk by using 40 x screws, tightening with a phillips head screwdriver. P9 P10 P10 P9 P10 **Option B** P10

www.fantasticfurniture.com.au

Furniture

Page 11

Step 10 Option A **Option B**

Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully

