

Version 1.0





MONACO

Table D4 Round Marble Effect

www.fantasticfurniture.com.au

Enjoy

Your purchase from Australia's Best Value Furniture Store



Assembly checklist



Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

!Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.

!The most common mistakes made during assembly are using the wrong hardware or getting components back to front.

!Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.

!Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.

!Never use any glue until you are certain that the parts belong together.

! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.

!If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.





What you need

to assemble the product


Part list

Box 1: Leg (P2) x 4; Hardware; Box 2: Table Top (P1) x 1.






Step 1







Place the Table Top (P1) on a soft, flat surface to avoid scratching or damaging.


Attach Leg (P2) onto the back of Table Top (P1) using 4 x Bolts (H1), watch the Leg direction as shown. Tighten the Bolts with Allen Key (H2). Repeat for all Legs (P2).



Step 2

Carefully turn the dining table over, and adjust the screws underneath the Legs (P2) to balance the table.





Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.





THIS TOP IS FINISHED WITH A CLEAR PU LACQUER

Avoid placing hot items directly onto the surface unless using a thick insulation material such as placemats or coasters. Heat may lead to discolouration or other damage to the surface of the product.

Use a soft cloth that has been dampened in water to clean the surface of this product. Do not use abrasive cleaners, furniture wax or polish on the surface of this product, as it may damage the surface.

CAUTION: FREQUENT EXPOSURE TO DIRECT SUNLIGHT OR SIMILAR SOURCES MAY CAUSE THE SURFACE TO DISCOLOUR OR FADE.

