




**Fantastic
Furniture**

Version 1.0



Two People



Required

Java
Bookcase Lowline 6 Shelf
fantasticfurniture.com.au

Secure it!

Reduce the risk of furniture tip-over accidents



WARNING: ENSURE THE WALL STRAP IS ATTACHED TO AVOID SERIOUS INJURY OR DEATH.

To avoid any serious or fatal injury, a wall strap has been provided with this product to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Fixing devices are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.

RECOMMENDED WEIGHT CAPACITY: 15kgs/shelf

To reduce the risk of furniture tipover:




- Do not allow children to stand, climb or hang on furniture. It may topple and cause serious injury or death.
- Do not place toys or other child appealing items on top of this furniture, and place heaviest items towards the bottom of the furniture.




- Do not open more than one drawer at the time.
- Anchoring this product to a wall or other suitable surface is recommended. Check anchors regularly.
- Avoid putting a TV on this product.

Wall attachment guide




For plasterboard
(without available wood stud)

Securing method:
Self drilling plasterboard anchor.



For plasterboard
(with available wood stud)

Securing method:
Screw inserted directly into stud.



For masonry wall

Securing method:
Solid wall: Plug with screw
Hollow wall: Spring toggle

Please seek professional advice if you are in doubt of what fixing device to use.

Rattan

Rattan is a natural material that will respond to humidity in the environment. Low humidity may cause the rattan to shrink. High humidity may cause the rattan to absorb moisture and expand, causing the weaving to look loose and wavy.

This is a natural phenomenon and not a defect.

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love!



**Fantastic
Furniture**

Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!

@fantasticfurniture


Assembly Checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What you need

to assemble the product




DO NOT USE



Other tools you need

Phillips Head Screwdriver




Parts list

Carton 1:

- 1 x Top Panel (P1)
- 1 x Left Side Panel (P2)
- 1 x Right Side Panel (P3)
- 1 x Left Divider Panel (P4)
- 1 x Right Divider Panel (P5)
- 2 x Fixed Shelves (P6)
- 1 x Adjustable Shelf (P7)
- 1 x Back Panel (P8)
- 1 x Bottom Panel (P9)
- 4 x Legs (P10)

Hardware Pack



16 x Cam Bolts
(H1)



16 x Cam
Nuts (H2)



24 x Dowels
(H3)



8 x Bolts
(H4)




4 x Felt Pads
(H5)




12 x Flat Washers
(H6)



8 x Spring
Washers (H7)



4 x Shelf Pins
(H8)




8 x Screws
(H9)



4 x Back Panel
Connectors (H10)




8 x Back Panel
Screws (H11)



1 x Allen Key
(H12)





2 x Wall Straps
(H13)



2 x Wall Strap
Screws (H14)


Step 1



You will need	
	
4 x Felt Pads (H5)	



Attach 4 x Felt Pads (H5) to the bottom of legs (P10x4) by removing the adhesive backing and pressing firmly.




Step 2


You will need	
	
8 x Bolts (H4)	8 x Flat Washers (H6)
	
8 x Spring Washers (H7)	1 x Allen Key (H12)



Attach Legs (P10x4) to Bottom Panel (P9) with 8 x Bolts (H4), 8 x Spring Washers (H7) and 8 x Flat Washers (H6) as shown by tightening with the Allen Key (H12).




Step 3


You will need	
	
16 x Dowels (H3)	4 x Cam Bolts (H1)
	
Phillips Head Screwdriver	



Insert 16 x Dowels (H3) into Left & Right Divider Panels (P4&P5) and Fixed Shelves (P6x2) as shown. Attach 4 x Cam Bolts (H1) to Left & Right Divider Panels (P4&P5) as shown by tightening with the Phillips Head Screwdriver.



Step 4

You will need	
	
8 x Dowels (H3)	4 x Cam Bolts (H1)
	
Phillips Head Screwdriver	




Insert 8 x Dowels and attach 4 x Cam Bolts (H1) to Left & Right Side Panels (P2&P3) as shown by tightening with the Phillips Head Screwdriver.


Step 5

You will need	
	
4 x Cam Nuts (H2)	Phillips Head Screwdriver

This is how a cam nut works.....





The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.




Ensure the raw edges on the shelf and divider panel are at the back of the bookcase before securing.

Insert 4 x Cam Nuts (H2) into Fixed Shelf (P6) as shown.
Rotate the cam nuts so the arrows point towards the incoming cam bolts.
Attach Left Side Panel (P2) and Left Divider Panel (P4) to Fixed Shelf (P6) by tightening the cam nuts with the Phillips Head Screwdriver.

Step 6



You will need	
	
4 x Cam Nuts (H2)	Phillips Head Screwdriver




Ensure the raw edges on the shelf and divider panel are at the back of the bookcase before securing.


Insert 4 x Cam Nuts (H2) into Fixed Shelf (P6) as shown.
Rotate the cam nuts so the arrows point towards the incoming cam bolts.
Attach Right Side Panel (P3) and Right Divider Panel (P5) to Fixed Shelf (P6) by tightening the cam nuts with the Phillips Head Screwdriver.

Step 7

You will need	
	
8 x Screws (H9)	Phillips Head Screwdriver




Ensure the raw edges on all panels are at the back of the bookcase before securing.





Attach Left & Right Side Panels (P2&P3) and Left & Right Divider Panels (P4&P5) to Bottom Panel (P9) as shown with 8 x Screws (H9) by tightening with the Phillips Head Screwdriver.


Step 8



Slide Back Panel (P8) into the grooves of Left & Right Side Panels (P2&P3) and Bottom Panel (P9) as shown.



Step 9

You will need	
	
8 x Cam Bolts (H1)	Phillips Head Screwdriver




Attach 8 x Cam Bolts (H1) to Top Panel (P1) by tightening with the Phillips Head Screwdriver.


Step 10

You will need	
	
8 x Cam Nuts (H2)	Phillips Head Screwdriver

Two People



Required






Insert 8 x Cam Nuts (H2) into Left & Right Side Panels (P2&P3) and Left & Right Divider Panels (P4&P5) as shown.

Rotate the cam nuts so the arrows point towards the incoming cam bolts.


Attach Top Panel (P1) to Left & Right Side Panels (P2&P3) and Left & Right

Divider Panels (P4&P5) by tightening the cam nuts with the Phillips Head Screwdriver.

Step 11



You will need	
	
4 x Back Panel Screws (H11)	4 x Back Panel Connectors (H10)
	
Phillips Head Screwdriver	


Ensure the corners of the bookcase are square before securing



Insert 4 x Back Panel Connectors (H10) into the corners of the assembled bookcase as shown and secure with 4 x Back Panel Screws (H11) by tightening with the Phillips Head Screwdriver.

Step 12


You will need	
	
4 x Back Panel Screws (H11)	Phillips Head Screwdriver



Secure Back Panel (P8) in place with 4 x Back Panels Screws (H11) as shown by tightening with the Phillips Head Screwdriver.

Step 13

You will need	
4 x Shelf Pins (H8)	




Insert 4 x Shelf Pins (H8) into Left & Right Divider Panels (P4&P5) at your desired height. Place Adjustable Shelf (P7) into bookcase as shown by resting on the shelf pins. Ensure the shelf is firmly secured in place before using.

Step 14



We strongly recommend that this product is permanently fixed to the wall or other suitable surface.

You will need	
2 x Flat Washers (H6)	2 x Wall Strap Screws (H14)
2 x Wall Straps (H13)	Phillips Head Screwdriver



Attach Wall Straps (H14) to back of Top Panel (P1) with 2 x Flat Washers (H6) and 2 x Wall Strap Screws (H13) by tightening with the Phillips Head Screwdriver.

Step 15




You will need	
	
2 x Flat Washers (H6)	Phillips Head Screwdriver

Seek advice from a qualified trades person on how to attach this wall strap to your specific wall.

Screw and wall plug are not included.
Please use appropriate fixtures for your wall.

With assistance, move the bookcase to the final position.
Attach the wall straps to the wall with the appropriate fixtures.
Make sure they are firmly attached and secure.

Two People



Job complete!

In the interest of our environment please dispose of all packaging thoughtfully.