



Version 1.0



TWO PEOPLE



REQUIRED

Replica Eames

Dining Chair

www.fantasticfurniture.com.au

Caution

Do not stand on, or use this chair as a step ladder.
Use this product for seating one person at a time.
This product should be checked periodically to ensure all
components are secure and all hardware is tight.

RECOMMENDED WEIGHT CAPACITY 120 KG

Enjoy

Your purchase from
Australia's Best Value Furniture Store



Assembly checklist



Read through the instructions carefully before you begin



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.




What you need


To assemble the product



1 x Allen Key



Seat
(P1)



Frame
(P2)

4 x Plastic Washers
(H1)



4 x Spring Washers
(H2)



4 x Washers
(H3)






4 x M6*18 Screws
(H4)



Step 1

You will need:

1 x Seat (P1)	
4 x Plastic Washers (H1)	









Place seat (P1) on a soft covered surface.

Take out the 4 pcs plastic protection cap on the seat by hand before assembly.

Fix with 4 x Plastic Washes (H1) on the seat .

Step 2

1 x Frame (P2)	
4 x Spring Washers (H2)	
4 x Washers (H3)	
4 x Screws (H4)	
1 x Allen Key (H5)	



Position Frame (P2) over the seat (P1).

Align the holes on the Frame (P2) to the Screw holes of the seat (P1).

Fix Frame(P2) to the Seat (P1) with 4 x Washers (H3) and 4 x Spring Washers (H2) and 4 x Screws (H4).

Fully tighten the bolts using Allen Key (H5).

Turn the chair over carefully.



Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.



Version 1.0



TOTO

Table D4

www.fantasticfurniture.com.au

**WARNING : For safety any straps
used to secure hardware or
furniture parts must be removed
before this product is used.**

Enjoy

Your purchase from
Australia's Best Value furniture



Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.

! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.

! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.

! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.

! Never use any glue until you are certain that the parts belong together.


! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.

! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help centre for further assistance.



What you need

to assemble the product



Parts list

Table Top (P1); Table Leg (P2);
Hardware Pack.



1 x Allen Key
(H1)



8 x Bolts
(H2)









8 x Spring Washer
(H3)



8 x Flat Washer
(H4)

Step 1

You will need	
	
8 x Bolts (H2)	1 x Allen Key (H1)
	
Spring Washer (H3)	Flat Washer (H4)



Attach table legs to table apron using Bolts (H2) and Washers (H3) & (H4).

Note : Do not tighten bolts until table is on flat surface.



Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.