




**Fantastic
Furniture**

Version 4.0



Nicki

Chair

fantasticfurniture.com.au



CAUTION:

Use this product for seating one person at a time.
Do not stand on, or use this chair as a step ladder.
Do not rock on chair as this may result in injury.
This product should be checked periodically to ensure
all components are secure and all hardware is tight.

RECOMMENDED WEIGHT CAPACITY 120 KG

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love!



Fantastic Furniture

Love it? Share it!


Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!
@fantasticfurniture




Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful information


- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What you need


to assemble the product




DO NOT USE



2 x Front Leg
(Short)



2 x Back Leg
(Long)



1 x Seat
(P3)


Parts list

2 x Front Leg (Short);

2 x Back Leg (Long);

1 x Seat (P3)

Hardware pack



8 x Bolts
(H1)




8 x Washers
(H2)



4 x Felt Pads
(H3)









1 x Allen Key
(H4)



8 x Spring Washers
(H5)

Step 1


You will need	
	
8 x Bolts (H1)	8 x Washers (H2)
	
4 x Felt pads (H3)	1 x Allen key (H4)
	
8 x Spring Washers (H5)	



Mount 2 x front leg (Short) and 2 x back leg (Long) to seat (P3) using washers (H2), Spring washers (H5), bolts (H1) and allen key (H4). Attach felt pads (H3) to legs. Do not fully tighten Bolts, tighten only 80%


Note: The Front and Back legs have a different construction and the chair will not sit flush unless these are attached to the correct side.

Step 2






Press down on the seat to get all legs in level with the floor.

Step 3




DO NOT USE



Fully tighten 8 x Bolts (H1) to 100% by tightening with the Allen Key (H4)

Step 4



Job Complete!

In the interest of our environment please dispose
of all packaging thoughtfully.