ASSEMBLY INSTRUCTIONS

Please read all instructions carefully before assembly.

ARM CHAIR

Model : ACH-ONOR-SOF-SP-WH

Parts and Hardware

A 1PC 

B 1PC 

C 1PC

D 4PCS 

▶ Parts B, C and D are stored within Part A.

Step 1



Unzip to locate Parts B, C and D



Step 2



Step 3



Adjustable back support

Step 4



⚠ WARNING

1. Do not stand on the product. Do not use it as a step ladder.
2. Do not use the product until all screws are securely fastened.
3. Do not use a sharp tool to open any part of the packaging.