




**Fantastic  
Furniture**

Version 1.0



# Waverley

Trestle Desk

[fantasticfurniture.com.au](http://fantasticfurniture.com.au)



**Glass should always be handled with care**

Scratches, chips, sudden changes in temperature and hairline fractures may cause the glass to break. This glass is designed to break into small, relatively harmless pieces and not sharp fragments.

Avoid placing hot or cold items directly onto the table unless using a thick insulation material such as placemats or coasters.

Avoid dropping objects onto the glass. Do not allow hard or pointed objects to come into contact with the glass. Never use the top area as a chopping surface. Do not sit or stand on the glass surface.

**Recommended weight capacity: 60kgs**

# Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture  
to help create a home you'll love!



# Fantastic Furniture

## Love it? Share it!


Fantastic buy! Share how it looks at home on Instagram for  
your chance to win a \$250 Fantastic Furniture Gift Card!

**@fantasticfurniture**


# Assembly Checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.





Unless instructed, do not fully tighten screws until the item is fully assembled.

## Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

# What you need

to assemble the product



## Parts list

Box 1:

2xTrestle Legs(P2);

Box 2:

1xGlass Top(P1)

## Hardware Pack



8 x Bolts  
(H1)



8 x Washers  
(H2)







1 x Allen Key  
(H3)



8 x Levelling Feet  
(H4)

# Step 1

You will need:	
	
8 x Bolts (H1)	8 x Washers (H2)
	
1 x Allen Key (H3)	





Align the Trestle Leg (P2) screw holes with the metal plates on the Glass Top (P1).

Use 4 x Washers (H2) and 4 x Bolts (H1) to secure the Trestle Leg (P2) to the Glass Top (P1) by tightening with the Allen Key (H3).

Repeat steps to attach the second Trestle Leg (P2).


# Step 2

You will need:

8 x Levelling Feet (H4)



Screw in 8 x Levelling Feet (H4) to the bottom of Trestle Legs (P2x2).

If your floor is uneven the levelling feet can be adjusted to make the desktop level.



# Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.