




**Fantastic  
Furniture**

Version 1.2



**Two People**



**Required**

**Toronto**

**Bookcase 2 Drawer**

[fantasticfurniture.com.au](http://fantasticfurniture.com.au)

# Secure it!

Reduce the risk of furniture tip-over accidents



## WARNING: ENSURE THE WALL STRAP IS ATTACHED TO AVOID SERIOUS INJURY OR DEATH.

To avoid any serious or fatal injury, a wall strap has been provided with this product to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Fixing devices are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.

**NOTE: Recommended weight capacity 40kgs/shelf**

To reduce the risk of furniture tipover:




- Do not allow children to stand, climb or hang on furniture. It may topple and cause serious injury or death.
- Do not place toys or other child appealing items on top of this furniture, and place heaviest items towards the bottom of the furniture.




- Do not open more than one drawer at the time.
- Anchoring this product to a wall or other suitable surface is recommended. Check anchors regularly.
- Avoid putting a TV on this product.

## Wall attachment guide




**For plasterboard**  
(without available wood stud)

**Securing method:**  
Self drilling plasterboard anchor.



**For plasterboard**  
(with available wood stud)

**Securing method:**  
Screw inserted directly into stud.



**For masonry wall**


**Securing method:**  
Solid wall: Plug with screw  
Hollow wall: Spring toggle

Please seek professional advice if you are in doubt of what fixing device to use.


# Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

## Useful Information

! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.

! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.

! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.

! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used as they may not fit through a door once assembled.

! Never use any glue until you are certain that the parts belong together.

! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.

! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.

! Please see page 2 for any safety requirements or weight restrictions.

# What you need

to assemble the product




**DO NOT USE**



Other tools you need :  
Mallet

Parts list:  
Bookcase

Bookcase



## Hardware pack





4 x Gliders  
(H1)


Please make sure you have all these parts before you start.



**Fantastic  
Furniture**

# Step 1

You will need	
4 x Gliders (H1)	
Mallet	




Gently place the bookcase on it's back. Use the mallet to hammer 4 x Gliders (H1) into the bottom of each leg as shown. Ensure that the glides are placed in the middle of the leg before securing.

Two People



Required

## Step 2




Seek advice from a qualified trades person on how to attach safety strap to the wall.

**Two People**




**Required**



We strongly advise that you use the wall safety strap provided to prevent the unit toppling

Gently stand the bookcase upright and move to it's final position. Attach the safety strap to the wall securely. Screw, washer & wall plug are not provided. Please use appropriate fixtures for your wall.



## Job Complete !

In the interest of our environment please dispose of all packing thoughtfully.