SHOE BENCH

MODEL:SS-BN-NEW-C1-WH/WD



ASSEMBLY INSTRUCTIONS

Please read instructions carefully before assembly.



Two persons and tools required for assembly

HARDWARE

A x3	B x6	C x8	D x16	E x16	F x16
	4x10mm	 Ø6x30mm	M3.5x12mm	M5x40mm	
G x1	**H** x1	**I** x2	**J** x2	**K** x2	**L** x1
			M4x12mm		
M x2	**N** x4	**O** x4			
		M4x40mm			

PARTS



Wipe with dry cloths

1





A x2	B x4	K x2	M x2	N x4
	4x10mm			

Secure it!

Preventing furniture tip-over accidents

WARNING: ENSURE THE WALL STRAP IS ATTACHED TO AVOID SERIOUS INJURY.

To avoid any serious or fatal injury, this product has been supplied with a wall strap to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Connecting attachments for your wall are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what wall connections to use.

Recommended weight capacity: 10kg/Drawer

⚠ WARNING

Children have died from furniture tipover.

- ALWAYS secure this furniture with an anchor device.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heavy items down low.

NEVER put a TV on this furniture



Wall anchoring guide



For plasterboard
(with available wood stud)

Securing method:
Self drilling plasterboard anchor.



For plasterboard
(with available wood stud)

Securing method:
Screw inserted directly into stud.



For masonry wall

Securing method:
Solid wall: Plug with screw
Hollow wall: Spring toggle

Please seek professional advise if you are in doubt of what fixing device to use.

2



O	x 4	C	x 4	E	x 8	F	x 8	G	x 1
M4x40mm		Ø6x30mm		M5x40mm					

4



A	x 1	B	x 2
		4x10mm	

H	x 1	L	x 1	D	x 6
				M3.5x12mm	

3



C	x 4	E	x 8	F	x 8	G	x 1	O	x 4
Ø6x30mm		M5x40mm						M4x40mm	

5



D	x 6
M3.5x12mm	

6



I	x 2	J	x 2
			M4x12mm

8



7







D	x 4
	M3.5x12mm

9