




**Fantastic
Furniture**

Version 2.0



TWO PEOPLE



REQUIRED

Dalkeith

Bookcase 4 Shelf

fantasticfurniture.com.au

Secure it!

Reduce the risk of furniture
tip-over accidents



WARNING: ENSURE THE WALL STRAP IS ATTACHED TO AVOID SERIOUS INJURY.

To avoid any serious or fatal injury, a wall strap has been provided with this product to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Fixing devices are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.

WEIGHT CAPACITY: 35 KGS PER SHELF

Tips to further reduce the risk of furniture tip-over accidents:

- Discourage children from climbing or hanging on furniture.
- Keep your heaviest items in the bottom drawers or shelves.
- Do not place TVs or heavy items on top of the furniture.
- Use locking devices on drawers to discourage small children from using them as steps.




Wall attachment guide




For plasterboard
(without available wood stud)

Securing method:
Self drilling plasterboard
anchor.



For plasterboard
(with available wood stud)

Securing method:
Screw inserted directly into
stud.



For masonry wall

Securing method:
Solid wall: Plug with screw
Hollow wall: Spring toggle



Please seek professional advice if you are in doubt of what fixing device to use.

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love



Fantastic Furniture

Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!

@fantasticfurniture

Assembly Checklist




Read through the instruction carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is full assembled.

Useful Information

! Never use power tools unless specifically instructed. They can damage your components or hardware if use incorrectly.

! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.

! Always use a soft surface (such as carpet or cardboard) when assembling your products to avoid scratching or damaging the surface of product.

! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.

! Never use any glue until you are certain that the parts belong together.

! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.

! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.

! Please see page 2 for any safety requirements or weight restrictions.

What you need

To assemble the product



DO NOT USE




Other tools you need


Phillips Head Screwdriver.

Parts list


- 1 x Left Side Frame (P1);
- 1 x Right Side Frame (P2);
- 4 x Shelf Panels (P3);
- 1 x Cross Bar (P4);
- 1 x Cross Bar (P5).



Hardware Pack



20 x Bolts
(H1)



4 x Wooden Dowels
(H2)



1 x Allen Key
(H3)



3 x Screws
(H4)






1 x Wall Strap
(H5)




2 x Washer
(H6)

Step 1



Note: Assemble the bookcase on a soft flat surface to prevent unit from being damaged during assembly.



You will need	
	
4 x Bolts (H1)	4 x Wooden Dowels (H2)
	
1 x Allen Key (H3)	



Insert 4 x Dowels (H2) into Left & Right Side Frames (P1 & P2) as shown. Connect the Cross Bars (P4 & P5) in the middle as shown and attach to Left & Right Side Frames (P1 & P2) with 4 x Bolts (H1) by tightening with the Allen Key (H3).




Step 2

You will need	
	
16 x Bolts (H1)	1 x Allen Key (H3)




Gently slide Shelf Panels (P3x4) into Left & Right Side Frames (P1 & P2). Attach Shelf Panels (P3x4) to Left & Right Side Frames (P1 & P2) with 16 x Bolts (H1) by tightening with Allen Key (H3) as shown.

Step 3





You will need	
	
2 x Screws (H4)	1 x Allen Key (H3)
	
Phillips Head Screwdriver	




Gently stand the partially assembled bookcase upright. Secure Cross Bars (P4 & P5) with 2 x Screws (H4) using the Phillip Head Screwdriver.



Step 4

You will need	
	
1 x Screw (H4)	1 x Washer (H6)
	
Phillips Head Screwdriver	1 x Wall Strap (H5)

Attach Wall Strap (H5) to the top Shelf Panel (P3) as shown with 1 x Washer (H6) and 1 x Screw (H4) by tightening with a Phillips head screwdriver.



Step 5

Will you need




Phillips head screwdriver

Screws and wall plugs are not provided. Please use appropriate fixtures for your wall.

Seek advice from a qualified trades person on how to attach safety strap to the wall.

Move the bookcase to it's final position. If necessary, adjust the levelling feet on the bottom of Left & Right Side Frames (P1 & P2) until the bookcase is level. Attach the bookcase to the wall using the wall strap provided, make sure it is firmly attached and a snug fit.

We strongly advise that you use The wall safety strap provided to prevent the unit toppling



Job complete!

In the interest of our environment please dispose off all packaging thoughtfully.