



Version 1.0









WARNING: ENSURE THE WALL STRAP IS ATTACHED TO AVOID SERIOUS INJURY.

To avoid any serious or fatal injury, this product has been provided with a wall strap to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Fixing devices are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.



GLASS SHOULD ALWAYS BE HANDLED WITH CARE

Scratches, chips, sudden changes in temperature and hairline fractures may cause the glass to break. This glass is designed to break into small, relatively harmless pieces and not sharp fragments.

Avoid placing hot or cold items directly onto the table unless using a thick insulation material such as placemats or coasters.

Avoid dropping objects onto the glass. Do not allow hard or pointed objects to come into contact with the glass. Never use the top area as a chopping surface. Do not sit or stand on the glass surface.

Recommended Weight Capacity 40 kg

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture to help create a home you'll love!



Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for your chance to win a \$250 Fantastic Furniture Gift Card!


@fantasticfurniture




Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



before you begin assembly.



Identify and lay out all of the components Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful information


- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.



What you need

to assemble the product





Parts list


1 x Table Top (P1);


1 x Shelf (P2);

2 x Legs (P3);

2 x Rails (P4);

Hardware pack






Attach shelf (P2) to $2 \times legs$ (P3), by using $4 \times small$ bolts (H2), $4 \times rubber$ washers (H4) and allen key (H7).


Do not fully tighten bolts, tighten only to 80 %

Step 2



Attach 2 x rails (P4) to 2 x legs (P3), using 8 x large bolts (H3) and allen key (H7) Do not fully tighten bolts, tighten only to 80 %


Fantastic Furniture



Lay table top (P1) onto a soft flat surface to avoid damaging the glass. With assistance, lay the assembled leg frame (P3, P4) onto table top (P1) and align the holes. Attach the legs (P3) to table top (P1) using 4 x medium bolts (H1). Insert 2 x wall straps (H6) between glass holder and leg, and align the holes, don't fully tightening bolt (H1) until all bolts (H1) are well inserted.

Step 4







You may now fully tighten the 8 x large bolts (H3) attaching the legs (P2) and rails (P4) using allen key (H7).








You may now fully tighten the 4×8 small bolts (H2) attaching the shelf (P2) to legs (P3) using allen key (H7).



With assistance, carefully turn over the hall table so it is upright. If required, you can extend the foot on each leg by turning it anti-clockwise, or clockwise as required, to ensure the table is level with the ground.

Furniture






We strongly advise that you use the wall straps provided to prevent the unit from toppling


Screws and wall plugs are not provided, please use appropriate fixtures for your wall.

Seek advice from a qualified trades person on how to attach this to your specific wall.



With assistance, move the hall table to its final position. Attach the wall strap to the wall using a wall plug and screws. Ensure it is firmly attached and secure.





Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.