





**Fantastic
Furniture**

Version 1.0



Two People



Required

Kobi

Bookcase Small Narrow

www.fantasticfurniture.com.au

CA3331F0607J02-01

Secure it!

Reduce the risk of furniture tip-over accidents



WARNING: ENSURE THE WALL STRAP IS ATTACHED TO AVOID SERIOUS INJURY OR DEATH.

To avoid any serious or fatal injury, a wall strap has been provided with this product to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Fixing devices are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.

Weight Capacity : 15kgs / Shelf

To reduce the risk of furniture tipover:




- Do not allow children to stand, climb or hang on furniture. It may topple and cause serious injury or death.




- Do not place toys or other child appealing items on top of this furniture, and place heaviest items towards the bottom of the furniture.
- Do not open more than one drawer at the time.
- Anchoring this product to a wall or other suitable surface is recommended. Check anchors regularly.
- Always anchor your TV for safety.

Wall attachment guide




For plasterboard
(without available wood stud)

Securing method:
Self drilling plasterboard anchor.



For plasterboard
(without available wood stud)

Securing method:
Screw inserted directly into stud.




For masonry wall

Securing method:
Solid wall: Plug with screw
Hollow wall: Spring toggle

Please seek professional advice if you are in doubt of what fixing device to use.

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love



Fantastic Furniture


Love it? Share it!

Fantastic buy! Share how it looks at home for your
chance to win a \$250 Fantastic Furniture Gift Card!
@fantasticfurniture


Assembly Checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What You Need

to assemble the product



DO NOT USE




Other Tools You Need

Phillips head screwdriver; Hammer

Parts List

Box 1: Left Side Panel (P1) x 1;
Right Side Panel (P2) x 1;
Top Panel (P3) x 1;
Bottom Panel (P4) x 1;
Shelf Panel (P5) x 2;
Front Panel (P6) x 1
Back Panel (P7) x 1 &
Back Panel (P8) x 1



Hardware Pack:



6 x Wedge
Screws
(H1)




1 x Bracket
Screw
(H2)



2 x Washers
(H3)



8 x Dowels
(H4)



8 x Cam Bolts
(H5)



8 x Cam Nuts
(H6)



4 x Feet
Glides
(H7)



1 x Wall
Bracket
(H8)



8 x Shelf
Studs
(H9)





6 x Wedges
(H10)



Fantastic
Furniture



Step 1


You will need

8 × Dowels (H4)



Insert 2 × Dowels (H4) into Top Panel (P3), 2 × Dowels (H4) into Bottom Panel (P4) and 4 × Dowels (H4) into Front Panel (P6).



Step 2


You will need

8 × Cam Bolts (H5)

Phillips Head Screwdriver



Secure 4 × Cam Bolts (H5) to Left Side Panel (P1) and 4 × Cam Bolts (H5) to Right Side Panel (P2) by tightening with the Phillips Head Screwdriver.


Step 3

You will need

4 x Cam Nuts (H6)

Phillips Head Screwdriver



Insert 2 x Cam Nuts (H6) into Top Panel (P3) and 2 x Cam Nuts (H6) into Bottom Panel (P4) as shown. Rotate the cam nuts so the arrows point towards the incoming cam bolts. Secure the Right Side Panel (P2) to Top & Bottom Panels (P3&P4) by tightening cam nuts with a Phillips Head Screwdriver. Insert Front Panel (P6) into Right Side Panel (P2) as shown.



Step 4




Ensure laminated side of back panels are facing the inside of the bookcase.

Slide Back Panels (P7&P8) into the grooves of Right Side Panel (P2) and Top & Bottom Panels (P3&P4) as shown.


Step 5

You will need

4 x Cam Nuts (H6)

Phillips Head Screwdriver

This is how a cam nut works...






The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.



Insert 2 x Cam Nuts (H6) into Top Panel (P3) and 2 x Cam Nuts (H6) into Bottom Panel (P4) as shown. Rotate the cam nuts so the arrows point towards the incoming cam bolts. Secure the Left Side Panel (P1) to Top & Bottom Panels (P3&P4) by tightening cam nuts with a Phillips Head Screwdriver.




Step 6



You will need

4 × Feet Glides (H7)

Hammer



Secure 4 × Feet Glides (H7) to the bottom of Left & Right Side Panels (P1&P2) with the Hammer. Ensure the feet glides are evenly spaced, approximately 2cm from the end of each panel.

Step 7

You will need

6 × Wedge Screws (H1)

6 × Wedges (H10)

Phillips Head Screwdriver





Insert 6 × Wedges (H10) into Top Panel (P3), Bottom Panel (P4) and Side Panels (P1&P2) as shown and use 6 × Wedge Screws (H1) to secure by tightening with the Phillips Head Screwdriver.

Step 8

You will need









8 × Shelf Studs
(H9)



Insert 8 × Shelf Studs (H9) into the Left & Right Side Panels (P1&P2) at your preferred height. Place the Shelf Panels (P5x2) into the unit by resting each shelf on the shelf studs. Ensure each shelf is positioned securely.

Step 9

You will need	
	
1 x Bracket Screw (H2)	1 x Wall Bracket (H8)
	
1 x Washer (H3)	Phillips Head Screwdriver




Use 1 x Bracket Screw (H2) and 1 x Washer (H3) to secure 1 x Wall Bracket (H8) to Top Panel (P3) as shown by tightening with the Phillips Head Screwdriver.

Step 10


You will need




1 × Washer
(H3)




Phillips Head
Screwdriver



Screws and wall plugs
are not provided,
please use appropriate
fixtures for your wall.



We strongly suggest using the wall bracket provided to prevent this unit from toppling. Seek advice from a qualified tradesperson on how to attach this to your specific wall. Move furniture to its final position, make sure it is firmly attached and a snug fit.



Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.