

Two People



Reed CUPBOARD 2 DOOR BASE fantasticfurniture.com.au

# Secure it!

Reduce the risk of furniture tip-over accidents





To avoid any serious or fatal injury, a wall strap has been provided with this product to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Fixing devices are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.

#### WEIGHT LIMIT: 20 KGS PER SHELF

To reduce the risk of furniture tipover:




- Do not allow children to stand, climb or hang on furniture. It may topple and cause serious injury or death.
- Do not place toys or other child appealing items on top of this furniture, and place heaviest items towards the bottom of the furniture.
- Do not open more than one drawer at the time.
- Anchoring this product to a wall or other suitable surface is recommended. Check anchors regularly.
- Avoid putting a TV on this product.

#### Wall attachment guide




For plasterboard (without available wood stud)

**Securing method:** Self drilling plasterboard anchor.



For plasterboard (with available wood stud)

Securing method: Screw inserted directly into stud.



For masonry wall

Securing method: Solid wall: Plug with screw Hollow wall: Spring toggle

Please seek professional advice if you are in doubt of what fixing device to use.



# Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture to help create a home you'll love!



#### Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for your chance to win a \$250 Fantastic Furniture Gift Card! @fantasticfurniture



#### Assembly Checklist





Read through the instructions carefully before you begin.

Make sure you have all the required tools. Never use power tools unless instructed.





Identify and lay out all of the components before you begin assembly.

Unless instructed, do not fully tighten screws until the item is fully assembled.

## **Useful information**

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 3 for any safety requirements or weight restrictions.




#### What You Need

to assemble the product




**Other tools you need** Phillips head screwdriver;Hammer.




#### Parts list

**Box :** Left Side Panel (P1) Right Side Panel (P2) Top Panel (P3) Bottom Panel (P4) 2 x Ort Panel (P5) Back Panel (P6) Shelf Panel (P7); Steel Bar (P8); Left Door Panel (P9); Right Door Panel (P10),

#### Hardware Pack :









Attach 4 x Hinges (H4) to Left & Right Door Panels (P9&P10) as shown with 8 x Screws (H5) by tightening with the Phillips Head Screwdriver.

Secure 2 x Handles (H7) to the front of Left & Right Door Panels (P9&P10) with 4 x Handle Screws (H8) by tightening with the Phillips Head Screwdriver.


## Step 2



Insert 4 x Dowels (H3) & 4 x Cam Nuts (H1) into Left & Right Side Panels (P1&P2) as shown. Attach 8 x Cam Bolts (H2) to Left & Right Side Panels (P1&P2) by tightening with the Phillips Head Screwdriver. Fantastic furniture.com.au




Insert 4 x Dowels (H3) & 4 x Cam Nuts (H1) into Bottom Panel (P4) as shown. Attach 2 x Cam Bolts (H2) to Bottom Panel (P4) by tightening with the Phillips Head Screwdriver.






Insert 4 x Dowels (H3) & 8 x Cam Nuts (H1) into Support Panels (P5x2) as shown. fantasticfurniture.com.au




Attach Support Panel (P5) to Bottom Panel (P4) by tightening  $2 \times Cam$  Nuts (H1) with the Phillips Head Screwdriver.




Attach Bottom Panel (P4) and Support Panels (P5x2) to Left & Right Side Panels (P1&P2) and secure by tightening all 8 x Cam Nuts (H1) with the Phillips Head Screwdriver.

Fantastic Furniture Page 8



Attach 6 x Cam Bolts (H2) to Top Panel (P3) by tightening with the Phillips Head Screwdriver.




Place the Steel Bar (P8) into the grooves of Left & Right Side Panels (P1&P2). Align the Top Panel (P3) with Support Panel (P5) and Left & Right Side Panels (P1&P2) and attach by tightening the 6 x Cam Nuts (H1).




## Step 9






Carefully align the edges of the Back Panel (P6) with the frame of the partially assembled unit. Secure Back Panel (P6) to Bottom Panel (P4),Top Panel (P3), and Left & Right Side Panels (P1&P2) with 32 x Nails (H9) as shown using the Hammer. Fix each nail 5mm from the edge of the Back Panel (P6).




Secure 6 x Leg Studs (H12) to Support Panel (P5) and Left & Right Side Panels (P1&P2) as shown using the Hammer.

Page 10

## Step 11




Insert 4 x Shelf Supports (H6) into Left & Right Side Panels (P1&P2) at your preferred height. Place Shelf Panel (P7) into the assembled unit and gently rest on the Shelf Supports. Ensure that the Shelf is firmly secured.




Secure 4 x Hinges (H4) on Left & Right Door Panels (P9&P10) to Left & Right Side Panels (P1&P2) with 8 x Screws (H5) as shown by tightening with the Phillips Head Screwdriver.








Attach Wall Strap (H10) to the back of Top Panel (P3) with Washer (H13) and Wall Strap Screw (H11) by tightening with the Phillips Head Screwdriver.





## **Job Complete!**

In the interest of our environment please dispose of all packaging thoughtfully.

