# ELKE

## CHAIR 1 STR WHITE

fantasticfurniture.com.au

# Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love!



**Fantastic Furniture**

## Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for
your chance to win a $250 Fantastic Furniture Gift Card!
**@fantasticfurniture**

# Assembly checklist

Read through the instructions carefully before you begin.

Make sure you have all the required tools. Never use power tools unless instructed.

Identify and lay out all the components before you begin assembly.

Unless instructed, do not fully tighten screws until the item is fully assembled.

# Useful information

! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.

! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.

! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.

! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.

! Never use any glue until you are certain that the parts belong together.

! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.

! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.

! Please see page 2 for any safety requirements or weight restrictions.

**Fantastic Furniture**

# What you need

## to assemble the product

**DO NOT USE**

Back Rest (P1)

Seat Cushion (P6)

Long Corner Block (P4)

Short Corner Block (P5)

Leg Frame (Left) (P2)

Cross Rail (P7)

Leg Frame (Right) (P3)

## Parts list.

Back Rest (P1);
Leg Frame (Left) (P2);
Leg Frame (Right) (P3);
Long Corner Block (P4);
Short Corner Block (P5);
Seat Cushion (P6);
Cross Rail (P7);

## Hardware Pack.

| 1 x Allen Key (H1) | 4 x 60mm Bolt (H2) | 2 x 50mm Bolt (H3) | 8 x 35mm Bolt (H4) | 4 x 25mm Bolt (H5) |
|---|---|---|---|---|
| 14 x Spring Washer (H6) | 14 x Flat Washer (H7) | 1 x Long Screw (H8) | 1 x Short Wood Bolt (H9) | 4 x Wood Button (H10) |

Fantastic Furniture

# Step 1

| You will need | |
|---|---|
| ⌐ | 🔩 |
| 1 x Allen Key (H1) | 1 x Long Screw (H8) |

H1

H8  X 1

(P2)

(P3)

ENSURE BOLT HOLES ARE FACING EACH OTHER IN FRONT AND BACK CORNERS, NOT FACING THE SIDES OF CHAIR.

Attach Leg Frame (Right) (P3) to Leg Frame (Left) (P2) using 1 x Long Screw (H8) by using Allen Key (H1).
DO NOT FULLY TIGHTEN ANY BOLTS OR SCREWS UNTIL STEP 8.

---

# Step 2

| You will need | |
|---|---|
| ⌐ | 🔩 |
| 1 x Allen Key (H1) | 4 x 60mm Bolt (H2) |

H1

H2

X 4

(P2)

(P3)

(P6)

CORRECT POSITION OF BOLT HOLES AT BACK OF CHAIR.

Attach Seat Cushion (P6) to Leg Frame (P2) & (P3) using 4 x 60mm Bolt (H2) by using Allen Key (H1).
DO NOT FULLY TIGHTEN ANY BOLTS OR SCREWS UNTIL STEP 8.

Fantastic Furniture

# Step 3

| You will need | |
|---|---|
| 1 x Allen Key (H1) | 4 x 35mm Bolt (H4) |
| 4 x Spring Washer (H6) | 4 x Flat Washer (H7) |



(P5)

X 4
H7
H6
H4
(P5)
H1

Attach Short Corner Block (P5) to leg Frame (P2) & (P3) using 4 x Spring Washer (H6),
4 x Flat Washer (H7) and 4 x 35mm Bolt (H4) by using Allen Key (H1).
DO NOT FULLY TIGHTEN ANY BOLTS OR SCREWS UNTIL STEP 8.

# Step 4

| You will need | |
|---|---|
| 1 x Allen Key (H1) | 4 x 35mm Bolt (H4) |
| 4 x Spring Washer (H6) | 4 x Flat Washer (H7) |



(P4)

X 4
H7
H6
H4
(P4)
H1

Attach Long Corner Block (P4) to Leg Frame (P2) & (P3) using
4 x Spring Washer (H6),4 x Flat Washer (H7) and 4 x 35mm Bolt (H4)
by using Allen Key (H1).
DO NOT FULLY TIGHTEN ANY BOLTS OR SCREWS UNTIL STEP 8.

# Step 5

| You will need | |
|---|---|
| 1 x Allen Key (H1) | 2 x 50mm Bolt (H3) |
| 2 x Spring Washer (H6) | 2 x Flat Washer (H7) |

Top View

LONG

SHORT

(P7)

H1  H3  H6  H7

X 1

Attach Cross Rail (P7) to Leg Frame (Right) (P3) using 2 x 50mm Bolt (H3),
2 x Spring Washer (H6) and 2 x Flat Washer (H7) by using Allen Key (H1).
DO NOT FULLY TIGHTEN ANY BOLTS OR SCREWS UNTIL STEP 8.

# Step 6

| You will need | |
|---|---|
| 1 x Allen Key (H1) | 1 x Short Wood Bolt (H9) |

H1

X 1

H9

Secure Cross Rail (P7) using 1 x Short Wood Bolt (H9).
DO NOT FULLY TIGHTEN ANY BOLTS OR SCREWS UNTIL STEP 8.

# Step 7

| You will need | |
|---|---|
| 1 x Allen Key (H1) | 4 x 25mm Bolt (H5) |
| 4 x Spring Washer (H6) | 4 x Flat Washer (H7) |

X 4

H7
H6
H5
H1

(Turn Chair upright)

Attach Back Rest (P1) to Leg Frame (P2) & (P3) using  4 x Flat Washer (H7),
4 x Spring Washer (H6),  and 4 x 25mm Bolt (H5)  by using Allen Key (H1).
DO NOT FULLY TIGHTEN ANY BOLTS OR SCREWS UNTIL STEP 8.

# Step 8

| You will need |
|---|
| 4 x Wood Button (H10) |

X 4

H10

Place chair on a flat surface and press the seat to level the legs. Tighten all screws
and bolts .Attach 4 X Wood Button (H10) to Leg Frame (P2) & (P3)
by pushing into hole firmly.

Fantastic Furniture

# Job complete!

In the interest of our environment please
dispose of all packaging thoughfully.

Fantastic
Furniture