Assembly Instructions
COMO
Queen Bed

2 PEOPLE REQUIRED

VER 1.2

FaNTaSTiC FURNITURE

WARNING

FAILURE TO FOLLOW THESE BASIC STEPS CAN LEAD TO DAMAGE THAT IS NOT COVERED BY YOUR WARRANTY

1

Read Instructions carefully. Check no parts are missing.

2

Lay out all of the components on a soft surface as if you were preparing to do a jigsaw puzzle.

3

Carefully identify each component, especially those that are similar. The most common mistake is getting things back to front.

4

Separate and identify each component from the hardware pack and rest each one in its proper location before fastening.

5

DO NOT USE

DO NOT fully tighten screws (leave slightly loose).When the item is fully assembled tighten the screws - but do not over tighten.

6

If glue is required DO NOT set until you are certain that the parts belong together.

What You Need

## To Assemble The Body

(Tools not provided)
Flat BladeScrewdriver
Phillips Head Screwdriver
Mallet

DO NOT USE

Bedhead (P1)

Rail (P4)

Side Rail (P3)

Supporter (P15)

Central Rail (P5)

Support Leg (P6)

Block (P16)

Block (P16)

Side Rail (P3)

Block (P16)

Clapboard (P7)

Block (P16)

Support Leg (P6)

Supporter (P15)

Bedfoot (P2)

Rail (P4)

Drawer Back (P12)

Right Drawer Side (P10)

Central Drawer Support (P13)

Drawer Base (P11)

x 4

2 x Drawer Supports (P14)

Left Drawer Side (P9)

Drawer Front (P8)

28 x End Connectors

14 x Centre Connectors

28 x Fantastic Furniture ComfortSlats™ Queen

4 x Inside Hexagonal Screws (H1)

46 x Small Dowels (H2)

2 x Cam Bolts (H3)

2 x Cam Nuts (H4)

24 x Screws (Ø4 x 25) (H5)

40 x Screws (Ø4 x 30) (H6)

7 x Long Screws (Ø4 x 35) (H7)

20 x Small Cam Bolts (H8)

20 x Small Cam Nuts (H9)

12 x Bolts (H10)

4 x Elbow Connectors (H11)

4 x Flat Connectors (H12)

11 x Plastic Glides (H13)

32 x Small Screws (Ø3.5 x 12) (H14)

16 x Wheels (H15)

2 x Stickers (H16)

1 x Allen Key (Large) (H17)

1 x Allen Key (Medium) (H18)

Please make sure you have all these parts before you start.

Step 1

You will need:

2 x Cam Bolts (H3)	
16 x Screws (H5)	
4 x Elbow Connectors (H11)	

H5 H5
H5 H5
H5 H5
H11

(P2)

H3

(P3)

H5

H11

H3

Attach 1 x Cam Bolt (H3) to Side Rail (P3).
Attach 2 x Elbow Connectors (H11) to Side Rail (P3) with 8 x Screws (H5).
Repeat Step 1 again with the other Side Rail (P3).

Step 2

You will need:

8 x Screws (H6)	
2 x Long Screws (H7)	
2 x Flat Connetors (H12)	
3 x Plastic Glides (H13)	

Make sure the bottom of the "U" shape is facing to the bottom rough side of Bedhead (P1).

H6 H6
H12

H7
H7

(P1)

H13

(P15)

H6
H6
H12

H13

H13

Attach 2 x Flat Connectors (H12) to Bedhead (P1) with 8 x Screws (H6).
Attach Supporter (P15) to Bedhead (P1) with 2 x Long Screws (H7).
Then hammer 3 x Plastic Glides (H13) on the bottom of Bedhead (P1).

Step 3

You will need:

8 x Screws (H6)	
2 x Long Screws (H7)	
2 x Flat Connetors (H12)	
3 x Plastic Glides (H13)	

Make sure the bottom of the "U" shape is facing to the bottom rough side of Bedfoot (P2).

H6 H6 H12

(P2)

H7 H7

(P15)

H6 H6 H12

H13

H13

H13

Attach 2 x Flat Connectors (H12) to Bedfoot (P2) with 8 x Screws (H6).
Attach Supporter (P15) to Bedfoot (P2) with 2 x Long Screws (H7).
Then hammer 3 x Plastic Glides (H13) on the bottom of Bedfoot (P2).

Step 4

You will need:

2 x Small Dowels (H2)	
2 x Cam Nuts (H4)	

This is how a cam nut works........

The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.

(P3)

(P7)

H2

H4

(P3)

2 PEOPLE REQUIRED

Insert 2 x Small Dowels (H2) into Side Rails (P3).
Insert 2 x Cam Nuts (H4) into the holes of Clapboard (P7).
Rotate the cam nuts so the arrow point towards the incoming cam bolts.
Push Side Rails (P3) into place and tighten the cam nuts.

Step 5

You will need:

2 x Long Screws (H7)	
3 x Plastic Glides (H13)	

H13

H13

H13

H13

MAKE SURE TWO ENDS ALIGN

H7

(P4)

(P7)

(P4)

H7

2 PEOPLE REQUIRED

Attach Rails (P4) to Clapboard (P7) with 2 x Long Screws (H7).
Then hammer 3 x Plastic Glides (H13) on the bottom of Clapboard (P7).

Step 6

You will need:

4 x Small Dowels (H2)	
6 x Bolts (H10)	
1 x Allen Key (Large) (H17)	

H2

H2

(P2)

H10

H17

(P3)

(P3)

2 PEOPLE REQUIRED

Insert 4 x Small Dowels (H2) into the holes of Bedfoot (P2).
Attach Side Rails (P3) to Bedfoot (P2) with 6 x Bolts (H10) using Allen Key (H17).
Do not fully tighten bolts, leave a little loose at this stage.

Step 7

You will need:

4 x Small Dowels (H2)	
6 x Bolts (H10)	
1 x Allen Key (Large) (H17)	

(P1)

2 PEOPLE CAREFULLY
TURN OVER THE BED FRAME

H10
H2
H2
H10

(P3)

(P3)

2 PEOPLE REQUIRED

H17

Insert 4 x Small Dowels (H2) into the holes of Bedhead (P1).
Attach Side Rails (P3) to Bedhead (P1) with 6 x Bolts (H10) using Allen Key (H17). Tighten firmly.
Move the bed to final position then check and tighten all bolts attaching the Side Rails
to the Bedhead and Bedfoot.

Step 8

You will need:

8 x Screws (H5)	

(P4)

(P16)
H5
(P16)
H5
H5
(P16)
H5
A
H5
H5
(P16)
H5
H5
A
(P6)

H5   H5   H5   H5

SECTION A-A

Attach 4 x Blocks (P16) to Rails (P4) with 8 x Screws (H5).

Step 9

You will need:	
2 x Plastic Glides (H13)	

H13

(P6)

H13

(P6)

(P5)

Attach 2 x Support Legs (P6) to Central Rail (P5), until it is firmly attached.
Then hammer 2 x Plastic Glides (H13) on Support Legs (P6).

Step 10

You will need:	
1 x Long Screws (H7)	
2 x Stickers (H16)	
4 x Inside Hexagonal Screws (H1)	
1 x Allen Key (Medium) (H18)	

(P1)

H1

H1

H18

(P5)

H7

H16

(P7)

H16

(P2)

Put Central Rail (P5) into the right place as shown.
Attach Central Rail to Bedhead (P1) and Beadfoot (P2) with 4 x Inside Hexagonal Screws (H1)
using Allen Key (H18) and Clapboard (P7) with 1 x Long Screw (H7).
Attach 2 x Stickers (H16) to the holes of Rails (P4).

Step 11

You will need:

5 x Small Dowels (H2)	
5 x Small Cam Bolts (H8)	

H8 H8 H2
H8
H8 H2
(P8)
H2 H8
H8

Insert 5 x Small Dowels (H2) into Drawer Front (P8), and attach 5 x Small Cam Bolts (H8) to it.

Step 12

You will need:

|	
8 x Small Screws (H14)	
4 x Wheels (H15)	

H14
H14
H15
H14 H14
H15
(P14)

Attach 2 x Wheels (H15) to Drawer Support (P14) with 4 x Small Screws (H14).
Repeat Step 12 again with the other Drawer Support (P14).

Step 13

You will need:

5 x Small Cam Nuts (H9)	

(P9) (P14)
(P9) (P10)
Grooves should face inside.
H9 H9
H9 (P13) (P14)
H9
(P10)
(P8)
H9
H9

This is how a cam nut works........

The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.

Insert 5 x Small Cam Nuts (H9) into the holes of Drawer Sides (P9,P10) and Central Drawer Support (P13).
Rotate the cam nuts so the arrows point towards the incoming cam bolts.
Push Drawer Sides (P9,P10) and Drawer Supports (P13、P14) into place and tighten the cam nuts.

Step 14

You will need:

4 x Small Dowels (H2)	

H2 H2

(P9) (P11) H2 H2

(P10)

Slide Drawer Base (P11) into the groove in the middle of Drawer Sides (P9,P10).
Insert 4 x Small Dowels (H2) into 2 x Drawer Supports (P14).

Step 15

You will need:

6 x Screws (H6)	

(P10)

H6

H6

H6 H6 (P12) H6 (P9)

H6

Attach Drawer Sides (P9,P10) to Drawer Back (P12) with 4 x Screws (H6),
then attach Drawer Back (P12) to Central Drawer Support (P13) with 2 x Screws (H6).
Make sure that the groove lines up the whole way around the drawer.

Step 16

Repeat step 11 to step 15 to assemble other 3 drawers.

Step 17

| You will need:	
28 x End Connectors	
28 x Fantastic Furniture ComfortSlats™ Queen	
14 x Centre Connectors	

HOW TO FIT YOUR COMFORT SLATS

1

Push 2 End Connectors, 2 Fantastic Furniture ComfortSlats™ Queen and a Centre Connector together.

2

Insert the full slat into the side rail and centre rail one by one.

3

Sometimes it makes it easier to line up the hole
if you press down in the middle of the slat to flatten it out.

4

Repeat for every bed slat until finished.

Step 18

Put the drawers into the bed.

The job is now complete!

In the interest of our environment
Please dispose of all packaging thoughtfully.