




**Fantastic
Furniture**

Version 1.0



Hamilton

Lowline Large

fantasticfurniture.com.au

Recommended weight capacity : 50kgs on top.

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love!



Fantastic Furniture

Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!

@fantasticfurniture


Assembly Checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What you need

to assemble the product




DO NOT USE




Other tools you need:
Phillips head screwdriver

Parts list


Top Panel (P1);
Left Side Panel (P2);
Right Side Panel (P3);
Divider (P4);
Divider (P5);
Shelf Panel (P6);
Bottom Panel (P7);
2 x Back Panels (P8);
Back Panel (P9);
2 x Door (P10) :
Rail (P11);
2 x Support Leg (P12)




Hardware pack




Step 1


You will need	
	
8 x Cam Bolts (H3)	2 x magnetics (H8)
	
4 x Wedge Screws (H13)	Phillips Head Screwdriver



Attach 8 x Cam Bolts (H3) and 2 x Magnetics (H8) to Top Panel (P1) with 4 x Wedge Screws (H13) by tightening with the Phillips Head Screwdriver.


Step 2

You will need	
	
6 x Cam Bolts (H3)	Phillips Head Screwdriver




Attach 6 x Cam Bolts (H3) to Left & Right Side Panels (P2&P3) by tightening with the Phillips Head Screwdriver.


Step 3

You will need	
	
2 x Dowels (H1)	3 x Cam Bolts (H3)
	
3 x Cam Nuts (H4)	Phillips Head Screwdriver

This is how a cam nut works.....





The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.



Attach 3 x Cam Bolts (H3) to Rail (P11) by tightening with the Phillips Head Screwdriver. Insert 2 x Dowels (H1) into Bottom Panel (P7) as shown. Insert 3 x Cam Nuts (H4) into Bottom Panel (P7) as shown. Rotate the cam nuts so the arrow points towards the incoming cam bolts. Attach Rail (P11) to Bottom Panel (P7) by tightening the Cam Nuts (H4) with the Phillips Head Screwdriver.


Step 4


You will need	
	
2 x Dowels (H1)	3 x Cam Nuts (H4)
	
Phillips Head Screwdriver	



Insert 2 x Dowels (H1) into Left Side Panel (P2) as shown. Insert 3x Cam Nuts (H4) into Rail & Bottom Panel (P11&P7) as shown. Rotate the cam nuts so the arrow points towards the incoming cam bolts. Attach Rail & Bottom Panel (P11&P7) to Left Side Panels (P2) by tightening the Cam Nuts (H4) with the Phillips Head Screwdriver.

Step 5


You will need	
	
2 x Dowels (H1)	3 x Cam Nuts (H4)
	
Phillips Head Screwdriver	



Insert 2 x Dowels (H1) into Right Side Panel (P3) as shown. Insert 3 x Cam Nuts (H4) into Rail & Bottom Panel (P11&P7) as shown. Rotate the cam nuts so the arrow points towards the incoming cam bolts. Attach Rail & Bottom Panel (P11&P7) to Right Side Panel (P3) by tightening the Cam Nuts (H4) with the Phillips Head Screwdriver.


Step 6

You will need	
	
4 x Cam Bolts (H3)	Phillips Head Screwdriver




Attach 4 x Cam Bolts (H3) to Dividers (P4&P5) by tightening with the Phillips Head Screwdriver.

Step 7


You will need	
	
4 x Dowels (H1)	4 x Cam Nuts (H4)
	
Phillips Head Screwdriver	

Insert 4 x Dowels (H1) into Dividers (P4&P5) as shown. Insert 4x Cam Nuts (H4) into Shelf Panel (P6) as shown. Rotate the cam nuts so the arrow points towards the incoming cam bolts. Attach Dividers (P4&P5) to Shelf Panel (P6) by tightening the Cam Nuts (H4) with the Phillips Head Screwdriver.



Step 8


You will need	
	
4 x Dowels (H1)	4 x Screws (H2)
	
Phillips Head Screwdriver	



Insert 4 x Dowels (H1) into Bottom Panel (P7) as shown. Attach Dividers (P4&P5) to Bottom Panel (P7) with 4 x Screws (H2) by tightening with the Phillips Head Screwdriver.


Step 9

You will need	
	
2 x Adjusters (H7)	




Attach Adjustable Support Legs (P12x2) to Bottom Panel (P7). Attach 2 x Adjusters (H7) to Support Legs (P12x2).


Step 10



Gently stand the unit upright. Slide Back Panels (P8x2 & P9) into the grooves of Dividers & Left & Right Side Panels (P4 & P5 & P2 & P3).


Step 11


You will need	
	
8 x Cam Nuts (H4)	4 x Dowels (H1)
	
Phillips Head Screwdriver	



Insert 4 x Dowels (H1) into Left & Right Side Panels (P2&P3) as shown. Insert 8x Cam Nuts (H4) into Dividers & Left & Right Side Panels (P4&P5&P2&P3) as shown. Rotate the cam nuts so the arrow points towards the incoming cam bolts. Attach Top Panel (P1) to Dividers & Left & Right Side Panels (P4&P5&P2&P3) by tightening the Cam Nuts (H4) with the Phillips Head Screwdriver.

Step 12


You will need	
	
8 x Small Screws (H5)	4 x Hinges (H9)
	
Phillips Head Screwdriver	



Attach 4 x Hinges (H9) to Doors (P10x2) with 8 x Small Screws (H5) by tightening with the Phillips Head Screwdriver.

Step 13


You will need	
	
10 x Small Screws (H5)	2 x Handles (H10)
	
2 x Handle Bolts (H11)	2 x Magnetics Bars (H6)
	
Phillips Head Screwdriver	




Attach Doors (P10x2) to Left & Right Side Panels (P2&P3) with 8x Small Screws (H5) and attach 2 x Handles (H10) to Doors (P10x2) with 2 x Handle Bolts (H11) by tightening with the Phillips Head Screwdriver. attach 2 x Magnetics (H6) to Doors (P10x2) with 2 x Small Screws (H5) by tightening with the Phillips Head Screwdriver.

Step 14

You will need	
	
8 x Wedges (H12)	8 x Wedge Screws (H13)
	
Phillips Head Screwdriver	



Secure Back Panels (P8 & P9 x 2) in place with 8 x Wedges (H12) using 8 x Wedge Screws (H13) by tightening with the Phillips Head Screwdriver.



Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.