




**Fantastic  
Furniture**

Version 1.0



# Havana

Coffee Table Rectangle

[fantasticfurniture.com.au](http://fantasticfurniture.com.au)

Recommended weight capacity : 80kg.

## Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture  
to help create a home you'll love!



# Fantastic Furniture

### Love it? Share it!


Fantastic buy! Share how it looks at home on Instagram for  
your chance to win a \$250 Fantastic Furniture Gift Card!

**@fantasticfurniture**


# Assembly Checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

## Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

# What you need


to assemble the product



DO NOT USE




**Other tools you need:**  
Phillips Head Screwdriver;  
Hammer




## Parts list


Top Panel (P1);  
Bottom Panel (P2);  
Divider (P3); Leg (P4);  
Drawer Front (P5);  
Left Drawer Side (P6);  
Right Drawer Side (P7);  
Drawer Base (P8);  
Drawer Back (P9);  
Support Leg (P10);




## Hardware pack





# Step 1


You will need	
	
12 x Cam Bolts (H3)	Phillips Head Screwdriver



Attach 8 x Cam Bolts (H3) into Top Panel (P1).  
 Attach 1 x Cam Bolts (H3) into Leg (P4). Repeat this step for the rest of 3 x Legs (P4).  
 Tighten Cam Bolts using a Phillips Head Screwdriver.

# Step 2


You will need	
	
2 x CL Runner Tracks (H6)	2 x CR Runner Tracks (H7)
	
8 x Small Screws (H5)	Phillips Head Screwdriver



Attach 1 x CL Runner Tracks (H6) and 1 x CR Runner Tracks (H7) to Divider (P3) with 4 x Small Screws (H5). Tighten Screws using a Phillips Head Screwdriver.  
 Repeat Step 2 for the other Divider (P3).

# Step 3


You will need	
	
4 x Small Dowels (H2)	4 x Inside Hexagonal Screws (H13)
	
1 x Allen Key (H18)	



Insert 4 x Small Dowels (H2) into Dividers (P3).  
 Attach Dividers (P3) to Bottom Panel (P2) with 4 x Inside Hexagonal Screws (H13) using Allen Key (H18).

# Step 4


You will need	
	
4 x Dowels (H1)	2 x Cam Nuts (H4)
	
Phillips Head Screwdriver	



Insert 4 x Dowels (H1) and 2 x Cam Nuts (H4) into the holes of Bottom Panel (P2) as shown. Rotate the cam nuts so the arrows point towards the incoming cam bolts. Attach 2 x Legs (P4) to Bottom Panel (P2), then tighten the cam nuts using a Phillips Head Screwdriver.

# Step 5


You will need	
	
4 x Dowels (H1)	2 x Cam Nuts (H4)
	
5 x Plastic Glides (H14)	1 x Double Ended Screws (H17)
	
Hammer	Phillips Head Screwdriver



Insert 4 x Dowels (H1) and 2 x Cam Nuts (H4) into the holes of Bottom Panel (P2) as shown. Rotate the cam nuts so the arrows point towards the incoming cam bolts. Attach 2 x Legs (P4) to Bottom Panel (P2), then tighten the cam nuts using a Phillips Head Screwdriver. Attach Support Leg (P10) to Bottom Panel (P2) with 1 x Double Ended Screws (H17). Hammer 5 x Plastic Glides (H14) on 4 x Legs (P4) and Support Leg (P10).

## Step 6


You will need	
	
8 x Dowels (H1)	4 x Small Dowels (H2)
	
8 x Cam Nuts (H4)	Phillips Head Screwdriver



Insert 8 x Dowels (H1) into Legs (P4). Insert 4 x Small Dowels (H2) into Dividers (P3). Insert 8 x Cam Nuts (H4) into the holes of Dividers (P3) and Legs (P4). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Attach Top Panel (P1) and tighten the cam nuts using a Phillips Head Screwdriver.

## Step 7


You will need	
	
4 x Small Cam Bolts (H10)	Phillips head screwdriver




Screw 4 x Small Cam Bolts (H10) into Drawer Front (P5) with a Phillips head screwdriver.

## Step 8

You will need	
	
4 x Small Cam Nuts (H11)	Phillips Head Screwdriver




This is how a cam nut works.....



The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.

Insert 4 x Small Cam Nuts (H11) into the holes of Drawer Sides (P6) and (P7). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Push Drawer Sides (P6) and (P7) into place and tighten the cam nuts using a Phillips Head Screwdriver.


## Step 9



Slide Drawer Base (P8) into the groove in Drawer Sides (P6) and (P7).

## Step 10


You will need	
	
4 x Long Screws (H12)	Phillips head screwdriver



Attach Drawer Back (P9) to Drawer Sides (P6) and (P7) with 4 x Long Screws (H12), make sure that the groove lines up the whole way around the drawer. Tighten Screws using a Phillips Head Screwdriver.

## Step 11


You will need	
1 x DL Runner (H8)	1 x DR Runner (H9)
4 x Small Screws (H5)	Phillips head screwdriver



Attach 1 x DL Runner (H8) to the bottom of Left Drawer Side (P6) and 1 x DR Runner (H9) to the bottom of Right Drawer Side (P7) with 4 x Small Screws (H5). Tighten Screws using a Phillips Head Screwdriver.


## Step 12

You will need	
1 x Handle (H15)	2 x Round Head Bolts (H16)
Phillips head screwdriver	




Attach 1 x Handle (H15) to Drawer Front (P5) with 2 x Round Head Bolts (H16). Tighten Round Head Bolts using a Phillips Head Screwdriver.

## Step 13




Repeat step 7 to step 12 to assemble the other drawer.

## Step 14



Put the drawers into the table.

## Step 15



# Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.