




**Fantastic
Furniture**

Version 1.0



Hamilton

Lowline Small

fantasticfurniture.com.au

Recommended weight capacity : 50kgs on top.

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love!



Fantastic Furniture

Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!

@fantasticfurniture


Assembly Checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What you need

to assemble the product





DO NOT USE




Other tools you need:
Phillips head screwdriver;
Hammer

Parts list



Top Panel (P1);
Left Side Panel (P2);
Right Side Panel (P3);
Shelf Panel (P4);
Rail (P5);
Rail (P6);
Back panel (P7);
Back panel(P8);
2 x Drawer Fronts (P9);
2 x Left Drawer Sides (P10) ;
2 x Right Drawer Sides (P11);
2 x Drawer Bases (P12);
2 x Drawer Backs (P13);
Divider (P14);
Divider (P15)




Hardware pack




Step 1


You will need	
	
6 x Small Screws (H5)	1 x CL Runner Tracks (H6)
	
1 x CR Runner Tracks (H7)	Phillips Head Screwdriver



Attach 1 x CL Runner Track (H6) to Left Side Panel (P2) and 1 x CR Runner Track (H7) to the Right Side Panel (P3) with 6 x Small Screws (H5) by tightening with the Phillips Head Screwdriver.



Step 2


You will need	
	
6 x Dowels (H1)	10 x Cam Bolts (H3)
	
Phillips Head Screwdriver	



Insert 6x dowels (H1) to Left & Right Side Panels (P2&P3) as shown. Attach 10 x Cam Bolts (H3) to Left & Right Side Panels (P2&P3) by tightening with the Phillips Head Screwdriver.



Step 3


You will need	
	
6x Small Screws (H5)	1 x CL Runner Tracks (H6)
	
1 x CR Runner Tracks (H7)	Phillips Head Screwdriver



Attach 1 x CL Runner Track (H6) to Divider (P15) with 6 x Small Screws (H5) by tightening with the Phillips Head Screwdriver. Flip the Divider (P15), and attach 1 x CR Runner Track (H7) to Divider (P15) with 6 x Small Screws (H5) by tightening with the Phillips Head Screwdriver.

Step 4

You will need	
	
2 x Dowels (H1)	2 x Cam Bolts (H3)
	
2 x Large Screws (H2)	Phillips Head Screwdriver





Attach 2 x Cam Bolts (H3) into Shelf Panel (P4). Insert 2 x Dowels (H1) into Divider (P14) as shown. Attach Divider (P14) to Shelf Panel (P4) with 2 x Large Screws (H2) by tightening with the Phillips Head Screwdriver.


Step 5

You will need	
	
1 x Cam Bolts (H3)	1 x Cam Nuts (H4)
	
Phillips Head Screwdriver	

Caution!!
Cam nut hole must face downward



This is how a cam nut works.....




The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so the arrow points towards the bolt.

Attach 1 x Cam Bolt (H3) into Rail (P5) by tightening with the Phillips Head Screwdriver. Insert 1 x Cam Nut (H4) into the hole of Rail (P5). Rotate the cam nuts so the arrow points towards the incoming cam bolts. Attach Rails (P5) to Divider (P15) by tightening with the Phillips Head Screwdriver.

Step 6


You will need	
	
2 x Large Screws (H2)	Phillips Head Screwdriver



Attach Rail (P6) to Divider (P15) with 2 x Large Screws (H2) by tightening with the Phillips Head Screwdriver.

Step 7


You will need	
	
2 x Cam Nuts (H4)	Phillips Head Screwdriver



Insert 2 x Cam Nuts (H4) into the holes of Divider (P15). Rotate the cam nuts so the arrow points towards the incoming cam bolts. Attach Divider (P15) to Shelf Panel (P4) by tightening with the Phillips Head Screwdriver.

Step 8


You will need	
	
5 x Cam Nuts (H4)	Phillips Head Screwdriver



Insert 5 x Cam Nuts (H4) into the holes of Rails & Shelf Panel (P5 & P6 & P4). Rotate the cam nuts so the arrow points towards the incoming cam bolts. Attach Rails & Shelf Panel (P5 & P6 & P4) to Left Side Panel (P2) by tightening with the Phillips Head Screwdriver. Slide Back Panel (P8) into the grooves of Rail & Shelf Panel (P6&P4).

Step 9


You will need	
	
5 x Cam Nuts (H4)	Phillips Head Screwdriver



Insert 5 x Cam Nuts (H4) into the holes of Rails & Shelf Panel (P5 & P6 & P4). Rotate the cam nuts so the arrow points towards the incoming cam bolts. Attach Rails & Shelf Panel (P5 & P6 & P4) to Right Side Panel (P3) by tightening with the Phillips Head Screwdriver.

Step 10

You will need	
	
6 x Cam Bolts (H3)	Phillips Head Screwdriver




Attach 6 x Cam Bolts (H3) to Top Panel (P1) by tightening with the Phillips Head Screwdriver.

Step 11


You will need	
	
6 x Cam Nuts (H4)	Phillips Head Screwdriver

Gently stand the unit upright. Slide Back Panel (P7) into the grooves of Left & Right Side Panel (P2&P3). Insert 6 x Cam Nuts (H4) into Divider & Right & Left Side Panels (P14&P3&P2) as shown. Rotate the cam nuts so the arrows point towards the incoming cam bolts. Attach Top Panel (P1) to unit by tightening cam nuts with the Phillips Head Screwdriver.



Step 12


You will need	
	
4 x Wedges (H12)	4 x Wedge Screws (H13)
	
Phillips Head Screwdriver	



Secure Back Panels (P7 & P8) in place with 4 x Wedges (H12) using 4 x Wedge Screws (H13) by tightening with the Phillips Head Screwdriver.

Step 13


You will need	
	
8 x Cam Bolts (H3)	Phillips Head Screwdriver



Attach 8 x Cam Bolts (H3) to Drawer Fronts (P9x2) by tightening with the Phillips Head Screwdriver.


Step 14

You will need	
	
8 x Cam Nuts (H4)	Phillips Head Screwdriver



Insert 8 x Cam Nuts (H4) into Left & Right Drawer Sides (P10x2&P11x2) as shown. Rotate the cam nuts so the arrows point towards the incoming cam bolts. Attach Left & Right Drawer Sides (P10x2&P11x2) to Drawer Fronts (P9x2) by tightening the cam nuts with the Phillips Head Screwdriver.


Step 15



Slide Drawer Bases (P12x2) into the grooves of Left & Right Drawer Sides (P10x2&P11x2).

Step 16


You will need	
	
8 x Large Screws (H2)	Phillips Head Screwdriver



Attach Drawer Backs (P13x2) to Left & Right Drawer Sides (P10x2&P11x2) with 8 x Large Screws (H2) by tightening with the Phillips Head Screwdriver. Ensure the Drawer Base lines up with the grooves the whole way around the drawer before securing.

Step 17


You will need	
	
2 x DL Runners (H8)	2 x DR Runners (H9)
	
8 x Small Screws (H5)	Phillips Head Screwdriver



Attach 2 x DL Runners (H8) to the bottom of Left Drawer Sides (P10x2) and 2 x DR Runners (H9) to the bottom of Right Drawer Sides (P11x2) with 8 x Small Screws (H5) by tightening with the Phillips Head Screwdriver.


Step 18

You will need	
	
2 x Handle Bolts (H11)	2 x Handles (H10)
	
Phillips Head Screwdriver	




Attach 2 x Handles (H11) to Drawer Fronts (P9x2) with 2 x Handle Bolts (H10) by tightening with the Phillips Head Screwdriver.

Step 19



Carefully insert the drawers into the lowline by gently guiding the runners into the tracks.



Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.