




**Fantastic
Furniture**

Version 1.0



Eden
Utility 5 Shelf

fantasticfurniture.com.au

Secure it!

Reduce the risk of furniture tip-over accidents



WARNING: ENSURE THE WALL STRAP IS ATTACHED TO AVOID SERIOUS INJURY OR DEATH.

To avoid any serious or fatal injury, a wall strap has been provided with this product to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Fixing devices are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.

Recommended Weight Capacity :15kg/shelf

To reduce the risk of furniture tipover:




- Do not allow children to stand, climb or hang on furniture. It may topple and cause serious injury or death.




- Do not place toys or other child appealing items on top of this furniture, and place heaviest items towards the bottom of the furniture.
- Do not open more than one drawer at the time.
- Anchoring this product to a wall or other suitable surface is recommended. Check anchors regularly.
- Avoid putting a TV on this product.

Wall attachment guide




For plasterboard
(without available wood stud)

Securing method:
Self drilling plasterboard anchor.



For plasterboard
(with available wood stud)

Securing method:
Screw inserted directly into stud.



For masonry wall

Securing method:
Solid wall: Plug with screw
Hollow wall: Spring toggle

Please seek professional advice if you are in doubt of what fixing device to use.

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love!



Fantastic Furniture

Love it? Share it!


Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!

@fantasticfurniture


Assembly Checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What you need

to assemble the product




DO NOT USE



Other tools you need:

Phillips head screwdriver;
Hammer


Left Side
Panel (P2)





Parts list


2 x Top/Base Panels (P1);
Left Side Panel (P2);
Right Side Panel (P3);
3 x Shelf Panels (P4);
Fixed Shelf Panel (P5);
2 x Back Panels (P6);
2 x Rails (P7);
2 x Back Panels (P8);

Hardware pack





Step 1


You will need	
	
8 x Cam Bolts (H3)	Phillips Head Screwdriver



Attach 8 x Cam Bolts (H3) to Left Side Panel (P2) as shown by tightening with the Phillips Head Screwdriver.




Step 2

You will need	
	
8 x Cam Bolts (H3)	Phillips Head Screwdriver




Attach 8 x Cam Bolts (H3) to Right Side Panel (P3) as shown by tightening with the Phillips Head Screwdriver.


Step 3

You will need	
	
8 x Dowels (H1)	8 x Cam Nuts (H4)
	
Phillips Head Screwdriver	

This is how a cam nut works.....




The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.






Insert 8 x Dowels (H1) into Left Side Panel (P2). Insert 8 x Cam Nuts (H4) into Top/Base Panels (P1 x 2), Fixed Shelf Panel (P5) and Rails (P7 x 2). Rotate the nuts so the arrows point towards the incoming bolts. Attach Top/Base Panels (P1 x 2), Fixed Shelf Panel (P5) and Rails (P7 x 2) to Left Side Panel (P2) by tightening all nuts with the Phillips Head Screwdriver.


Step 4



Slide Back Panels (P6 x 2 & P8 x 2) into the grooves of Top/Base Panels (P1 x 2) and Fixed Shelf Panel (P5).



Step 5


You will need	
	
8 x Dowels (H1)	8 x Cam Nuts (H4)
	
Phillips Head Screwdriver	



Insert 8 x Dowels (H1) into Top/Base Panels (P1 x 2), Fixed Panel (P5) and Rails (P7 x 2). Insert 8 x Cam Nuts (H4) into Top/Base Panels (P1 x 2), Fixed Shelf Panel (P5) and Rails (P7 x 2). Rotate the nuts so the arrows point towards the incoming bolts. Attach Right Side Panel (P3) to Top/Base Panels (P1 x 2), Fixed Shelf Panel (P5) and Rails (P7 x 2) by tightening all nuts with the Phillips Head Screwdriver.

Step 6

You will need	
	
4 x Plastic Glides (H6)	Hammer




Secure 4 x Plastic Glides (H6) to the bottom of Left & Right Side Panels (P2 & P3) as shown using the Hammer.

Step 7

You will need	
12 x Shelf Supports (H5)	


Insert 12 x Shelf Supports (H5) into the holes of the left & Right Side Panels (P2 & P3) at your preferred shelf height. Insert the Shelf Panels (P4 x 3) into the unit by resting each shelf on the Shelf Supports. Ensure each shelf is positioned securely.







Step 8



You will need	
12 x Wedges (H7)	12 x Wedge Screws (H2)
Phillips Head Screwdriver	

Secure Back Panels (P6 x 2 & P8 x 2) in place with 12 x Wedges (H7) using 12 x Wedge Screws (H2) by tightening with the Phillips Head Screwdriver.



Step 9



You will need	
	
1 x Safety Strap (H8)	1 x Safety Strap Screw (H9)
	
1 x Washer (H10)	Phillips Head Screwdriver



We strongly advise that you use the wall safety strap provided to prevent the unit toppling.



Attach the Safety Strap (H8) to the Top Panel (P1) with 1 x Safety Strap Screw (H9) & 1 x Washer (H10) by tightening with the Phillips Head Screwdriver.

Step 10

You will need	
	
1 x Washer (H10)	Phillips Head Screwdriver
Screw and Wall Plug are not provided. Please use appropriate fixtures for your wall.	

Seek advice from a qualified trades person on how to attach this safety strap to your specific wall.

Move the unit to the final position, and attach the safety strap to the wall securely. Make sure it is firmly attached and snug fit.



Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.