




**Fantastic
Furniture**

Version 1.0



Knox
Bookcase

fantasticfurniture.com.au

Secure it!

Reduce the risk of furniture tip-over accidents



WARNING: ENSURE THE WALL STRAP IS ATTACHED TO AVOID SERIOUS INJURY OR DEATH.

To avoid any serious or fatal injury, a wall strap has been provided with this product to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Fixing devices are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.

Recommended weight capacity: 25kg per Shelf

To reduce the risk of furniture tipover:




- Do not allow children to stand, climb or hang on furniture. It may topple and cause serious injury or death.
- Do not place toys or other child appealing items on top of this furniture, and place heaviest items towards the bottom of the furniture.




- Do not open more than one drawer at the time.
- Anchoring this product to a wall or other suitable surface is recommended. Check anchors regularly.
- Avoid putting a TV on this product.

Wall attachment guide




For plasterboard
(without available wood stud)

Securing method:
Self drilling plasterboard anchor.



For plasterboard
(with available wood stud)

Securing method:
Screw inserted directly into stud.



For masonry wall

Securing method:
Solid wall: Plug with screw
Hollow wall: Spring toggle

Please seek professional advice if you are in doubt of what fixing device to use.

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love!



Fantastic Furniture

Love it? Share it!


Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!

@fantasticfurniture


Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What you need

to assemble the product



DO NOT USE



Other tools you need:

Phillips head screwdriver;

Mallet.


Parts list

Shelf Panel 1 (P1);


Shelf Panel 2 (P2);

4x Shelf Panels 3 (P3);


5x Vertical Panels (P4)



Hardware pack



1 x Glue
(H1)



20 x Wood Dowels
M8 x 25
(H2)




10 x Cam
Bolts
(H3)



10 x Cam
Nuts
(H4)



1 x Allen Key
(H5)



10 x Metal
Tube Poles
(H6)



10 x Long
Screws x 40mm
(H7)



10 x Tube
Screws
(H8)



4 x Plastic
Feets
(H9)



4 x Medium
Screws x 30mm
(H10)



1 x Webbing
(H11)



1 x Pan Head
Short Screw x 16mm
(H12)



1 x Flat
Washer
(H13)







10 x Stickers
(H14)



10 x Long
Screws x 50mm
(H15)



Step 1



You will need	
	
20 x Wood Dowels M8 x 25 (H2)	Mallet



Using a mallet, gently tap 20x Wood Dowels (H2) into pre-drilled holes in 5x Vertical Panels (P4).






Step 2

You will need	
	
2 x Cam Bolts (H3)	Phillips Head Screwdriver




Fix 2x Cam Bolts (H3) to Shelf Panel 1 (P1) as per Detail A.
Tighten with a phillips head screwdriver.





Step 3

You will need				
				
1 x Glue (H1)	2 x Cam Nuts (H4)	2 x Metal Tube Poles (H6)	2 x Tube Screws (H8)	Phillips Head Screwdriver

This is how a cam nut works.....










The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.



Fix 2x Tube Screws (H8) to Shelf Panel 1 (P1) as per Detail C. Fix 2x Metal Tube Poles (H6) to Shelf Panel 1 (P1). Place a small amount of Glue (H1) to dowel holes as per Detail B. Fix Vertical Panel (P4) to Shelf Panel 1 (P1) using 2x Cam Nuts (H4) as per Detail A and tighten using phillips head screwdriver.







Step 4

You will need				
				
1 x Glue (H1)	1 x Allen Key (H5)	2 x Long Screws x40mm (H7)	2 x Long Screws x50mm (H15)	Phillips Head Screwdriver




Place a small amount of Glue (H1) in Wood Dowels as per Detail A. Fix Shelf Panel 3 (P3) to Vertical Panel (P4) and Metal Tube Poles (H6). Tighten with 2x Long Screws x 50mm (H15) using phillips head screwdriver and 2x Long Screws x 40mm (H7) using Allen Key (H5).



Step 5

You will need					
					
1 x Glue (H1)	2 x Cam Bolts (H3)	2 x Cam Nuts (H4)	2 x Metal Tube Poles (H6)	2 x Tube Screws (H8)	Phillips Head Screwdriver

This is how a cam nut works.....










The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.



Fix 2x Tube Screws (H8) to Shelf Panel 3 (P3) as per Detail C. Fix 2x Metal Tube Poles (H6) to Shelf Panel 3 (P3). Fix 2x Cam Bolts (H3) to Shelf Panel 3 (P3) as per Detail B. Place a small amount of Glue (H1) to dowel holes as per Detail D. Fix Vertical Panel (P4) to Shelf Panel 3 (P3) using 2x Cam Nuts (H4) as per Detail A and tighten using phillips head screwdriver.







Step 6

You will need				
				
1 x Glue (H1)	1 x Allen Key (H5)	2 x Long Screws x40mm (H7)	2 x Long Screws x50mm (H15)	Phillips Head Screwdriver




Place a small amount of Glue (H1) in Wood Dowels as per Detail A. Fix Shelf Panel 3 (P3) to Vertical Panel (P4) and Metal Tube Poles (H6). Tighten with 2x Long Screws x 50mm (H15) using phillips head screwdriver and 2x Long Screws x 40mm (H7) using Allen Key (H5).



Step 7

You will need					
					
1 x Glue (H1)	2 x Cam Bolts (H3)	2 x Cam Nuts (H4)	2 x Metal Tube Poles (H6)	2 x Tube Screws (H8)	Phillips Head Screwdriver

This is how a cam nut works.....










The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.



Fix 2x Tube Screws (H8) to Shelf Panel 3 (P3) as per Detail C. Fix 2x Metal Tube Poles (H6) to Shelf Panel 3 (P3). Fix 2x Cam Bolts (H3) to Shelf Panel 3 (P3) as per Detail B. Place a small amount of Glue (H1) to dowel holes as per Detail D. Fix Vertical Panel (P4) to Shelf Panel 3 (P3) using 2x Cam Nuts (H4) as per Detail A and tighten using phillips head screwdriver.







Step 8

You will need				
				
1 x Glue (H1)	1 x Allen Key (H5)	2 x Long Screws x40mm (H7)	2 x Long Screws x50mm (H15)	Phillips Head Screwdriver




Place a small amount of Glue (H1) in Wood Dowels as per Detail A. Fix Shelf Panel 3 (P3) to Vertical Panel (P4) and Metal Tube Poles (H6). Tighten with 2x Long Screws x 50mm (H15) using phillips head screwdriver and 2x Long Screws x 40mm (H7) using Allen Key (H5).



Step 9

You will need					
					
1 x Glue (H1)	2 x Cam Bolts (H3)	2 x Cam Nuts (H4)	2 x Metal Tube Poles (H6)	2 x Tube Screws (H8)	Phillips Head Screwdriver

This is how a cam nut works.....










The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.



Fix 2x Tube Screws (H8) to Shelf Panel 3 (P3) as per Detail C. Fix 2x Metal Tube Poles (H6) to Shelf Panel 3 (P3). Fix 2x Cam Bolts (H3) to Shelf Panel 3 (P3) as per Detail B. Place a small amount of Glue (H1) to dowel holes as per Detail D. Fix Vertical Panel (P4) to Shelf Panel 3 (P3) using 2x Cam Nuts (H4) as per Detail A and tighten using phillips head screwdriver.







Step 10

You will need				
				
1 x Glue (H1)	1 x Allen Key (H5)	2 x Long Screws x40mm (H7)	2 x Long Screws x50mm (H15)	Phillips Head Screwdriver




Place a small amount of Glue (H1) in Wood Dowels as per Detail A. Fix Shelf Panel 3 (P3) to Vertical Panel (P4) and Metal Tube Poles (H6). Tighten with 2x Long Screws x 50mm (H15) using phillips head screwdriver and 2x Long Screws x 40mm (H7) using Allen Key (H5).



Step 11

You will need					
					
1 x Glue (H1)	2 x Cam Bolts (H3)	2 x Cam Nuts (H4)	2 x Metal Tube Poles (H6)	2 x Tube Screws (H8)	Phillips Head Screwdriver


This is how a cam nut works.....




The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.




DETAIL D




DETAIL C



DETAIL B









DETAIL A




Fix 2x Tube Screws (H8) to Shelf Panel 3 (P3) as per Detail C. Fix 2x Metal Tube Poles (H6) to Shelf Panel 3 (P3). Fix 2x Cam Bolts (H3) to Shelf Panel 3 (P3) as per Detail B. Place a small amount of Glue (H1) to dowel holes as per Detail D. Fix Vertical Panel (P4) to Shelf Panel 3 (P3) using 2x Cam Nuts (H4) as per Detail A and tighten using phillips head screwdriver.

Step 12

You will need				
				
1 x Glue (H1)	1 x Allen Key (H5)	2 x Long Screws x40mm (H7)	2 x Long Screws x50mm (H15)	Phillips Head Screwdriver









DETAIL A



Place a small amount of Glue (H1) in Wood Dowels as per Detail A. Fix Shelf Panel 2 (P2) to Vertical Panel (P4) and Metal Tube Poles (H6). Tighten with 2x Long Screws x 50mm (H15) using phillips head screwdriver and 2x Long Screws x 40mm (H7) using Allen Key (H5).





Step 13



You will need			
			
4 x Plastic Feet (H9)	4 x Medium Screws x30mm (H10)	10 x Stickers (H14)	Phillips Head Screwdriver



Fix 4x Plastic Feet (H9) to Shelf Panel 2 (P2) with 4x Medium Screws x 30mm (H10) as per Detail A and tighten using phillips head screwdriver. Place 10x Stickers (H14) to cover screws as per Detail B.



Step 14

You will need			
			
1 x Webbing (H11)	1 x Pan Head Short Screw x 16mm (H12)	1 x Flat Washer (H13)	Phillips Head Screwdriver




Attach the Webbing (H11) to the unit using the Flat Washer (H13) and Pan Head Short Screw (H12) as per Detail A. **We strongly advise that you secure the unit to a wall using the Webbing provided, to prevent the unit from toppling.**

Step 15



Move furniture to its final position, then connect the end of the Webbing (H11) to the wall, ensuring it is firmly attached. Seek advice from a qualified trades person on how to attach this to your specific wall. Screws and wall plugs are not supplied. Please use appropriate fixtures for your wall.

Step 16



Job complete!

In the interest of our environment please dispose of all packaging thoughtfully.