




**Fantastic  
Furniture**

Version 1.0



**Two People**



**Required**

**Havana**  
Bed King MK2 Light Oak

[fantasticfurniture.com.au](http://fantasticfurniture.com.au)

# Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture  
to help create a home you'll love!



## Fantastic Furniture

### Love it? Share it!


Fantastic buy! Share how it looks at home on Instagram for  
your chance to win a \$250 Fantastic Furniture Gift Card!

**@fantasticfurniture**


# Assembly Checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

## Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

# What you need

## to assemble the product



DO NOT USE




### Other tools you need:



















Phillips Head Screwdriver;  
Hammer

### Parts list



Rail (P1);  
Rail (P2);  
Rail (P3);  
Rail (P4);  
2 x Back Panels (P5);  
Rail (P6);  
2 x Side Rails (P7);  
2 x Side Covers (P8);  
Centre Rail (P9);  
3 x Support Legs (P10);  
Rail (P11);  
Rail (P12);  
Rail (P13);  
Rail (P14);  
2 x Back Panels (P15);  
Rail (P16);  
11 x Slats (P17);  
2 x Support Slats (P18)




### Hardware pack

								
40 x Dowels (H1)	30 x Screws (H2)	12 x Cam Bolts (H3)	12 x Cam Nuts (H4)	20 x Half Round Nuts (H5)	16 x Threaded Rods (H6)	4 x Hexagonal Bolts (H7)	20 x Large Hexagonal Nuts (H8)	4 x Plastic Glides (H9)
								
5 x Bolts (H10)	1 x Large Allen Key (H11)	3 x Adjusters (H12)	2 x Hexagonal Nuts (H13)	1 x Allen Key (H14)	12 x Nuts (H15)	9 x Washers (H16)	1 x Spanner (H17)	10 x Large Hole Stickers (H18)
								12 x Small Hole Stickers (H19)





# Step 1


You will need	
	
6 x Threaded Rods (H6)	6 x Nuts (H15)



Insert 6 x nuts (H15) into the holes in rails (P1, P2, P3, P4). Ensure the lines in the nuts (H15) face incoming threaded rods as shown in the image above. Attach 6 x threaded rods (H6) to the 6 x nuts (H15) and hand tighten by turning clockwise.


# Step 2

You will need	
	
3 x Half Round Nuts (H5)	3 x Large Hexagonal Nuts (H8)
	
6 x Dowels (H1)	1 x Spanner (H17)



Insert 6 x dowels (H1) into rail (P2). Attach rails (P3, P4, P6) to rail (P2) and secure using 3 x half round nuts (H5) and 3 x large hexagonal nuts (H8), tightening with spanner (H17).



## Step 3



Slide 2 x back panels (P5) into the grooves of rails (P3, P4, P6).




## Step 4



You will need	
3 x Half Round Nuts (H5)	3 x Large Hexagonal Nuts (H8)
6 x Dowels (H1)	1 x Spanner (H17)



Insert 6 x dowels (H1) into rails (P3, P4, P6). Attach rail (P1) to rails (P3, P4, P6) and secure using 3 x half round nuts (H5) and 3 x large hexagonal nuts (H8), tightening with spanner (H17).





## Step 5


You will need	
	
6 x Threaded Rods (H6)	6 x Nuts (H15)
	
Phillips Head Screwdriver	



Insert 6 x nuts (H15) into holes on rails (P11, P12, P13, P14). Ensure the lines on the nuts (H15) face incoming threaded rods as shown in the image above. Attach 6 x threaded rods (H6) into the 6 x nuts (H15) and hand tighten by turning clockwise.


## Step 6

You will need	
	
3 x Half Round Nuts (H5)	3 x Large Hexagonal Nuts (H8)
	
6 x Dowels (H1)	1 x Spanner (H17)



Insert 6 x dowels (H1) into rail (P12). Attach rails (P13, P14, P16) to rail (P12) and secure using 3 x half round nuts (H5) and 3 x large hexagonal nuts (H8), tightening with spanner (H17).


## Step 7



Slide 2 x back panels (P15) into the grooves of rails (P13, P14, P16).

## Step 8




You will need	
3 x Half Round Nuts (H5)	3 x Large Hexagonal Nuts (H8)
6 x Dowels (H1)	1 x Spanner (H17)




Insert 6 x dowels (H1) into rails (P13, P14, P16). Attach rail (P11) to rails (P13, P14, P16) and secure using 3 x half round nuts (H5) and 3 x large hexagonal nuts (H8), tightening with spanner (H17).





## Step 9


You will need	
	
12 x Cam Bolts (H3)	4 x Dowels (H1)
	
Phillips Head Screwdriver	




Attach 6 x cam bolts (H3) into 1 x side cover (P8), tightening with a phillips head screwdriver. Insert 2 x dowels (H1) into the side cover (P8).

## Step 10

You will need	
	
12 x Cam Nuts (H4)	Phillips Head Screwdriver








This is how a cam nut works.....




The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.

Insert 6 x cam nuts (H4) into the holes on the side rail (P7). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Attach the side rail (P7) to the side cover (P8), then tighten the cam nuts with a phillips head screwdriver. Repeat step 9 and step 10 for the other side cover (P8) and side rail (P7).





## Step 11

You will need	
	
4 x Threaded Rods (H6)	2 x Plastic Glides (H9)
	
6 x Small Hole Stickers (H19)	Phillips Head Screwdriver
	
Hammer	



Attach 4 x threaded rods (H6) into rails (P13, P14). Attach 2 x plastic glides (H9) to the end of rails (P13, P14) by gently tapping with a hammer. Attach 6 x small hole stickers (H19) to the holes of rails (P11, P12, P13, P14).


## Step 12

You will need	
	
6 x Dowels (H1)	4 x Half Round Nuts (H5)
	
4 x Large Hexagonal Nuts (H8)	1 x Spanner (H17)

Two People






Required



Insert 6 x dowels (H1) into 2 x side covers (P8) and 2 x side rails (P7). Attach rails (P13, P14) to 2 x side covers (P8) and 2 x side rails (P7) and secure using 4 x large hexagonal nuts (H8) and 4 x half round nuts (H5), tightening with the spanner (H17).








# Step 13


You will need	
	
2 x Plastic Glides (H9)	Hammer



Attach 2 x plastic glides (H9) to end of rails (P3, P4) by gently tapping with a hammer.





# Step 14


You will need	
	
4 x Half Round Nuts (H5)	4 x Large Hexagonal Nuts (H8)
	
6 x Dowels (H1)	1 x Spanner (H17)
	
4 x Hexagonal Bolts (H7)	1 x Large Allen Key (H11)
	
4 x Washers (H16)	



Insert 6 x dowels (H1) into 2 x side covers (P8) and 2 x side rails (P7). Thread 4 x hexagonal bolts (H7) through the 4 x washers (H16) and push the 4 x hexagonal bolts (H7) through rails (P3, P4). Attach rails (P3, P4) to 2 x side covers (P8) and 2 x side rails (P7), secure using 4 x large hexagonal nuts (H8) and 4 x half round nuts (H5) with spanner (H17). Tighten 4 x hexagonal bolts (H7) with large allen key (H11).



## Step 15


You will need	
	
3 x Bolts (H10)	3 x Adjusters (H12)
	
3 x Washers (H16)	1 x Allen Key (H14)



Attach the 3 x support legs (P10) to the centre rail (P9) using 3 x washers (H16) and 3 x bolts (H10), tightening with the allen key (H14). Insert the 3 x adjusters (H12) into the 3 x support legs (P10) and hand tighten by turning clockwise.







## Step 16


You will need	
	
4 x Screws (H2)	Phillips Head Screwdriver



Attach the centre rail (P9) to the rails (P2, P16) using 4 x screws (H2). Tighten with a phillips head screwdriver.



# Step 17


You will need	
	
4 x Screws (H2)	2 x Bolts (H10)
	
2 x Hexagonal Nuts (H13)	2 x Washers (H16)
	
1 x Allen Key (H14)	Phillips Head Screwdriver



Attach the 2 x support slats (P18) to the centre rail (P9) using 2 x bolts (H10), 2 x washers (H16) and 2 x hexagonal nuts (H13), tightening with the allen key (H14). Attach the 2 x support slats (P18) to the 2 x side rails (P7) using 4 x screws (H2), tightening with a phillips head screwdriver. Ensure the adjusters (H12) on the support legs (P10) are retracted so they are not touching the floor. With assistance, move the bed into its final position. Once the bed is in it's final position extend the 3 x adjusters (H12) on the 3 x support legs (P10) so they are level with the floor.



# Step 18


You will need	
	
22 x Screws (H2)	Phillips Head Screwdriver




Attach the 11 x slats (P17) to the 2 x side rails (P7) using 22 x screws (H2), tightening with a phillips head screwdriver.

## Step 19

You will need	
	
10 x Large Hole Stickers (H18)	6 x Small Hole Stickers (H19)



Cover the holes on rails (P2, P3, P4, P6, P11, P12) using 10 x large hole stickers (H18).  
Cover the holes on rails (P1, P2, P3, P4) using 6 x small hole stickers (H19).



## Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.