



# Assembly Instructions

## COMO

### Double Bed




VER 1.2



# WARNING


FAILURE TO FOLLOW THESE BASIC STEPS CAN LEAD TO DAMAGE THAT IS NOT COVERED BY YOUR WARRANTY

1




Read Instructions carefully. Check no parts are missing.

2




Lay out all of the components on a soft surface as if you were preparing to do a jigsaw puzzle.

3




Carefully identify each component, especially those that are similar. The most common mistake is getting things back to front.

4




Separate and identify each component from the hardware pack and rest each one in its proper location before fastening.

5



**DO NOT** fully tighten screws (leave slightly loose). When the item is fully assembled tighten the screws - but do not over tighten.


6



If glue is required **DO NOT** set until you are certain that the parts belong together.

# What You Need



## To Assemble The Body



(Tools not provided)  
 Flat Blade Screwdriver  
 Phillips Head Screwdriver  
 Mallet




**DO NOT USE**




26 x End Connectors



13 x Centre Connectors



26 x Fantastic Furniture  
 ComfortSlats™ Double




4 x Inside Hexagonal Screws (H1)	46 x Small Dowels (H2)	2 x Cam Bolts (H3)	2 x Cam Nuts (H4)	24 x Screws (Ø4 x 25) (H5)	40 x Screws (Ø4 x 30) (H6)	7 x Long Screws (Ø4 x 35) (H7)	20 x Small Cam Bolts (H8)	20 x Small Cam Nuts (H9)
12 x Bolts (H10)	4 x Elbow Connectors (H11)	4 x Flat Connectors (H12)	11 x Plastic Glides (H13)	32 x Small Screws (Ø3.5 x 12) (H14)	16 x Wheels (H15)	2 x Stickers (H16)	1 x Allen Key (Large) (H17)	1 x Allen Key (Medium) (H18)

Please make sure you have all these parts before you start.

# Step 1


You will need:	
2 x Cam Bolts (H3)	
16 x Screws (H5)	
4 x Elbow Connectors (H11)	



Attach 1 x Cam Bolt (H3) to Side Rail (P3).  
 Attach 2 x Elbow Connectors (H11) to Side Rail (P3) with 8 x Screws (H5).  
 Repeat Step 1 again with the other Side Rail (P3).

# Step 2

You will need:	
8 x Screws (H6)	
2 x Long Screws (H7)	
2 x Flat Connectors (H12)	
3 x Plastic Glides (H13)	




Make sure the bottom of the "U" shape is facing to the bottom rough side of Bedhead (P1).

Attach 2 x Flat Connectors (H12) to Bedhead (P1) with 8 x Screws (H6).  
 Attach Supporter (P15) to Bedhead (P1) with 2 x Long Screws (H7).  
 Then hammer 3 x Plastic Glides (H13) on the bottom of Bedhead (P1).

# Step 3




You will need:	
8 x Screws (H6)	
2 x Long Screws (H7)	
2 x Flat Connectors (H12)	
3 x Plastic Glides (H13)	



Attach 2 x Flat Connectors (H12) to Bedfoot (P2) with 8 x Screws (H6).  
 Attach Supporter (P15) to Bedfoot (P2) with 2 x Long Screws (H7).  
 Then hammer 3 x Plastic Glides (H13) on the bottom of Bedfoot (P2).

# Step 4




You will need:	
2 x Small Dowels (H2)	
2 x Cam Nuts (H4)	



Insert 2 x Small Dowels (H2) into Side Rails (P3).  
 Insert 2 x Cam Nuts (H4) into the holes of Clapboard (P7).  
 Rotate the cam nuts so the arrow points towards the incoming cam bolts.  
 Push Side Rails (P3) into place and tighten the cam nuts.

# Step 5



You will need:	
2 x Long Screws (H7)	
3 x Plastic Glides (H13)	



Attach Rails (P4) to Clapboard (P7) with 2 x Long Screws (H7). Then hammer 3 x Plastic Glides (H13) on the bottom of Clapboard (P7).

# Step 6

You will need:	
4 x Small Dowels (H2)	
6 x Bolts (H10)	
1 x Allen Key (Large) (H17)	




Insert 4 x Small Dowels (H2) into the holes of Bedfoot (P2). Attach Side Rails (P3) to Bedfoot (P2) with 6 x Bolts (H10) using Allen Key (H17). Do not fully tighten bolts, leave a little loose at this stage.



# Step 7

You will need:

4 x Small Dowels (H2)	
6 x Bolts (H10)	
1 x Allen Key (Large) (H17)	



2 PEOPLE CAREFULLY TURN OVER THE BED FRAME




Insert 4 x Small Dowels (H2) into the holes of Bedhead (P1). Attach Side Rails (P3) to Bedhead (P1) with 6 x Bolts (H10) using Allen Key (H17). Tighten firmly. Move the bed to final position then check and tighten all bolts attaching the Side Rails to the Bedhead and Bedfoot.


# Step 8

You will need:

8 x Screws (H5)	
-----------------	--




SECTION A-A



Attach 4 x Blocks (P16) to Rails (P4) with 8 x Screws (H5).

# Step 9


You will need:	
2 x Plastic Glides (H13)	



Attach 2 x Support Legs (P6) to Central Rail (P5), until it is firmly attached. Then hammer 2 x Plastic Glides (H13) on Support Legs (P6).

# Step 10


You will need:	
1 x Long Screws (H7)	
2 x Stickers (H16)	
4 x Inside Hexagonal Screws (H1)	
1 x Allen Key (Medium) (H18)	



Put Central Rail (P5) into the right place as shown. Attach Central Rail to Bedhead (P1) and Bedfoot (P2) with 4 x Inside Hexagonal Screws (H1) using Allen Key (H18) and Clapboard (P7) with 1 x Long Screw (H7). Attach 2 x Stickers (H16) to the holes of Rails (P4).

# Step 11


You will need:	
5 x Small Dowels (H2)	
5 x Small Cam Bolts (H8)	



Insert 5 x Small Dowels (H2) into Drawer Front (P8), and attach 5 x Small Cam Bolts (H8) to it.

# Step 12


You will need:	
8 x Small Screws (H14)	
4 x Wheels (H15)	



Attach 2 x Wheels (H15) to Drawer Support (P14) with 4 x Small Screws (H14). Repeat Step 12 again with the other Drawer Support (P14).


# Step 13

You will need:	
5 x Small Cam Nuts (H9)	



Grooves should face inside.

This is how a cam nut works.....




The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.

Insert 5 x Small Cam Nuts (H9) into the holes of Drawer Sides (P9,P10) and Central Drawer Support (P13). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Push Drawer Sides (P9,P10) and Drawer Supports (P13, P14) into place and tighten the cam nuts.

# Step 14


You will need:	
4 x Small Dowels (H2)	



Slide Drawer Base (P11) into the groove in the middle of Drawer Sides (P9,P10).  
Insert 4 x Small Dowels (H2) into 2 x Drawer Supports (P14).


# Step 15

You will need:	
6 x Screws (H6)	



Attach Drawer Sides (P9,P10) to Drawer Back (P12) with 4 x Screws (H6),  
then attach Drawer Back (P12) to Central Drawer Support (P13) with 2 x Screws (H6).  
Make sure that the groove lines up the whole way around the drawer.

# Step 16




Repeat step 11 to step 15 to assemble other 3 drawers.


# Step 17

You will need:	
26 x End Connectors	
26 x Fantastic Furniture ComfortSlats™ Double	
13 x Centre Connectors	


## HOW TO FIT YOUR COMFORT SLATS




Push 2 End Connectors, 2 Fantastic Furniture ComfortSlats™ Double and a Centre Connector together.



Insert the full slat into the side rail and centre rail one by one.




Sometimes it makes it easier to line up the hole if you press down in the middle of the slat to flatten it out.




Repeat for every bed slat until finished.

## Step 18



Put the drawers into the bed.



## The job is now complete!

In the interest of our environment  
Please dispose of all packaging thoughtfully.