


# Assembly Instructions

## COMO

### Single Bed




VER 1.2



# WARNING


FAILURE TO FOLLOW THESE BASIC STEPS CAN LEAD TO DAMAGE THAT IS NOT COVERED BY YOUR WARRANTY

1




Read Instructions carefully. Check no parts are missing.

2




Lay out all of the components on a soft surface as if you were preparing to do a jigsaw puzzle.

3




Carefully identify each component, especially those that are similar. The most common mistake is getting things back to front.

4




Separate and identify each component from the hardware pack and rest each one in its proper location before fastening.

5




**DO NOT** fully tighten screws (leave slightly loose). When the item is fully assembled tighten the screws - but do not over tighten.

6



If glue is required **DO NOT** set until you are certain that the parts belong together.

# What You Need





## To Assemble The Body

(Tools not provided)  
 Flat Blade Screwdriver  
 Phillips Head Screwdriver  
 Mallet



**DO NOT USE**




x 2

26 x Plastic Connectors



13 x Fantastic Furniture ComfortSlats™ Single




4 x Elbow Brackets (H1)	28 x Small Dowels (H2)	2 x Cam Bolts (H3)	2 x Cam Nuts (H4)	26 x Screws (Ø4 x 25) (H5)	30 x Screws (Ø4 x 30) (H6)	3 x Stickers (H7)	10 x Small Cam Bolts (H8)
10 x Small Cam Nuts (H9)	12 x Bolts (H10)	4 x Elbow Connectors (H11)	4 x Flat Connectors (H12)	11 x Plastic Glides (H13)	32 x Small Screws (Ø3.5 x 12) (H14)	8 x Wheels (H15)	1 x Allen Key (H16)

Please make sure you have all these parts before you start.

# Step 1


You will need:	
5 x Small Dowels (H2)	
5 x Small Cam Bolts (H8)	



Insert 5 x Small Dowels (H2) into Drawer Front (P7), and attach 5 x Small Cam Bolts (H8) to it.

# Step 2


You will need:	
8 x Small Screws (H14)	
4 x Wheels (H15)	



Attach 2 x Wheels (H15) to Drawer Support (P13) with 4 x Small Screws (H14). Repeat Step 2 again with the other Drawer Support (P13).

# Step 3

You will need:	
5 x Small Cam Nuts (H9)	




This is how a cam nut works.....

The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.

Insert 5 x Small Cam Nuts (H9) into the holes of Drawer Sides (P8,P9) and Central Drawer Support (P12). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Push Drawer Sides (P8,P9) and Central Drawer Support (P12) into place and tighten the cam nuts. Attach 2 x Drawer Supports (P13) to Drawer Front (P7).

# Step 4


You will need:	
4 x Small Dowels (H2)	



Slide Drawer Base (P11) into the groove in the Drawer Sides (P8,P9).  
Insert 4 x Small Dowels (H2) into Drawer Support (P13).


# Step 5

You will need:	
6 x Screws (H6)	



Attach Drawer Back (P10) to Drawer Sides (P8,P9) with 4 x Screws (H6),  
and Central Drawer Support (P12) with 2 x Screws (H6).  
Make sure that the groove lines up the whole way around the drawer.


# Step 6



Repeat step 1 to step 5 to assemble the other drawer.

# Step 7

You will need:	
2 x Cam Bolts (H3)	
16 x Screws (H5)	
4 x Elbow Connectors (H11)	




Attach 1 x Cam Bolt (H3) to Side Rail (P3).

Attach 2 x Elbow Connectors (H11) to Side Rail (P3) with 8 x Screws (H5).

Repeat Step 7 again with the other Side Rail (P3).

# Step 8

You will need:	
4 x Elbow Brackets (H1)	
8 x Small Screws (H14)	
3 x Plastic Glides (H13)	





Attach 4 x Elbow Brackets (H1) to Base Panel (P5) with 8 x Small Screws (H14).

Then hammer 3 x Plastic Glides (H13) on the bottom of Base Panel (P5).

# Step 9



You will need:	
8 x Screws (H6)	
2 x Flat Connectors (H12)	
3 x Plastic Glides (H13)	



Attach 2 x Flat Connectors (H12) to Bedhead (P1) with 8 x Screws (H6).  
Then hammer 3 x Plastic Glides (H13) on the bottom of Bedhead (P1).

# Step 10


You will need:	
8 x Screws (H6)	
2 x Flat Connectors (H12)	
3 x Plastic Glides (H13)	



Attach 2 x Flat Connectors (H12) to Bedfoot (P2) with 8 x Screws (H6).  
Then hammer 3 x Plastic Glides (H13) on the bottom of Bedfoot (P2).

# Step 11

You will need:	
2 x Small Dowels (H2)	
2 x Cam Nuts (H4)	




**This is how a cam nut works.....**

The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so the arrow points towards the incoming cam bolts.


Insert 2 x Small Dowels (H2) into Side Rails (P3).  
 Insert 2 x Cam Nuts (H4) into the holes of Clapboard (P6).  
 Rotate the cam nuts so the arrow points towards the incoming cam bolts.  
 Push Side Rails (P3) into place and tighten the cam nuts.

# Step 12

You will need:	
2 x Screws (H6)	
2 x Plastic Glides (H13)	



**P4 MUST GO IN CORRECT WAY WITH HOLE CLOSE TO TOP**




Attach Rails (P4) to Clapboard (P6) with 2 x Screws (H6).  
 Then hammer 2 x Plastic Glides (H13) on the bottom of Clapboard (P6).

# Step 13

You will need:

4 x Small Dowels (H2)	
6 x Bolts (H10)	
1 x Allen Key (H16)	




Insert 4 x Small Dowels (H2) into the holes of Bedfoot (P2).  
Attach Side Rails (P3) to Bedfoot (P2) with 6 x Bolts (H10) using Allen Key (H16).


# Step 14

You will need:

4 x Small Dowels (H2)	
6 x Bolts (H10)	
1 x Allen Key (H16)	



2 PEOPLE CAREFULLY  
TURN OVER THE BED FRAME





Insert 4 x Small Dowels (H2) into the holes of Bedhead (P1).  
Attach Side Rails (P3) to Bedhead (P1) with 6 x Bolts (H10) using Allen Key (H16).

# Step 15

You will need:

4 x Screws  
(H5)





Attach 2 x Blocks (P14) to Rail (P4) with 4 x Screws (H5).



# Step 16

You will need:

4 x Screws  
(H5)







Attach 2 x Blocks (P14) to Rail (P4) with 4 x Screws (H5).



## Step 17

You will need:	
8 x Small Screws (H14)	
2 x Screws (H5)	
3 x Stickers (H7)	




Whether you would like to choose Option 1 or Option 2, please attach Base Panel (P5) to Bedboard (P1,P2) with 8 x Small Screws (H14). Attach Base Panel (P5) to Rails (P4) with 2 x Screws (H5). Attach 3 x Stickers (H7) to the holes of Rail (P4). And then follow the rest steps to assemble.

# Step 18


You will need:

26 x Plastic Connectors	
13 x Fantastic Furniture ComfortSlats™ Single	


## HOW TO FIT YOUR COMFORT SLATS




Push plastic connectors firmly onto each Fantastic Furniture ComfortSlats™ Single.



Place the slat in position then push down in the centre to flatten. Make sure the plastic prong lines up with the hole, then push in firmly.




Repeat the same process for the other end of the slat.




Repeat for every bed slat until finished.

## Step 19



Put the drawers into the bed.



## The job is now complete!

In the interest of our environment  
Please dispose of all packaging thoughtfully.