




**Fantastic
Furniture**

Version 1.0



Hamilton

Buffet

fantasticfurniture.com.au

Recommended weight capacity : 80kgs on top.



**WARNING: ENSURE THE WALL STRAP IS ATTACHED TO
AVOID SERIOUS INJURY.**

To avoid any serious or fatal injury, this product has been supplied with a wall strap to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Connecting attachments for your wall are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what wall connections to use.

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love!



Fantastic Furniture

Love it? Share it!


Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!

@fantasticfurniture


Assembly Checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What you need

to assemble the product




DO NOT USE




Other tools you need:
Phillips head screwdriver;

Parts list


Top Panel (P1);
Bottom Panel (P2);
Left Side Panel (P3);
Right Side Panel (P4);
3 x Shelf Panels (P5);
3 x Back Panels (P6);
Divider (P7);
Divider (P8);
3 x Rail (P9);
2 x Door (P10);
Rail (P11);
2 x Support Legs (P12);
Left Drawer Front (P13);
Middle Drawer Front (P14);
Right Drawer Front (P15);
3 x Left Drawer Side (P16);
3 x Right Drawer Side (P17);
3 x Drawer Back (P18);
3 x Drawer Base (P19);
Door (P20)








Support
Legs
(P12) x2




Hardware pack








Step 1


You will need	
	
8 x Cam Bolts (H3)	6 x Small Screws (H5)
	
1 x CL Runner Track (H6)	1 x CR Runner Track (H7)
	
Phillips Head Screwdriver	



Attach 8 x Cam Bolts (H3) to Left&Right Side Panels (P3&P4) as shown by tightening with the Phillips Head Screwdriver. Attach 1x CL Runner (H6) to Left Side Panel (P3) and 1x CR Runner (H7) to Right Side Panel (P4) with 6 x Small Screws (H5) by tightening with the Phillips Head Screwdriver.






Step 2


You will need	
	
2 x Cam Bolts (H3)	6 x Small Screws (H5)
	
1 x CL Runner Track (H6)	1 x CR Runner Track (H7)
	
Phillips Head Screwdriver	



Attach 2 x Cam Bolts (H3) , 1 x CL Runner Track (H6) and 1 x CR Runner Track (H7) to each side of Divider (P7) with 6 x Small Screws (H5) by tightening with the Phillips Head Screwdriver.




Step 3


You will need	
	
2 x Cam Bolts (H3)	6 x Small Screws (H5)
	
1 x CL Runner Track (H6)	1 x CR Runner Track (H7)
	
Phillips Head Screwdriver	




Attach 2 x Cam Bolts (H3) , 1 x CL Runner Track (H6) and 1 x CR Runner Track (H7) to each side of Divider (P8) with 6 x Small Screws (H5) by tightening with the Phillips Head Screwdriver.

Step 4

You will need	
	
2 x Long Dowels (H18)	2 x Cam Nuts (H4)
	
Phillips Head Screwdriver	





This is how a cam nut works.....




The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.

Insert 2 x Long Dowels (H18) into Dividers (P7&P8). Insert 2 x Cam Nuts (H4) into Rail (P9). Rotate the nuts so the arrows point towards the incoming bolts. Attach Dividers (P7&P8) to Rail (P9) by tightening all nuts with the Phillips Head Screwdriver.



Step 5


You will need	
	
3 x Cam Bolts (H3)	Phillips Head Screwdriver



Attach 3 x Cam Bolts (H3) to Rail (P11) by tightening with the Phillips Head Screwdriver.




Step 6


You will need	
	
3 x Cam Nuts (H4)	Phillips Head Screwdriver



Insert 3 x Cam Nuts (H4) into Bottom Panel (P2). Rotate the nuts so the arrows point towards the incoming bolts. Attach Rail (P11) to Bottom Panel (P2) by tightening all nuts with the Phillips Head Screwdriver.



Step 7


You will need	
	
4 x Dowels (H1)	4 x Long Screws (H2)
	
Phillips Head Screwdriver	



Attach Bottom Panel (P2) to Dividers (P7&P8) with 4 x Long Screws (H2) and 4 x Dowels (H1) by tightening with the Phillips Head Screwdriver.




Step 8


You will need	
	
2 x Cam Nuts (H4)	Phillips Head Screwdriver



Insert 2 x Cam Nuts (H4) into Rails (P9x2). Rotate the nuts so the arrows point towards the incoming bolts. Attach Rails (P9x2) to Divider (P7&P8) by tightening all nuts with the Phillips Head Screwdriver.

Step 9




You will need	
	
4 x Dowels (H1)	4 x Cam Nuts (H4)
	
Phillips Head Screwdriver	




Insert 4 x Dowels (H1) and 4 x Cam Nuts (H4) into Rails (P9&P11) and Bottom Panel (P2).

Rotate the nuts so the arrows point towards the incoming bolts. Attach Left Side Panel (P3) to Rails (P9&P11) and Bottom Panel (P2) by tightening all nuts with the Phillips Head Screwdriver.

Step 10


You will need	
	
4 x Dowels (H1)	4 x Cam Nuts (H4)
	
Phillips Head Screwdriver	




Insert 4 x Dowels (H1) and 4 x Cam Nuts (H4) into Rails (P9&P11) and Bottom Panel (P2).

Rotate the nuts so the arrows point towards the incoming bolts. Attach Right Side Panel (P4) to Rails (P9&P11) and Bottom Panel (P2) by tightening all nuts with the Phillips Head Screwdriver.


Step 11

You will need	
	
2 x Adjusters (H17)	





Attach 2 x Support Legs (P12) to Bottom Panel (P2). Insert the 2 x Adjusters (H17) into the 2 x Support Legs (P12).


Step 12



Gently stand the unit upright. Slide Back Panels (P6x3) into the grooves of Left & Right Side Panel (P3&P4) and Dividers (P7&P8).




Step 13


You will need	
	
8 x Cam Bolts (H3)	Phillips Head Screwdriver



Attach 8 x Cam Bolts (H3) to Top Panel (P1) by tightening with the Phillips Head Screwdriver.


Step 14


You will need	
	
8 x Dowels (H1)	8 x Cam Nuts (H4)
	
Phillips Head Screwdriver	



Insert 8 x Dowels (H1) into Dividers (P7&P8) and Left&Right Side Panel (P3&P4). Insert 8 x Cam Nuts (H4) into Dividers (P7&P8) and Left&Right Side Panel (P3&P4). Rotate the nuts so the arrows point towards the incoming bolts. Attach Top Panel (P1) to Dividers (P7&P8) and Left&Right Side Panel (P3&P4) by tightening all nuts with the Phillips Head Screwdriver.





Step 15


You will need	
	
12 x Shelf Plugs (H16)	



Insert 12 x Shelf Plugs (H16) into the end cavities of the cabinet as shown. Insert the 3 x Shelf Panels (P5) and balance on top of the plugs.



Step 16


You will need	
	
4 x Hinges (H14)	12 x Hinge Screws (H15)
	
2 x Hinges (H19)	Phillips Head Screwdriver



Attach 4 x Hinges (H14) to Doors (P10x2), attach 2 x Hinges (H19) to Door (P20), securing with 12 x Small Screws (H15). Tighten with a Phillips Head Screwdriver. Make sure the 4 x Hinges (H14) are assembled on Door (P10), the 2 x Hinges (H19) are assembled on door (P20).




Step 17


You will need	
	
24 x Hinge Screws (H15)	Phillips Head Screwdriver



Secure Doors (P10x2&P20) to the main unit by attaching the other end of the 6 x Hinges (H14,H19) with 24 x Hinge Screws (H15) as shown. Tighten with a Phillips Head Screwdriver.



Step 18


You will need	
	
3 x Handles (H10)	3 x Handle Bolts (H11)
	
Phillips Head Screwdriver	



Attach 3 x Handles (H10) to Doors (P10x2&P20) with 3 x Handle Bolts (H11) by tightening with the Phillips Head Screwdriver.

Step 19


You will need	
	
4 x Cam Bolts (H3)	Phillips Head Screwdriver



Attach 4 x Cam Bolts (H3) to Left Drawer Front (P13) by tightening with the Phillips Head Screwdriver.


Step 20

You will need	
	
4 x Cam Nuts (H4)	Phillips Head Screwdriver





Insert 4 x Cam Nuts (H4) into the holes of Drawer Sides (P16, P17). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Push Drawer Sides (P16, P17) into place and tighten the cam nuts.


Step 21



Slide Drawer Base (P19) into the groove in Drawer Sides (P16, P17).





Step 22


You will need	
	
4 x Long Screws (H2)	Phillips Head Screwdriver



Attach Drawer Back (P18) to Drawer Sides (P16,P17) with 4 x Long Screws (H2). Make sure that the groove lines up the whole way around the drawer.




Step 23


You will need	
	
1 x DL Runner (H8)	1 x DR Runner (H9)
	
4 x Small Screws (H5)	Phillips Head Screwdriver



Attach 1 x DL Runner (H8) to Left Drawer Side (P16) and 1 x DR Runner (H9) to Right Drawer Side (P17) with 4 x Small Screws (H5) by tightening with the Phillips Head Screwdriver.



Step 24


You will need	
	
1 x Handle (H10)	1 x Handle Bolt (H11)
	
Phillips head screwdriver	



Attach 1 x Handle (H10) to Left Drawer Front (P13) with 1 x Handle Bolt (H11) by tightening with the Phillips Head Screwdriver.

Step 25


You will need	
	
4 x Cam Bolts (H3)	Phillips Head Screwdriver



Attach 4 x Cam Bolts (H3) to Middle Drawer Front (P14) by tightening with the Phillips Head Screwdriver.


Step 26

You will need	
	
4 x Cam Nuts (H4)	Phillips Head Screwdriver




Insert 4 x Cam Nuts (H4) into the holes of Drawer Sides (P16, P17). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Push Drawer Sides (P16, P17) into place and tighten the cam nuts.


Step 27



Slide Drawer Base (P19) into the groove in Drawer Sides (P16, P17).





Step 28


You will need	
	
4 x Long Screws (H2)	Phillips Head Screwdriver



Attach Drawer Back (P18) to Drawer Side (P16,P17) with 4 x Long Screws (H2). Make sure that the groove lines up the whole way around the drawer.




Step 29


You will need	
	
1 x DL Runner (H8)	1 x DR Runner (H9)
	
4 x Small Screws (H5)	Phillips Head Screwdriver



Attach 1 x DL Runner (H8) to Left Drawer Side (P16) and 1 x DR Runner (H9) to Right Drawer Side (P17) with 4 x Small Screws (H5) by tightening with the Phillips Head Screwdriver.



Step 30


You will need	
	
1 x Handle (H10)	1 x Handle Bolt (H11)
	
Phillips head screwdriver	



Attach 1 x Handle (H10) to Middle Drawer Front (P14) with 1 x Handle Bolt (H11) by tightening with the Phillips Head Screwdriver.

Step 31


You will need	
	
4 x Cam Bolts (H3)	Phillips Head Screwdriver



Attach 4 x Cam Bolts (H3) to Right Drawer Front (P15) by tightening with the Phillips Head Screwdriver.


Step 32

You will need	
	
4 x Cam Nuts (H4)	Phillips Head Screwdriver




Insert 4 x Cam Nuts (H4) into the holes of Drawer Sides (P16, P17). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Push Drawer Sides (P16, P17) into place and tighten the cam nuts.


Step 33



Slide Drawer Base (P19) into the groove in Drawer Sides (P16, P17).





Step 34


You will need	
	
4 x Long Screws (H2)	Phillips Head Screwdriver



Attach Drawer Back (P18) to Drawer Sides (P16,P17) with 4 x Long Screws (H2). Make sure that the groove lines up the whole way around the drawer.




Step 35


You will need	
	
1 x DL Runner (H8)	1 x DR Runner (H9)
	
4 x Small Screws (H5)	Phillips Head Screwdriver



Attach 1 x DL Runner (H8) to Left Drawer Side (P16) and 1 x DR Runner (H9) to Right Drawer Side (P17) with 4 x Small Screws (H5) by tightening with the Phillips Head Screwdriver.


Step 36

You will need	
	
1 x Handle (H10)	1 x Handle Bolt (H11)
	
Phillips head screwdriver	



Attach 1 x Handle (H10) to Right Drawer Front (P15) with 1 x Handle Bolt (H11) by tightening with the Phillips Head Screwdriver.


Step 37



Insert the assembled drawers into the corresponding compartments as shown. Ensure the drawers slide easily along the rails.



Step 38


You will need	
8 x Wedges (H12)	8 x Wedge Screws (H13)
2 x Safety Straps (H20)	2 x Safety Strap Screws (H21)
2 x Washers (H22)	Phillips head screwdriver




Secure Back Panels (P6 x 2) in place with 8 x Wedges (H12) using 8 x Wedge Screws (H13) by tightening with the Phillips Head Screwdriver. Use 2 x Safety Strap Screws (H21) and 2 x Washers (H22) to connect 2 x Safety Straps (H20) on Top Panel (P1).

Step 39

You will need	
	
2 x Washers (H22)	Phillips Head Screwdriver
Screw and Wall Plug are not provided. Please use appropriate fixtures for your wall.	



Move the buffet to the final position, and attach the safety strap to the wall securely. Make sure it is firmly attached and snug fit.




Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.

TO ADJUST YOUR DOORS TO MAKE THE GAPS MORE EVEN


STEP 1

Open the door.




STEP 2


Adjust the door panels upward or downward



1.




2.



MOVE DOOR UPWARD OR DOWNWARD

3.




Unscrew 2 screws in round holes loosen 2 screws in oval holes a bit.


Tighten 2 screws in oval holes. Screw in 2 screws in round holes

STEP 3


Adjust the flush between door panel and side panel



1.




2.



KEEP DOOR IN RIGHT POSITION

3.




MOVE DOOR OUTWARD by turning this screw counter-clockwise


MOVE DOOR OUTWARD by turning this screw clockwise

STEP 4


Adjust the Gap between door panel and side panel



1.




2.



MOVE DOOR BACK OR FORTH

3.



Loosen this screw a bit.

Re-tighten this screw.