


Version 1.0





# Secure it!

Reduce the risk of furniture tip-over accidents



#### WARNING: ENSURE THE WALL STRAP IS ATTACHED TO AVOID SERIOUS INJURY OR DEATH.

To avoid any serious or fatal injury, a wall strap has been provided with this product to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Fixing devices are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.

#### Recommended Weight Capacity :15kg/hanging rail or drawer

To reduce the risk of furniture tipover:



- Do not allow children to stand, climb or hang on furniture. It may topple and cause serious injury or death.
- Do not place toys or other child appealing items on top of this furniture, and place heaviest items towards the bottom of the furniture.
- Do not open more than one drawer at the time.
- Anchoring this product to a wall or other suitable surface is recommended. Check anchors regularly.
- Avoid putting a TV on this product.

#### Wall attachment guide




For plasterboard (without available wood stud)

**Securing method:** Self drilling plasterboard anchor.



For plasterboard (with available wood stud)

Securing method: Screw inserted directly into stud.



For masonry wall

Solid wall: Plug with screw Hollow wall: Spring toggle

Please seek professional advice if you are in doubt of what fixing device to use.

# Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture to help create a home you'll love!



### Love it? Share it!


Fantastic buy! Share how it looks at home on Instagram for your chance to win a \$250 Fantastic Furniture Gift Card! @fantasticfurniture



## **Assembly Checklist**



Read through the instructions carefully before you begin.




Identify and lay out all of the components before you begin assembly.

# **Useful Information**


- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.




Make sure you have all the required tools. Never use power tools unless instructed.




Unless instructed, do not fully tighten screws until the item is fully assembled.




Fantastic Furniture Page 5




Attach 8 x Cam Bolts (H3) to Left Side Panel (P2) as shown by tightening with the Phillips Head Screwdriver. Attach 4 x CL Runner Tracks (H6) to Left Side Panel (P2) with 12 x Small Screws (H5) by tightening with the Phillips Head Screwdriver.




Attach 8 x Cam Bolts (H3) to Right Side Panel (P3) as shown by tightening with the Phillips Head Screwdriver. Attach 4 x CR Runner Tracks (H7) to Right Side Panel (P3) with 12 x Small Screws (H5) by tightening with the Phillips Head Screwdriver.






into Top Panel (P1), Shelf Panel (P4), Rails (P6 x 2) and Bottom Panel (P14). Rotate the nuts so the arrows point towards the incoming bolts. Attach Top Panel (P1), Shelf Panel (P4), Rails (P6 x 2) and Bottom Panel (P14) to Left Side Panel (P2) by tightening all nuts with the Phillips Head Screwdriver.


Page 7




Top Panel (P1), Shelf Panel (P4) and Bottom Panel (P14).




Page 8






Secure 4  $\times$  Plastic Glides (H11) to the bottom of Left & Right Side Panels (P2 & P3) as shown using the Hammer.




Attach  $5 \times$  Small Cam Bolts (H14) to Drawer Front (P7) as shown by tightening with the Phillips Head Screwdriver.







Insert 1 x Dowel (H1) into Drawer Front (P7). Insert 5 x Small Cam Nuts (H15) into Left & Right Drawer Sides (P8 & P9) and Support Rail (P12). Rotate the nuts so the arrows point towards the incoming bolts. Attach the Left & Right Drawer Sides (P8 & P9) and Support Rail (P12) to Drawer Front (P7) by tightening all nuts with the Phillips Head Screwdriver.



Slide Drawer Base (P10) into the grooves of Left & Right Drawer Sides (P8 & P9) and Drawer Front (P7).



Attach Drawer Back (P11) to Left & Right Drawer Sides (P8 & P9) and Support Rail (P12) with 6 x Long Screws (H2) by tightening with the Phillips Head Screwdriver. Ensure the drawer base lines up with the grooves all the way around the drawer before securing.




Attach 1 x DL Runner (H8) to the bottom of Left Drawer Side (P8) and 1 x DR Runner (H9) to the bottom of Right Drawer Side (P9) with  $4 \times \text{Small Screws}$  (H5) by tightening with the Phillips Head Screwdriver.


Repeat Step 8 - 12 for the remaining 3 x Drawers.








Attach Rail (P15) to Left & Right Side Panels (P2 & P3) with  $4 \times$  Screws (H2O) by tightening with the Phillips Head Screwdriver.







You will need	
P	
2 x Hanging Rail Supports (H16)	1 x Hanging Rail (H10)
A CONTRACT	
4 x Small Screws (H5)	Phillips Head Screwdriver



Secure 2 x Hanging Rail Supports (H16) to Left & Right Side Panels (P2 & P3) with 4 x Small Screws (H5) as shown by tightening with the Phillips Head Screwdriver. Place the Hanging Rail (H10) in the unit by resting it on the Hanging Rail Supports (H16 x 2).

#### Step 16







Secure Back Panels (P5 x 2 & P13 x 2) in place with 12 x Wedges (H12) and 12 x Wedge Screws (H13) by tightening with the Phillips Head Screwdriver.










We strongly advise that you use the wall safety strap provided to prevent the unit toppling.

Attach the Safety Strap (H17) to the Top Panel (P1) with  $1 \times Safety Strap Screw (H18) \& 1 \times Washer (H19) by tightening with the Phillips Head Screwdriver.$ 



# Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.

