




































PARTS LIST

A HEADBOARD (1 PC) 	B FOOTBOARD (1 PC) 	C SIDE RAIL (2 PCS) 	D CENTRAL RAIL (1 PC) 	E SUPPORT LEG (2 PCS) 	F SIDE RAIL (4PCS) SUPPORT 
G LEGS (4 PCS) 	H FOOTBOARD (1 PC) FRONT PANEL (WITH LABEL 1) 	I FOOTBOARD (1 PC) BACK PANEL (WITH LABEL 2) 	J FOOTBOARD & SIDE RAIL SIDE PANEL (6 PCS) (WITH LABEL 3) 	K FOOTBOARD (1 PC) BOTTOM PANEL (WITH LABEL 4) 	L SIDE RAIL (2 PCS) FRONT PANEL (WITH LABEL 5) 
M SIDE RAIL (2 PCS) BACK PANEL (WITH LABEL 6) 	N SIDE RAIL (2 PCS) BOTTOM PANEL (WITH LABEL 7) 	O BOTTOM PANEL (7 PCS) BIG SUPPORT (WITH LABEL 8) 	P BOTTOM PANEL (4 PCS) SMALL SUPPORT (WITH LABEL 9) 	Q SLAT (14 PCS) 	R SIDE WING (2 PCS) 

HARDWARE LIST


1 JCBC M6 X 40mm(2 PCS) 	2 JCB M8 x 16 mm (8pcs) (PRE-ATTACHED) 	3 ALLEN KEY M4 X 65mm (1 PC) 	4 ALLEN KEY M5 X 70mm (1 PC) 	5 CSK M3.5 x 16mm (60PCS) 
6 CSK M4 x 25mm (8 PCS) 	7 CSK M4 x 32mm (67 PCS) 	8 CSK M4 x 50mm (28 PCS) 	9 ROLLER (14 PCS) 	10 WOOD DOWEL 20MM (8 PCS) 
11 POWER NAIL 6/8 (24 PCS) 	12 ADJUSTER (2 PCS) 	13 JCBC M6 X 50mm(4 PCS) 	14 SPRING WASHERS (4 PCS) 	15 FLAT WASHERS (4 PCS) 
16 METAL STOPPER (6 PCS) 				

Step 1 : Unzip the black non-woven fabric on the back of headboard and take out side wing (R) out.




Back View !!


Step 2 : Tighten the legs (G) by using self tapping screws to both headboard (A) and footboard (B) as shown. Not required to predrill the holes. Tighten the side wing (R) to headboard (A) as shown.




Step 3 : Attach wood dowel (10) to side rail (C). Tighten the side rail support (F) to the side rail (C) with screws (6) using screw driver (not included).




Step 4 : Attach side rail (C) to headboard (A) and footboard (B) by pushing the bracket down to fit it.




Step 5 : Attach the support legs (E) to the center rail (D) of the bed as shown. Slide the center rail (D) to the headboard (A) and footboard (B).




Step 6 : Tighten the footboard side panel (J) to the footboard front panel (H) and footboard back panel (I) with screws (8) using screw driver (not included).




Step 7 : Slide the footboard bottom panel (K) to the set up drawer.




Step 8 : Tighten the bottom panel support (O & P) with screws (7) using screw driver (not included). Attach the bottom panel with Nail (11) using the hammer (not included).




Step 9 : Tighten the roller (9) with screws (5) using screw driver (not included).




Step 10 : Tighten the side rail side panel (J) to the side rail front panel (L) and side rail back panel (M) with screws (8) using screwdriver (not included).




Step 11 : Slide the side rail bottom panel (O) to the set up drawer.




Step 12 : Tighten the bottom panel support (O & P) with screws (7) using screw driver (not included).



Step 13 : Tighten the roller (9) with screws (5) using screw driver (not included).



Step 14 : Affix the Slat (Q) to the side rail support wood and the center rail (D). Tighten all the 4 corner .



Remark

- A) Please lift up the foot end gently to straighten the bed .
- B) Tighten screws on one side of side rail only.
- C) Side rail is flexible please push on the center parts of the side rail gently then tighten the screw on side rail immediately. If necessary you may need to push the centre of side rail and pull the slat gently toward you all at the same time which will close the gap .
- D) Tighten all the screw.

ATTENTION:
prevent the drawer from being pulled out too far and drop

It is optional to choose attach the drawer stopper.