




**Fantastic
Furniture**

Version 1.0



Anaheim

Corner Desk

fantasticfurniture.com.au

**It takes two people to move this product.
Recommended weight capacity : 80kg**

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love!



Fantastic Furniture


Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!
@fantasticfurniture


Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What you need


to assemble the product




DO NOT USE

Parts list


4 x Leg Frame (P1);
2 x Leg Frame (P2);
2 x Right Desk Rail (P3);
1 x Left Desk Rail (P4);
1 x Left Desk Rail (P5);
2 x Left Support Rail (P6);
2 x Leg Frame Rail (P7);
1 x Left Desk Rail (P8);
4 x Leg Frame Tube (P9);
1 x Bracket (P10);
1 x Left Desk Top (P11);
1 x Left Desk Bottom (P12);
1 x Panel (P13);
1 x Panel (P14);
2 x Panel (P15);
1 x Panel (P16);
1 x Right Desk Top (P17);
1 x Right Desk Bottom (P18);
1 x Panel (P19);
1 x Panel (P20);
1 x Panel (P21);
1 x Panel (P22);
1 x Panel (P23);
1 x Drawer Front (P24);
1 x Left Drawer Side (P25);
1 x Right Drawer Side (P26);
1 x Drawer Back (P27);
1 x Drawer Support (P28);
1 x Drawer Base (P29);
2 x Top Shelf (P30);
2 x Bottom Shelf (P31)



4 x Leg Frame
(P1)



2 x Leg Frame
(P2)



2 x Right Desk Rail
(P3)



1 x Left Desk Rail
(P4)



1 x Left Desk Rail
(P5)



2 x Left Support Rail
(P6)



2 x Leg Frame Rail
(P7)



1 x Left Desk Rail
(P8)




4 x Leg Frame Tube
(P9)



1 x Bracket
(P10)



Fantastic
Furniture




Hardware pack




1 x CLRunner Track
(H1)



1 x CR Runner Track
(H2)



1 x DL Runner
(H3)



1 x DR Runner
(H4)



20 x Bolts
(H5)



8 x Bolts (60mm)
(H6)



6 x Bolts (45mm)
(H7)



12 x Bolts (35mm)
(H8)



16 x Bolts (28mm)
(H9)



12 x Bolts (25mm)
(H10)



4 x Bolts (12mm)
(H11)



14 x Screws
(H12)



12 x Screws
(H13)



2 x Bolts
(H14)



21 x Cam Bolts
(H15)



21 x Cam Nuts
(H16)







44 x Dowels
(H17)



1 x Allen Key
(H18)



Step 1

You will need		
		
4 x Bolts (60mm) (H6)	8 x Bolts (35mm) (H8)	1 x Allen Key (H18)




Attach 1 x Leg Frame Rail (P7) to 1 x Leg Frame (P1) with 1 x Bolts (H6), tightening to 70% with the Allen Key (H18).
 Attach 2 x Leg Frame Tubes (P9) to 1 x Leg Frame (P1) with 2 x Bolts (H8), tightening to 70% with the Allen Key (H18).
 Repeat process to attach the Leg Frame (P1) on the other side.
 Fully tighten bolts.
 Repeat the above process for the remaining Leg Frames.

Step 2

You will need	
	
16 x Bolts (28mm) (H9)	1 x Allen Key (H18)

2X







Fix Top Shelf (P30) to the 2 x Leg Frames (P1) with 4 x Bolts (H9), by tightening with the Allen Key (H18).

Fix Bottom Shelf (P31) to the 2 x Leg Frames (P1) with 4 x Bolts (H9), by tightening with the Allen Key (H18).

Repeat process for the remaining Leg Frames.




Step 3


You will need		
		
2 x Bolts (H14)	2 x Bolts (45mm) (H7)	1 x Allen Key (H18)



Fix the 2 x Right Desk Rails (P3) onto the Leg Frame Rail (P7) with 2 x Bolts (H7), tightening to 70% with the Allen Key (H18).
Insert 2 x Bolts (H14) to the other end of the Right Desk Rails (P3), tightening by rotating clockwise as shown.


Step 4

You will need		
		
2 x Bolts (60mm) (H6)	2 x Bolts (45mm) (H7)	1 x Allen Key (H18)






Fix the Left Desk Rail (P4) and Left Desk Rail (P5) to the Leg Frame Rail (P7) with 2 x Bolts (H7), tightening to 70% with the Allen Key (H18).
Attach the Left Desk Rail (P4) and Left Desk Rail (P8) to Leg Frame (P2) with 2 x Bolts (H6), tightening to 70% with the Allen Key (H18).


Step 5



Slot the bolts on the 2 x Right Desk Rails (P3) through Left Desk Rail (P4). Then attach 2 x Left Support Rails (P6) to the 2 x Right Desk Rails (P3) by rotating the rails as shown.

Step 6



You will need		
		
2 x Bolts (60mm) (H6)	2 x Bolts (45mm) (H7)	1 x Allen Key (H18)




Fix the 2 x Left Support Rails (P6) to Rails (P5 & P8) with 2 x Bolts (H7), tightening to 70% with the Allen Key (H18).

Then fix the 2 x Left Support Rails (P6) to the Leg Frame (P2) with 2 x Bolts (H6), tightening to 70% with the Allen Key (H18).




Step 7


You will need	
	
4 x Bolts (12mm) (H11)	1 x Allen Key (H18)



Attach the Bracket (P10) to the Leg Frames (P2) with 4 x Bolts (H11), tightening with the Allen Key (H18).
Now fully tighten all bolts on the frame.



Step 8


You will need		
		
8 x Cam Bolts (H15)	10 x Dowels (H17)	Phillips Head Screwdriver



Insert 10 x Dowels (H17) into Left Desk Top (P11).
Insert 8 x Cam Bolts (H15) into Left Desk Top (P11), by tightening with a
Phillips Head Screwdriver.



Step 9


You will need	
	
4 x Cam Nuts (H16)	Phillips Head Screwdriver




Insert 4 x Cam Nuts (H16) into Panels (P13 & P14).
 Rotate the Cam Nuts so the arrows point towards the incoming bolts.
 Attach Panels (P13 & P14) to the Left Desk Top (P11), by tightening the Cam Nuts with a Phillips Head Screwdriver.
 Slot on Panel (P16) onto the Dowels into position as shown.

Step 10



You will need	
	
4 x Cam Nuts (H16)	Phillips Head Screwdriver



This is how a cam nut works.....






The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.




Insert 4 x Cam Nuts (H16) into 2 x Panels (P15). Rotate the Cam Nuts so the arrows point towards in the incoming bolts.

Attach 2 x Panels (P15) to the Left Desk Top (P11), by tightening the Cam Nuts with a Phillips Head Screwdriver.



Step 11


You will need		
		
4 x Bolts (H12)	8 x Dowels (H17)	Phillips Head Screwdriver



Insert 8 x Dowels (H17) into Panels (P13, P14 & P15).
Secure Panels (P13 & P14) with 4 x Screws (H12), by tightening with a Phillips Head Screwdriver.




Step 12


You will need	
	
10 x Bolts (H5)	1 x Allen Key (H18)



Align the Left Desk Bottom (P12) to the Dowels as shown.
Attach the Left Desk Bottom (P12) to Panels (P13, P14, P15 & P16) with 10 x Bolts (H5), by tightening with the Allen Key (H18).

Step 13




You will need		
		
2 x Bolts (35mm) (H8)	8 x Bolts (25mm) (H10)	1 x Allen Key (H18)




With two people, carefully lift the left desk unit on top of the frame and align with the holes on the frame.

Attach the left desk unit with 2 x Bolts (H8) and 8 x Bolts (H10), by tightening with the Allen Key (H18) as shown.



Step 14




You will need		
		
8 x Cam Bolts (H15)	10 x Dowels (H17)	Phillips Head Screwdriver



Insert 10 x Dowels (H17) into the Right Desk Top (P17) as shown.
Insert 8 x Cam Bolts (H15) into Right Desk Top (P17), by tightening with Phillips Head Screwdriver.



Step 15


You will need	
	
4 x Cam Nuts (H16)	Phillips Head Screwdriver




Insert 4 x Cam Nuts (H16) into the Panels (P19 & P20).
 Rotate the Cam Nuts (H16) so the arrows point towards the incoming bolts.
 Attach Panels (P19 & P20) to the Right Desk Top (P17), by tightening the Cam Nuts (H16) with a Phillips Head Screwdriver.
 Slot on Panel (P23) onto the Dowels into position as shown.

Step 16



You will need	
	
4 x Cam Nuts (H16)	Phillips Head Screwdriver



This is how a cam nut works.....







The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.



Insert 4 x Cam Nuts (H16) into Panels (P21 & P22).
 Rotate the Cam Nuts (H16) so the arrows point towards the incoming bolts.
 Attach Panels (P21 & P22) to the Right Desk Top (P17), by tightening the Cam Nuts (H16) with a Phillips Head Screwdriver.



Step 17


You will need		
		
4 x Bolts (H12)	8 x Dowels (H17)	Phillips Head Screwdriver



Insert 8 x Dowels (H17) into Panels (P19, P20, P21 & P22).
Secure Panels (P19 & P20) with 4 x Screws (H12), by tightening with a Phillips Head Screwdriver.



Step 18


You will need	
	
6 x Bolts (H13)	Phillips Head Screwdriver



Attach 1 x CL Runner Track (H1) to Panel (P21) and 1 x CR Runner Track (H2) to Panel (P22) with 6 x Screws (H13), by tightening with a Phillips Head Screwdriver as shown.


Step 19


You will need	
	
10 x Bolts (H5)	1 x Allen Key (H18)



Align the Right Desk Bottom (P18) to the Dowels as shown.
Attach the Right Desk Bottom (P18) to Panels (P19, P20, P22 & P23) with 10 x Bolts (H5), by tightening with the Allen Key (H18).

Step 20

You will need

8 x Dowels (H17)







With two people, carefully lift the right desk unit into position, aligning to the holes in the frame.

Connect the right desk unit with the left desk unit with 8 x Dowels (H17).

Please watch your fingers during this process of connecting the two desk units.



Step 21


You will need		
		
2 x Bolts (35mm) (H8)	4 x Bolts (25mm) (H10)	1 x Allen Key (H18)



Attach the right desk unit to the frame with 2 x Bolts (H8) and 4 x Bolts (H10), by tightening with the Allen Key (H18) as shown.


Step 22

You will need	
	
6 x Bolts (H12)	Phillips Head Screwdriver






Attach the Right Drawer Side (P25), Left Drawer Side (P26) and Drawer Support (P28) to the Drawer Back (P27) with 6 x Screws (H12), by tightening with a Phillips Head Screwdriver as shown.

Step 23




Slide in the Drawer Base (P29) into the grooves of Panels (P25, P26 & P27).
Ensure the Drawer Base (P29) is slotted into the grooves fully.






Step 24

You will need		
		
5 x Cam Bolts (H15)	5 x Cam Nuts (H16)	Phillips Head Screwdriver

This is how a cam nut works.....



The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.






Insert 5 x Cam Nuts (H16) into the Panels (P25, P26 & P28).
 Rotate the Cam Nuts (H16) so the arrows point towards the incoming bolts.
 Insert 5 x Cam Bolts (H15) into the Drawer Front (P24), by tightening with a Phillips Head Screwdriver.
 Attach the Drawer Front (P24) to Panels (P25, P26 & P28), by tightening the Cam Nuts (H16) with a Phillips Head Screwdriver.



Fantastic Furniture


Step 25

You will need	
	
6 x Bolts (H13)	Phillips Head Screwdriver




Attach 1 x DL Runner (H3) to the bottom of Left Drawer Side (P25) and 1 x DR Runner (H4) to the bottom of Right Drawer Side (P26) with 6 x Screws (H13) by tightening with the Phillips Head Screwdriver.

Step 26



Insert the assembled drawer into the corresponding compartment as shown.
Ensure the drawers slide easily along the rails.

Step 27



Job complete!

In the interest of our environment please dispose
of all packaging thoughtfully.