


Version 1.0



Required

Secure it!

Reduce the risk of furniture tip-over accidents





To avoid any serious or fatal injury, a wall strap has been provided with this product to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Fixing devices are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.

Recommended Weight Capacity :15kg/hanging rail, 10kg/shelf

To reduce the risk of furniture tipover:



- Do not allow children to stand, climb or hang on furniture. It may topple and cause serious injury or death.
- Do not place toys or other child appealing items on top of this furniture, and place heaviest items towards the bottom of the furniture.
- Do not open more than one drawer at the time.
- Anchoring this product to a wall or other suitable surface is recommended. Check anchors regularly.
- Avoid putting a TV on this product.

Wall attachment guide




For plasterboard (without available wood stud)

Securing method: Self drilling plasterboard anchor.



For plasterboard (with available wood stud)

Securing method: Screw inserted directly into stud.



For masonry wall

Solid wall: Plug with screw Hollow wall: Spring toggle

Please seek professional advice if you are in doubt of what fixing device to use.

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture to help create a home you'll love!



Love it? Share it!


Fantastic buy! Share how it looks at home on Instagram for your chance to win a \$250 Fantastic Furniture Gift Card! @fantasticfurniture



Assembly Checklist



Read through the instructions carefully before you begin.



Identify and lay out all of the components before you begin assembly.



- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.




Make sure you have all the required tools. Never use power tools unless instructed.





Unless instructed, do not fully tighten screws until the item is fully assembled.







Furniture Page 5






Page 6






Insert 4 x Dowels (H1) into Shelf Panels (P8 & P9). Insert 4 x Cam Nuts (H4) into Shelf Panels (P8 & P9). Rotate the nuts so the arrows point towards the incoming bolts. Attach Shelf Panels (P8 & P9) to Divider (P7) by tightening all nuts with the Phillips Head Screwdriver.




Insert 2 x Cam Bolts (H3) into Bottom Panel (P4). Tightening with the Phillips Head Screwdriver. Insert 2 x Cam Nuts (H4) into Rail (P10). Rotate the nuts so the arrows point towards the incoming bolts. Attach Rail (P10) to Bottom Panel (P4) by tightening all nuts with the Phillips Head Screwdriver.











Insert 2 x Dowels (H1) into Divider (P7). Attach Bottom Panel (P4) to Divider (P7) with 2 x Long Screws (H2) by tightening with the Phillips Head Screwdriver.

Step 6




Insert 5 x Dowels (H1) into Shelf Panel (P9), Bottom Panel (P4) and Rail (P10). Insert 5 x Cam Nuts (H4) into Shelf Panel (P9), Bottom Panel (P4) and Rail (P10). Rotate the nuts so the arrows point towards the incoming bolts. Attach Left Side Panel (P2) to Shelf Panel (P9), Bottom Panel (P4) and Rail (P10) by tightening all nuts with the Phillips Head Screwdriver.






Insert 5 x Cam Nuts (H4) into Shelf Panel (P8), Bottom Panel (P4) and Rail (P10). Rotate the nuts so the arrows point towards the incoming bolts. Attach Right Side Panel (P3) to Shelf Panel (P8), Bottom Panel (P4) and Rail (P10) by tightening all nuts with the Phillips Head Screwdriver.




Slide Back Panels (P5 & P6) into the grooves of Left & Right Side Panel (P2 & P3) and Divider (P7).






Attach 1 \times Magnetic Mechanism (H6) to Top Panel (P1) with 2 \times Wedge Screws (H14) as shown by tightening with the Phillips Head Screwdriver.



Insert 6 x Dowels (H1) into Left & Right Side Panel (P2 & P3) and Divider (P7). Attach Top panel (P1) to Left & Right Side Panel (P2 & P3) and Divider (P7) with 6 x Long Screws (H2) by tightening with the Phillips Head Screwdriver.


Attach 4 x Plastic Glides (H12) to Left & Right Side Panel (P2 & P3), gently using a hammer. Lift the unit until it is vertical.






Two People






Attach 2 x Hanging Rail Supports (H10) to the Left Side Panels (P2) and Divider (P7) with 4 x Small Screws (H18) by tightening with a Phillips Head Screwdriver. Attach 1 x Hanging Rail (H11) to Hanging Rail Support (H10) as shown by slotting it in.




Attach 2 x Magnetics Bars (H7) to Door (P11) with 4 x Small Screws (H18). Attach 3 x Hinges (H9) to Door (P11) with 6 x Screws (H5). Tightening with the Phillips Head Screwdriver.





Attach Door (P11) to Left Side Panel (P2) with 12 x Screws (H5). Attach 1 x Handle (H15) to Door (P11) with 1 x Handle Screw (H16). Tightening with the Phillips Head Screwdriver.


Step 14





Insert 8 x Shelf Supports (H8) into the holes of the Right Side Panel (P3) and Divider (P7) at your preferred shelf height.

Insert the 2 x Shelf Panels (P12) into the unit by resting each shelf on the Shelf Supports.


Ensure each shelf is positioned securely.








Secure Back Panels (P5 & P6) in place with 10 \times Wedges (H13) and 10 \times Wedge Screws (H14) by tightening with the Phillips Head Screwdriver.



Move the unit to the final position, and attach the safety strap to the wall securely. Make sure it is firmly attached and snug fit.





Job Complete!


In the interest of our environment please dispose of all packaging thoughtfully.



TO ADJUST YOUR DOORS TO MAKE THE GAPS MORE EVEN


STEP 1

Open the door.





STEP 2

Adjust the door panels upward or downward



Unscrew 2 screws in round holes loosen 2 screws in oval holes a bit.







MOVE DOOR UPWARD OR DOWNWARD


Tighten 2 screws in oval holes. Screw in 2 screws in round holes

STEP 3 Adjust the flush between door panel and side panel






MOVE DOOR OUTWARD by turning this screw counter-clockwise




KEEP DOOR IN RIGHT POSITION




MOVE DOOR OUTWARD by turning this screw clockwise


STEP 4


Adjust the Gap beteen door panel and side panel





Loosen this screw a bit.





MOVE DOOR BACK OR FORTH

Re-tighten this screw.

