




Version 1.0



HAVANA

Bedside 2 Drawer

www.fantasticfurniture.com.au


Enjoy
Your purchase from
Australia's Best Value Furniture Store




Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools.
Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.

What you need

to assemble the product



DO NOT USE





Additional Tools Required

Flat head screwdriver;
Phillips head screwdriver;
Hammer

Parts list

Box 1: Top Panel (P1);
Left Side Panel (P2);
Right Side Panel (P3);
Rail (P4); Rail (P5);
Back Panel (P6);
LF Leg (P7); RF Leg (P8);
LR Leg (P9); RR Leg (P10);
2 x Drawer Front (P11);
2 x Left Drawer Side (P12);
2 x Right Drawer Side (P13);
2 x Drawer Base (P14);
2 x Drawer Back (P15);
LF: Left Front
LR: Left Rear
RF: Right Front
RR: Right Rear


Hardware pack



20 x Dowels
(H1)



4 x Plastic
Glides
(H2)



18 x Cam Bolts
(H3)



18 x Cam Nuts
(H4)



20 x Small
Screws
(H5)




2 x CL Runner
Tracks
(H6)




2 x CR Runner
Tracks
(H7)



2 x DL Runners
(H8)



2 x DR Runners
(H9)




8 x Small
Cam Bolts
(H10)



8 x Small
Cam Nuts
(H11)



8 x Long
Screws
(H12)



2 x Handles
(H13)



4 x Round
Head Bolts
(H14)






4 x Wedges
(H15)



4 x Screws
(H16)




Step 1


You will need	
	
8 x Cam Bolts (H3)	Phillips head screwdriver




Attach 8 x Cam Bolts (H3) into Legs (P7, P8, P9, P10).

Step 2

You will need	
	
4 x Dowels (H1)	4 x Cam Nuts (H4)
	
Flat head screwdriver	






This is how a cam nut works.....




The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.

Insert 4 x Dowels (H1) into the holes of Left Side Panel (P2).
Insert 4 x Cam Nuts (H4) into the holes of Left Side Panel (P2).
Rotate the cam nuts so the arrows point towards the incoming cam bolts.
Attach Legs (P7, P9) to Left Side Panel (P2), then tighten the cam nuts.




Step 3


You will need	
	
4 x Dowels (H1)	4 x Cam Nuts (H4)
	
Flat head screwdriver	



Insert 4 x Dowels (H1) into the holes of Right Side Panel (P3).
Insert 4 x Cam Nuts (H4) into the holes of Right Side Panel (P3).
Rotate the cam nuts so the arrows point towards the incoming cam bolts.
Attach Legs (P8, P10) to Right Side Panel (P3), then tighten the cam nuts.




Step 4


You will need	
	
2 x CL Runner Tracks (H6)	6 x Small Screws (H5)
	
Phillips head screwdriver	



Attach 2 x CL Runner Tracks (H6) to Left Side Panel (P2) with 6 x Small Screws (H5).



Step 5


You will need	
	
2 x CR Runner Tracks (H7)	6 x Small Screws (H5)
	
Phillips head screwdriver	



Attach 2 x CR Runner Tracks (H7) to Right Side Panel (P3) with 6 x Small Screws (H5).




Step 6


You will need	
	
4 x Cam Bolts (H3)	Phillips head screwdriver



Attach 4 x Cam Bolts (H3) into Side Panels (P2, P3) and Legs (P7, P8, P9, P10).

Step 7

You will need	
	
2 x Dowels (H1)	2 x Cam Nuts (H4)
	
Flat head screwdriver	



Insert 2 x Dowels (H1) into Rails (P4, P5).




Insert 2 x Cam Nuts (H4) into the holes of Rails (P4, P5).


Rotate the cam nuts so the arrows point towards the incoming cam bolts.

Align the holes and attach Legs (P7, P9) to Left Side Panel (P2).

Tighten the cam nuts.

Step 8

You will need	
	
2 x Dowels (H1)	2 x Cam Nuts (H4)
	
Flat head screwdriver	



Insert 2 x Dowels (H1) into Rails (P4, P5).



Insert 2 x Cam Nuts (H4) into the holes of Rails (P4, P5).


Rotate the cam nuts so the arrows point towards the incoming cam bolts.

Align the holes and attach Legs (P8, P10) to Right Side Panel (P3).

Tighten the cam nuts.


Step 9


You will need	
	
4 x Plastic Glides (H2)	Hammer



Attach 4 x Plastic Glides (H2) to the bottom of Legs (P7, P8, P9, P10) with a Hammer.



Step 10


You will need	
	
8 x Dowels (H1)	



Slide Back Panel (P6) into the groove in Legs (P9, P10) and Rail (P5).
Insert 8 x Dowels (H1) into Side Panels (P2, P3) and Legs (P7, P8, P9, P10).



Step 11


You will need	
	
6 x Cam Bolts (H3)	Phillips head screwdriver



Attach 6 x Cam Bolts (H3) into Top Panel (P1) as shown.




Step 12



You will need	
	
6 x Cam Nuts (H4)	Flat head screwdriver



Insert 6 x Cam Nuts (H4) into the holes of Side Panels (P2, P3) and Legs (P7, P8, P9, P10). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Attach Top Panel (P1) to the frame and tighten the cam nuts using a Flat head screwdriver.



Step 13


You will need	
	
4 x Wedges (H15)	4 x Screws (H16)
	
Phillips head screwdriver	



Secure Back Panel (P6) in place with 4 x Wedges (H15) using 4 x Screws (H16).



Step 14


You will need	
	
4 x Small Cam Bolts (H10)	Phillips head screwdriver



Screw 4 x Small Cam Bolts (H10) into Drawer Front (P11) with a Phillips head screwdriver.


Step 15

You will need	
	
4 x Small Cam Nuts (H11)	Flat head screwdriver





Insert 4 x Small Cam Nuts (H11) into the holes of Drawer Sides (P12, P13). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Align the holes together, secure Drawer Sides (P12, P13) into place and tighten the cam nuts using a Flat head screwdriver.

Step 16




Slide Drawer Base (P14) in through the grooves on Drawer Sides (P12, P13).





Step 17


You will need	
	
4 x Long Screws(H12)	Phillips head screwdriver

Attach Drawer Back (P15) to Drawer Sides (P12, P13) with 4 x Long Screws (H12), make sure that the groove lines up the whole way around the drawer. Tighten Screws using a Phillips head screwdriver.






Step 18


You will need	
	
1 x DL Runner (H8)	1 x DR Runner (H9)
	
4 x Small Screws (H5)	Phillips head screwdriver



Attach 1 x DL Runner (H8) to the bottom of Left Drawer Side (P12) and 1 x DR Runner (H9) to the bottom of Right Drawer Side (P13) with 4 x Small Screws (H5). Tighten Screws using a Phillips head screwdriver.


Step 19

You will need	
	
1 x Handle (H13)	2 x Round Head Bolts (H14)
	
Phillips head screwdriver	




Attach 1 x Handle (H13) to Drawer Front (P11) with 2 x Round Head Bolts (H14). Tighten round head bolts using a Phillips head screwdriver. Repeat Step 14 to Step 19 to assemble the other drawer.

Step 20



Slide the drawers into the bedside table.

Step 21



Recommended weight capacity : 80KG.


Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.



**Fantastic
Furniture**

Version 1.0



Two People



Required

HAVANA
Bed King

fantasticfurniture.com.au

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love



Fantastic Furniture

Love it? Share it!


Fantastic buy! Share how it looks at home for your
chance to win a \$250 Fantastic Furniture Gift Card!

[fantasticfurniture](#)


Assembly Checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What you need


to assemble the product



DO NOT USE



Other tools you need:
Phillips head screwdriver;
Hammer



Parts list

Bedhead (P1);
Bedfoot (P2);
2 x Side Covers (P3);
2 x Side Rails (P4);
Centre Rail (P5);
3 x Support Legs (P6);
2 x Article bed boards (P7);
11 x Article bed boards (P8)


Hardware pack



20 x Dowels
(H1)



26 x Screws
(H2)



12 x Cam Bolts
(H3)



12 x Cam Nuts
(H4)



4 x Half Round
Nuts
(H5)



4 x Threaded Rod
(H6)



4 x Hexagonal
Nuts
(H7)



1 x Spanner
(H8)



4 x Plastic
Glides
(H9)



5 x Long Bolts
(H10)



1 x Allen Key
(H11)



4 x Brackets
(H12)



8 x Bolts
(H13)



8 x Washers
(H14)



2 x Hexagonal
Nuts
(H15)



3 x Adjustable
(H16)








4 x Washers
(H17)



4 x Screws
(H18)





Step 1


You will need	
	
8 x Dowels (H1)	2 x Threaded Rod (H6)
	
2 x Plastic Glides (H9)	Hammer



Insert 8 x Dowels (H1) into Bedhead (P1). Attach 2 x Threaded Rod (H6) into Bedhead (P1). Hammer 2 x Plastic Glides (H9) onto the bottom of Bedhead (P1).







Step 2


You will need	
	
8 x Dowels (H1)	2 x Threaded Rod (H6)
	
2 x Plastic Glides (H9)	Hammer



Insert 8 x Dowels (H1) into Bedfoot (P2). Attach 2 x Threaded Rod (H6) into Bedfoot (P2). Hammer 2 x Plastic Glides (H9) onto the bottom of Bedfoot (P2).

Step 3

You will need	
	
6 x Cam Bolts (H3)	2 x Brackets (H12)
	
2 x Bolts (H13)	2 x Washers (H14)
	
1 x Allen Key (H11)	Phillips head screwdriver







Make sure the Brackets (H9) are well aligned with the edge of Side Cover (P3).

Attach 6 x Cam Bolts (H3) into Side Cover (P3).

Attach 2 x Brackets (H12) to Side Cover (P3) with 2 x Bolts (H13) and 2 x Washers (H14) using an Allen Key (H11). Do not fully tighten the bolts until Step 6.

Step 4

You will need	
	
6 x Cam Nuts (H4)	2 x Dowels (H1)
	
Phillips head screwdriver	



This is how a cam nut works.....

The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.

Insert 2 x Dowels (H1) into Side Cover (P3).

Insert 6 x Cam Nuts (H4) into the holes of Side Rail (P4).







Rotate the cam nuts so the arrows point towards the incoming cam bolts.


Attach Side Rail (P4) to Side Cover (P3),

then tighten the cam nuts with the Phillips Head Screwdriver.

Repeat Step 3 to Step 4 for the other Side Cover (P3) and Side Rail (P4).







Step 5


You will need	
	
2 x Half Round Nuts (H5)	2 x Hexagonal Nuts (H7)
	
1 x Spanner (H8)	2 x Bolts (H13)
	
2 x Washers (H14)	1 x Allen Key (H11)



Attach Bedfoot (P2) to Side Covers (P3) and Side Rails (P4) with 2 x Half Round Nuts (H5), and 2 x Hexagonal Nuts (H7) using a Spanner (H8). Connect the brackets to Bedfoot (P2) with 2 x Bolts (H13) and 2 x Washers (H14) using an Allen Key (H11). Do not fully tighten the bolts until Step 6.




Step 6


You will need	
	
2 x Half Round Nuts (H5)	2 x Hexagonal Nuts (H7)
	
1 x Spanner (H8)	2 x Bolts (H13)
	
2 x Washers (H14)	1 x Allen Key (H11)



Attach Bedhead (P1) to Side Covers (P3) and Side Rails (P4) with 2 x Half Round Nuts (H5), and 2 x Hexagonal Nuts (H7) using a Spanner (H8). Connect the brackets to Bedhead (P1) with 2 x Bolts (H13) and 2 x Washers (H14) using an Allen Key (H11). Fully tighten all Bolts (H13) on 4 x Brackets (H9).



Step 7


You will need	
	
3 x Long Bolts (H10)	1 x Allen Key (H11)
	
3 x Adjustable (H16)	



Attach 3 x Support Legs (P6) to Centre Rail (P5) with 3 x Long Bolts (H10) using Allen Key (H11). Insert the 3 x Adjustable (H16) into the Support Legs (P6) .







Step 8


You will need	
	
4 x Screws (H18)	Phillips head screwdriver



Attach Centre Rail (P5) to Bedhead (P1) and Bedfoot (P2) screw with 4 x Screws (H18). Tighten with a Phillips Head Screwdriver.



Step 9


You will need	
	
4 x Screws (H2)	2 x Long Bolts (H10)
	
2 x Hexagonal Nuts (H15)	4 x Washers (H17)
	
1 x Allen Key (H11)	Phillips head screwdriver




Attach Article bed boards (P7x2) to Centre Rail (P5) with 4 x Washers (H17), 2 x Long Bolts (H10) and 2 x Hexagonal Nuts (H15) using Allen Key (H11). Then screw Article bed boards (P7x2) with 4 x Screws (H2). Move the bed to the proper position after folding and adjusting the foot 5mm. After reaching the proper position, rotate the adjusting foot to the ground level.

Step 10

You will need	
	
22 x Screws (H2)	Phillips head screwdriver



Attach Article bed boards (P8x11) to Side Rails (P4) with 22 x Screws (H2). Tighten with a Phillips head screwdriver.




Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.



Version 1.0



HAVANA

Tallboy 5 Drawer

www.fantasticfurniture.com.au


Enjoy
Your purchase from
Australia's Best Value Furniture Store




Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools.
Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.

What you need to assemble the product



DO NOT USE



Additional Tools Required

Flat head screwdriver;
Phillips head screwdriver;
Hammer

Parts list

Box 1: Top Panel (P1);
Rail (P5); Rail (P6);
LF Leg (P7); RF Leg (P8);
LR Leg (P9); RR Leg (P10);

Box 2: Left Side Panel (P2);
Right Side Panel (P3);
2 x Rails (P4);
Back Panel (P11);

5 x Drawer Fronts (P12);
5 x Left Drawer Sides (P13);
5 x Right Drawer Sides (P14);
5 x Drawer Bases (P15);
5 x Drawer Backs (P16);
5 x Drawer Supports (P17);
Connect Stick (P18)

LF : Left Front LR : Left Rear
RF : Right Front RR : Right Rear

Hardware pack

Top Panel
(P1)

RR Leg
(P10)

Right Side
Panel
(P3)

Back Panel
(P11)

Rail
(P4)

Rail
(P4)

Rail
(P6)



Rail
(P5)

RF
Leg
(P8)



LR
Leg
(P9)


Left Side
Panel
(P2)

LF
Leg
(P7)






Step 1


You will need	
	
16 x Cam Bolts (H3)	Phillips head screwdriver




Attach 16 x Cam Bolts (H3) into Legs (P7, P8, P9, P10).

Step 2

You will need	
	
12 x Small Dowels (H2)	16 x Cam Nuts (H4)
	
Flat head screwdriver	



This is how a cam nut works.....



The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.

Insert 12 x Small Dowels (H2) into the holes of Side Panels (P2, P3).




Insert 16 x Cam Nuts (H4) into the holes of Side Panels (P2, P3).


Rotate the cam nuts so the arrows point towards the incoming cam bolts.

Attach Legs (P7, P9) to Left Side Panel (P2) and Legs (P8, P10) to Right Side Panel (P3).

Tighten the cam nuts using a Flat head screwdriver.

Step 3


You will need	
	
5 x CL Runner Track (H6)	15 x Small Screws (H5)
	
Phillips head screwdriver	



Attach 5 x CL Runner Tracks (H6) to Left Side Panel (P2) with 15 x Small Screws (H5).



Step 4


You will need	
	
5 x CR Runner Track (H7)	15 x Small Screws (H5)
	
Phillips head screwdriver	



Attach 5 x CR Runner Tracks (H7) to Right Side Panel (P3) with 15 x Small Screws (H5).




Step 5


You will need	
	
8 x Cam Bolts (H3)	Phillips head screwdriver



Attach 8 x Cam Bolts (H3) into Side Panels (P2, P3) and Legs (P7, P8, P9, P10).






Step 6


You will need	
	
4 x Small Dowels (H2)	4 x Cam Nuts (H4)
	
Flat head screwdriver	



Insert 4 x Small Dowels (H2) into Left Side Panel (P2) and Legs (P7, P9).
 Insert 4 x Cam Nuts (H4) into the holes of Rails (P4, P5, P6).
 Rotate the cam nuts so the arrows point towards the incoming cam bolts.
 Attach Rails (P4, P5, P6) to the left frame, then tighten the cam nuts using a Flat head screwdriver.


Step 7

You will need	
	
4 x Small Dowels (H2)	4 x Cam Nuts (H4)
	
4 x Plastic Glides (H2)	Flat head screwdriver
	
Hammer	




Insert 4 x Small Dowels (H2) into Right Side Panel (P3) and Leg (P10).
 Insert 4 x Cam Nuts (H4) into the holes of Rails (P4, P5, P6).
 Rotate the cam nuts so the arrows point towards the incoming cam bolts.
 Push the right frame into place, then tighten the cam nuts using a Flat head screwdriver.
 Hammer 4 x Plastic Glides (H2) on Legs (P7, P8, P9, P10) as shown.

Step 8

You will need	
	
4 x Dowels (H1)	





make sure the arrow label
is facing top when slide
in the back panel



Carefully turn the tallboy over to an upright position.
Slide Back Panels (P11) into the grooves in Legs (P9, P10) and Rail (P6).
Insert 4 x Dowels (H1) into Legs (P7, P8, P9, P10) as shown.



Step 9


You will need	
	
4 x Small Dowels (H2)	



Insert 4 x Small Dowels (H2) into Side Panels (P2, P3) as shown.



Step 10


You will need	
	
6 x Cam Bolts (H3)	Phillips head screwdriver



Attach 6 x Cam Bolts (H3) into Top Panel (P1) as shown.





Step 11


You will need	
	
6 x Cam Nuts (H4)	Flat head screwdriver





Insert 6 x Cam Nuts (H4) into the holes of Side Panels (P2, P3) and Legs (P7, P8, P9, P10). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Attach Top Panel (P1) into place, and then tighten the cam nuts.

Step 12

You will need	
	
4 x Wedges (H15)	4 x Screws (H16)
	
2 x Small Screws (H5)	Phillips head screwdriver






Make sure Wedge (H15) is facing to the bottom of Top Panel (P1).



Secure Back Panel (P11) in place with 4 x Wedges (H15) using 4 x Screws (H16).
Use 2 x Small Screws (H5) to fix Back Panel (P11) onto Rail (P4).
Tighten the screws with a Phillips head screwdriver.




Step 13


You will need	
	
5 x Small Cam Bolts (H10)	Phillips head screwdriver



Screw 5 x Small Cam Bolts (H10) into Drawer Front (P12) with a Phillips head screwdriver.

Step 14

You will need	
	
1 x Small Dowel (H2)	5 x Small Cam Nuts (H11)
	
Flat head screwdriver	




Insert 1 x Small Dowel (H2) into Drawer Front (P12) as shown.

Insert 5 x Small Cam Nuts (H11) into the holes of Drawer Sides (P13, P14) and Drawer Support (P17).

Rotate the cam nuts so the arrows point towards the incoming cam bolts.



Align the holes together, secure Drawer Sides (P13, P14) and Drawer Support (P17) into place, tighten the cam nuts using a Flat head screwdriver.


Step 15



Slide Drawer Base (P15) into the grooves in Drawer Sides (P13, P14).

Step 16

You will need	
	
6 x Long Screws (H12)	Phillips head screwdriver



Attach Drawer Back (P16) to Drawer Sides (P13, P14)


and Drawer Support (P17) with 6 x Long Screws (H12), make sure that the groove lines up the whole way around the drawer.

Tighten Screws using a Phillips head screwdriver.

www.fantasticfurniture.com.au

Step 17


You will need	
1 x DL Runner (H8)	1 x DR Runner (H9)
4 x Small Screws (H5)	Phillips head screwdriver



Attach 1 x DL Runner (H8) to the bottom of Left Drawer Side (P13) and 1 x DR Runner (H9) to the bottom of Right Drawer Side (P14) with 4 x Small Screws (H5). Tighten Screws using a Phillips head screwdriver.


Step 18

You will need	
2 x Handles (H13)	4 x Round Head Bolts (H14)
Phillips head screwdriver	




Attach 2 x Handles (H13) to Drawer Front (P12) with 4 x Round Head Bolts (H14). Tighten Round Head Bolts using a Phillips head screwdriver.

Step 19







Repeat Step 13 to Step 18 to assemble the other 4 drawers.

Step 20





Put the drawers into the dresser.

Step 21



You will need	
	
1 x Safety Strap (H18)	1 x Screw (H19)
	
1 x Washer (H20)	Phillips head screwdriver


We strongly advise that you use the wall safety strap provided to prevent the unit toppling




Use Screw (H19) and Washer (H20) to attach Safety Strap (H18) securely on Top Panel (P1) as shown.

Step 22


You will need	
	
1 x Washer (H20)	Phillips head screwdriver
Screw and Wall Plug which are not provided. Please use appropriate fixtures for your wall.	



Seek advice from a qualified trades person on how to attach this safety strap to your specific wall.



Move the tallboy to the final position, and attach the safety strap to the wall securely. Make sure it is firmly attached and snug fit.



Recommended weight capacity : 80KG.

Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.