




Version 1.0



HAVANA

Bedside 2 Drawer

www.fantasticfurniture.com.au

Enjoy


Your purchase from
Australia's Best Value Furniture Store




Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.

What you need

to assemble the product



DO NOT USE



Additional Tools Required




Flat head screwdriver;
Phillips head screwdriver;
Hammer

Parts list

Box 1: Top Panel (P1);
Left Side Panel (P2);
Right Side Panel (P3);
Rail (P4); Rail (P5);
Back Panel (P6);
LF Leg (P7); RF Leg (P8);
LR Leg (P9); RR Leg (P10);
2 x Drawer Front (P11);
2 x Left Drawer Side (P12);
2 x Right Drawer Side (P13);
2 x Drawer Base (P14);
2 x Drawer Back (P15);


LF: Left Front
LR: Left Rear
RF: Right Front
RR: Right Rear

Hardware pack



Step 1


You will need	
	
8 x Cam Bolts (H3)	Phillips head screwdriver




Attach 8 x Cam Bolts (H3) into Legs (P7, P8, P9, P10).

Step 2

You will need	
	
4 x Dowels (H1)	4 x Cam Nuts (H4)
	
Flat head screwdriver	



This is how a cam nut works.....




The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.

Insert 4 x Dowels (H1) into the holes of Left Side Panel (P2).
 Insert 4 x Cam Nuts (H4) into the holes of Left Side Panel (P2).
 Rotate the cam nuts so the arrows point towards the incoming cam bolts.
 Attach Legs (P7, P9) to Left Side Panel (P2), then tighten the cam nuts.


Step 3


You will need	
	
4 x Dowels (H1)	4 x Cam Nuts (H4)
	
Flat head screwdriver	



Insert 4 x Dowels (H1) into the holes of Right Side Panel (P3).
 Insert 4 x Cam Nuts (H4) into the holes of Right Side Panel (P3).
 Rotate the cam nuts so the arrows point towards the incoming cam bolts.
 Attach Legs (P8, P10) to Right Side Panel (P3), then tighten the cam nuts.


Step 4


You will need	
	
2 x CL Runner Tracks (H6)	6 x Small Screws (H5)
	
Phillips head screwdriver	



Attach 2 x CL Runner Tracks (H6) to Left Side Panel (P2) with 6 x Small Screws (H5).

Step 5


You will need	
	
2 x CR Runner Tracks (H7)	6 x Small Screws (H5)
	
Phillips head screwdriver	



Attach 2 x CR Runner Tracks (H7) to Right Side Panel (P3) with 6 x Small Screws (H5).

Step 6


You will need	
	
4 x Cam Bolts (H3)	Phillips head screwdriver



Attach 4 x Cam Bolts (H3) into Side Panels (P2, P3) and Legs (P7, P8, P9, P10).

Step 7

You will need	
	
2 x Dowels (H1)	2 x Cam Nuts (H4)
	
Flat head screwdriver	



Insert 2 x Dowels (H1) into Rails (P4, P5).

Insert 2 x Cam Nuts (H4) into the holes of Rails (P4, P5).


Rotate the cam nuts so the arrows point towards the incoming cam bolts.

Align the holes and attach Legs (P7, P9) to Left Side Panel (P2).

Tighten the cam nuts.

Step 8

You will need	
	
2 x Dowels (H1)	2 x Cam Nuts (H4)
	
Flat head screwdriver	



Insert 2 x Dowels (H1) into Rails (P4, P5).

Insert 2 x Cam Nuts (H4) into the holes of Rails (P4, P5).


Rotate the cam nuts so the arrows point towards the incoming cam bolts.

Align the holes and attach Legs (P8, P10) to Right Side Panel (P3).

Tighten the cam nuts.

Step 9


You will need	
	
4 x Plastic Glides (H2)	Hammer



Attach 4 x Plastic Glides (H2) to the bottom of Legs (P7, P8, P9, P10) with a Hammer.

Step 10


You will need	
	
8 x Dowels (H1)	



Slide Back Panel (P6) into the groove in Legs (P9, P10) and Rail (P5). Insert 8 x Dowels (H1) into Side Panels (P2, P3) and Legs (P7, P8, P9, P10).

Step 11


You will need	
	
6 x Cam Bolts (H3)	Phillips head screwdriver



Attach 6 x Cam Bolts (H3) into Top Panel (P1) as shown.

Step 12



You will need	
	
6 x Cam Nuts (H4)	Flat head screwdriver



Insert 6 x Cam Nuts (H4) into the holes of Side Panels (P2, P3) and Legs (P7, P8, P9, P10). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Attach Top Panel (P1) to the frame and tighten the cam nuts using a Flat head screwdriver.

Step 13


You will need	
	
4 x Wedges (H15)	4 x Screws (H16)
	
Phillips head screwdriver	



Secure Back Panel (P6) in place with 4 x Wedges (H15) using 4 x Screws (H16).

Step 14


You will need	
	
4 x Small Cam Bolts (H10)	Phillips head screwdriver



Screw 4 x Small Cam Bolts (H10) into Drawer Front (P11) with a Phillips head screwdriver.


Step 15

You will need	
	
4 x Small Cam Nuts (H11)	Flat head screwdriver



Insert 4 x Small Cam Nuts (H11) into the holes of Drawer Sides (P12, P13). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Align the holes together, secure Drawer Sides (P12, P13) into place and tighten the cam nuts using a Flat head screwdriver.

Step 16




Slide Drawer Base (P14) in through the grooves on Drawer Sides (P12, P13).

Step 17


You will need	
	
4 x Long Screws(H12)	Phillips head screwdriver

Attach Drawer Back (P15) to Drawer Sides (P12, P13) with 4 x Long Screws (H12), make sure that the groove lines up the whole way around the drawer. Tighten Screws using a Phillips head screwdriver.



Step 18


You will need	
	
1 x DL Runner (H8)	1 x DR Runner (H9)
	
4 x Small Screws (H5)	Phillips head screwdriver



Attach 1 x DL Runner (H8) to the bottom of Left Drawer Side (P12) and 1 x DR Runner (H9) to the bottom of Right Drawer Side (P13) with 4 x Small Screws (H5). Tighten Screws using a Phillips head screwdriver.


Step 19

You will need	
	
1 x Handle (H13)	2 x Round Head Bolts (H14)
	
Phillips head screwdriver	




Attach 1 x Handle (H13) to Drawer Front (P11) with 2 x Round Head Bolts (H14). Tighten round head bolts using a Phillips head screwdriver. Repeat Step 14 to Step 19 to assemble the other drawer.

Step 20



Slide the drawers into the bedside table.

Step 21




Recommended weight capacity : 80KG.

Job Complete!


In the interest of our environment please dispose of all packaging thoughtfully.



Version 1.0



TWO PEOPLE



REQUIRED

HAVANA

Dresser 7 Drawer

www.fantasticfurniture.com.au

Enjoy
Your purchase from
Australia's Best Value Furniture Store



**WARNING: ENSURE THE WALL STRAP IS ATTACHED TO
AVOID SERIOUS INJURY.**

To avoid any serious or fatal injury, this product has been fitted with a wall strap to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Fixing devices are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.


Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.

What you need

to assemble the product



DO NOT USE



Additional Tools Required

Flat head screwdriver;
Phillips head screwdriver;
Hammer




Parts list

Box 1: Top Panel (P1);
Left Side Panel (P2);
Right Side Panel (P3); 2 x Dividers (P4);
2 x Rails (P5); Divider (P6);
LF Leg (P7); RF Leg (P8);
LR Leg (P9); RR Leg (P10);
Rail (P11); Rail (P12);
Back Panel (P13);

Box 2: Smaller Drawer Front (P14);
Smaller Drawer Front (P15);
Smaller Drawer Front (P16);
7 x Left Drawer Side (P17);
7 x Right Drawer Side (P18);
3 x Smaller Drawer Base (P19);
3 x Smaller Drawer Back (P20);
2 x Larger Drawer Front (P21);
2 x Larger Drawer Front (P22);
4 x Larger Drawer Base (P23);
4 x Larger Drawer Back (P24);

LF: Left Front LR: Left Rear
RF: Right Front RR: Right Rear

Hardware pack



30 x Dowels
(H1)



6 x Plastic
Glides
(H2)




32 x Cam
Bolts
(H3)




32 x Cam
Nuts
(H4)



70 x Small
Screws
(H5)



7 x CL Runner
Tracks
(H6)



7 x CR Runner
Tracks
(H7)



7 x DL
Runners
(H8)



7 x DR
Runners
(H9)



28 x Small
Cam Bolts
(H10)



28 x Small
Cam Nuts
(H11)



36 x Long
Screws
(H12)



7 x Handles
(H13)



14 x Round
Head Bolts
(H14)




4 x Wedges
(H15)



4 x Screws
(H16)



2 x Wooden
Screws M4 x 40mm
(H17)




2 x Washers
(H18)

1 x Safety
Strap
(H19)

Step 1


You will need	
	
12 x Cam Bolts (H3)	Phillips head screwdriver



Attach 12 x Cam Bolts (H3) into Legs (P7, P8, P9, P10).


Step 2

You will need	
	
4 x Dowels (H1)	6 x Cam Nuts (H4)
	
Flat head screwdriver	



Insert 4 x Dowels (H1) into the holes of Left Side Panel (P2).
 Insert 6 x Cam Nuts (H4) into the holes of Left Side Panel (P2).
 Rotate the cam nuts so the arrows point towards the incoming cam bolts.
 Attach Legs (P7, P9) to Left Side Panel (P2), then tighten the cam nuts.


This is how a cam nut works.....



The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.

Step 3

You will need	
	
4 x Dowels (H1)	6 x Cam Nuts (H4)
	
Flat head screwdriver	






Insert 4 x Dowels (H1) into the holes of Right Side Panel (P3).
 Insert 6 x Cam Nuts (H4) into the holes of Right Side Panel (P3).
 Rotate the cam nuts so the arrows point towards the incoming cam bolts.
 Attach Legs (P8, P10) to Right Side Panel (P3), then tighten the cam nuts.

www.fantasticfurniture.com.au

Step 4


You will need	
3 x CL Runner Tracks (H6)	3 x CR Runner Tracks (H7)
18 x Small Screws (H5)	Phillips head screwdriver



Attach 3 x CL Runner Tracks (H6) to Left Side Panel (P2) with 9 x Small Screws (H5).
 Attach 3 x CR Runner Tracks (H7) to Right Side Panel (P3) with 9 x Small Screws (H5).

Step 5


You will need	
8 x Cam Bolts (H3)	Phillips head screwdriver



Attach 8 x Cam Bolts (H3) into Side Panels (P2, P3) and Legs (P7, P8, P9, P10).

Step 6


You will need	
2 x CL Runner Tracks (H6)	2 x CR Runner Tracks (H7)
12 x Small Screws (H5)	Phillips head screwdriver



Attach 1 x CL Runner Track (H6) to Divider (P4) with 3 x Small Screws (H5). Turn Divider (P4) over to the other side, then attach 1 x CR Runner Track (H7) with 3 x Small Screws (H5). Repeat Step 6 for the other Divider (P4).

Step 7


You will need	
2 x Cam Bolts (H3)	8 x Long Screws (H12)
Phillips head screwdriver	



Attach Rails (P5) to Dividers (P4) with 8 x Long Screws (H12). Insert 2 x Cam Bolts (H3) into the holes of Rails (P5).

Step 8

You will need	
2 x CL Runner Tracks (H6)	2 x CR Runner Tracks (H7)
12 x Small Screws (H5)	Phillips head screwdriver



Attach 2 x CL Runner Tracks (H6) to Divider (P6) with 6 x Small Screws (H5). Turn Divider (P6) over to the other side, then attach 2 x CR Runner Tracks (H7) with 6 x Small Screws (H5).


Step 9

You will need	
	
2 x Wooden Screws M4 x 40mm (H17)	Phillips head screwdriver

TWO PEOPLE



REQUIRED



Attach Rails (P11, P12) to Divider (P6) with 2 x Wooden Screws (H17) using a Phillips head screwdriver.


Step 10

You will need	
	
2 x Dowels (H1)	2 x Cam Nuts (H4)
	
Flat head screwdriver	

TWO PEOPLE



REQUIRED




Insert 2 x Dowels (H1) into the holes of Rails (P5).
 Insert 2 x Cam Nuts (H4) into the holes of Divider (P6).
 Rotate the cam nuts so the arrows point towards the incoming cam bolts.
 Push Rails (P5) into place and tighten the cam nuts.

www.fantasticfurniture.com.au

Step 11

You will need	
	
4 x Dowels (H1)	4 x Cam Nuts (H4)
	
Flat head screwdriver	Hammer



Insert 4 x Dowels (H1) into Rails (P5, P11, P12).


Insert 4 x Cam Nuts (H4) into the holes of Rails (P5, P11, P12).

Rotate the cam nuts so the arrows point towards the incoming cam bolts.

Attach Left Side Panel (P2) with Rails (P5, P11, P12) securely, and tighten the cam nuts.

Step 12

You will need	
	
4 x Dowels (H1)	4 x Cam Nuts (H4)
	
6 x Plastic Glides (H2)	Flat head screwdriver
	
Hammer	



Insert 4 x Dowels (H1) into Rails (P5, P11, P12).


Insert 4 x Cam Nuts (H4) into the holes of Rails (P5, P11, P12).

Rotate the cam nuts so the arrows point towards the incoming cam bolts.


Attach Right Side Panel (P2) with Rails (P5, P11, P12) securely and tighten the cam nuts.

Attach 6 x Plastic Glides (H2) on Legs (P7, P8, P9, P10) and Divider (P6) with a Hammer.

Step 13



TWO PEOPLE




REQUIRED

Carefully turn the cabinet over to an upright position.
Slide Back Panels (P13) in through the grooves of Legs (P9, P10) and Rail (P12).

Step 14

You will need	
	
10 x Cam Bolts (H3)	Phillips head screwdriver




Attach 10 x Cam Bolts (H3) into Top Panel (P1) as shown.

www.fantasticfurniture.com.au

Step 15


You will need	
	
12 x Dowels (H1)	



Insert 12 x Dowels (H1) into Side Panels (P2, P3), Dividers (P4) and Legs (P7, P8, P9, P10) as shown.

Step 16

You will need	
	
10 x Cam Nuts (H4)	Flat head screwdriver



TWO PEOPLE





Insert 10 x Cam Nuts (H4) into the holes of Side Panels (P2, P3), Dividers (P4) and Legs (P7, P8, P9, P10). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Attach Top Panel (P1) to the frame and then tighten the cam nuts using a Flat head screwdriver.

www.fantasticfurniture.com.au

Step 17


You will need	
	
4 x Wedges (H15)	4 x Screws (H16)
	
Phillips head screwdriver	



Secure Back Panel (P13) in place with 4 x Wedges (H15) using 4 x Screws (H16).

Step 18


You will need	
	
4 x Small Cam Bolts (H10)	Phillips head screwdriver



Screw 4 x Small Cam Bolts (H10) into Smaller Drawer Front (P14) with a Phillips head screwdriver.

Step 19


You will need	
	
4 x Small Cam Nuts (H11)	Flat head screwdriver



Insert 4 x Small Cam Nuts (H11) into the holes of Drawer Sides (P17, P18). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Attach Drawer Sides (P17, P18) with Smaller Drawer Front (P14), and then tighten the cam nuts.

www.fantasticfurniture.com.au


Step 20



Slide Smaller Drawer Base (P19) in through the grooves of Drawer Sides (P17, P18).

Step 21



You will need	
	
4 x Long Screws(H12)	Phillips head screwdriver



Attach Smaller Drawer Back (P20) to Drawer Sides (P17, P18) with 4 x Long Screws (H12), make sure that the grooves line up the whole way around the drawer. Tighten Screws using a Phillips head screwdriver.

Step 22


You will need	
	
1 x DL Runner (H8)	1 x DR Runner (H9)
	
4 x Small Screws (H5)	Phillips head screwdriver



Attach 1 x DL Runner (H8) to the bottom of Left Drawer Side (P17) and 1 x DR Runner (H9) to the bottom of Right Drawer Side (P18) with 4 x Small Screws (H5). Tighten Screws using a Phillips head screwdriver.


Step 23

You will need	
	
1 x Handle (H13)	2 x Round Head Bolts (H14)
	
Phillips head screwdriver	



Attach 1 x Handle (H13) to Smaller Drawer Front (P14) with 2 x Round Head Bolts (H14). Tighten Round Head Bolts using a Phillips head screwdriver.


Step 24



Repeat Step 18 to Step 23 with Smaller Drawer Fronts (P15, P16) to assemble the other 2 smaller drawers.

Step 25


You will need	
	
4 x Small Cam Bolts (H10)	Phillips head screwdriver



Insert 4 x Small Cam Bolts (H10) into Larger Drawer Front (P21).


Step 26

You will need	
	
4 x Small Cam Nuts (H11)	Flat head screwdriver



Insert 4 x Small Cam Nuts (H11) into the holes of Drawer Sides (P17, P18). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Attach Drawer Sides (P17, P18) with Larger Drawer Front (P21), and then tighten the cam nuts.


Step 27



Slide Larger Drawer Base (P23) in through the grooves of Drawer Sides (P17, P18).


Step 28


You will need	
	
4 x Long Screws (H12)	Phillips head screwdriver



Attach Larger Drawer Back (P24) to Drawer Sides (P17, P18) with 4 x Long Screws (H12), make sure that the grooves line up the whole way around the drawer. Tighten Screws using a Phillips head screwdriver.

Step 29


You will need	
	
1 x DL Runner (H8)	1 x DR Runner (H9)
	
4 x Small Screws (H5)	Phillips head screwdriver



Attach 1 x DL Runner (H8) to the bottom of Left Drawer Side (P17) and 1 x DR Runner (H9) to the bottom of Right Drawer Side (P18) with 4 x Small Screws (H5). Tighten Screws using a Phillips head screwdriver.


Step 30

You will need	
	
1 x Handle (H13)	2 x Round Head Bolts (H14)
	
Phillips head screwdriver	





Attach 1 x Handle (H13) to Larger Drawer Front (P21) with 2 x Round Head Bolts (H14). Tighten Round Head Bolts using a Phillips head screwdriver.

Step 31



Repeat Step 25 to Step 30 with Larger Drawer Fronts (P21, P22) to assemble the other 3 larger drawers.

Step 32





Slide 7 x drawers into the Dresser as shown.

Step 33

We strongly advise that you use the wall safety strap provided to prevent the unit toppling

You will need	
1 x Safety Strap (H19)	1 x Screw (H20)
1 x Washer (H18)	Phillips head screwdriver





Use Screw (H20) and Washer (H18) to attach Safety Strap (H19) securely on Top Panel (P1) as shown.

www.fantasticfurniture.com.au


Step 34

Seek advice from a qualified trades person on how to attach this safety strap to your specific wall.

You will need	
	
1 x Washer (H18)	Phillips head screwdriver
Screw and Wall Plug which are not provided. Please use appropriate fixtures for your wall.	



Move the dresser to the final position, and attach the safety strap to the wall securely. Make sure it is firmly attached and snug fit.



Recommended weight capacity : 80KG.


Recommended weight capacity of drawer: 18KG/drawer.

Job Complete!


In the interest of our environment please dispose of all packaging thoughtfully.



Version 1.0



TWO PEOPLE



REQUIRED

HAVANA

Bed Queen (Frame Only)

www.fantasticfurniture.com.au

Enjoy


Your purchase from
Australia's Best Value Furniture Store




Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.

What you need

to assemble the product




DO NOT USE



Additional Tools Required

Flat head screwdriver;
Phillips head screwdriver;
Hammer



Parts list


Box 1: Bedhead (P1);
Bedfoot (P2);

Box 2: 2 x Side Covers (P3);
2 x Side Rails (P4);
Centre Rail (P5);
2 x Support Legs (P6);


28 x End Connectors



14 x Centre Connectors



28 x Fantastic Furniture
ComfortSlats™ Queen



Hardware pack



16 x Dowels
(H1)



4 x Screws
(H2)



12 x Cam Bolts
(H3)



12 x Cam Nuts
(H4)



8 x Half Round
Nuts
(H5)



8 x Threaded Rod
(H6)



8 x Hexagonal
Nuts
(H7)



1 x Spanner
(H8)



4 x Plastic
Glides
(H9)




2 x Long Bolts
(H10)



1 x Allen Key
(H11)

Step 1


You will need	
	
6 x Dowels (H1)	4 x Threaded Rod (H6)
	
2 x Plastic Glides (H9)	Hammer



Insert 6 x Dowels (H1) into Bedhead (P1).
 Attach 4 x Threaded Rod (H6) into Bedhead (P1).
 Hammer 2 x Plastic Glides (H9) onto the bottom of Bedhead (P1).

Step 2


You will need	
	
6 x Dowels (H1)	4 x Threaded Rod (H6)
	
2 x Plastic Glides (H9)	Hammer




Insert 6 x Dowels (H1) into Bedfoot (P2).
 Attach 4 x Threaded Rod (H6) into Bedfoot (P2).
 Hammer 2 x Plastic Glides (H9) onto the bottom of Bedfoot (P2).

Step 3

You will need	
	
4 x Dowels (H1)	12 x Cam Bolts (H3)
	
12 x Cam Nuts (H4)	Phillips head screwdriver
	
Flat head screwdriver	



This is how a cam nut works.....




The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.

Insert 2 x Dowels (H1) into Side Cover (P3).
 Attach 6 x Cam Bolts (H3) into Side Cover (P3).
 Insert 6 x Cam Nuts (H4) into the holes of Side Rail (P4).
 Rotate the cam nuts so the arrows point towards the incoming cam bolts.
 Attach Side Cover (P3) to Side Rail (P4), then tighten the cam nuts.
 Repeat Step 3 for the other Side Cover (P3) and Side Rail (P4).


Step 4


You will need	
	
4 x Half Round Nuts (H5)	4 x Hexagonal Nuts (H7)
	
1 x Spanner (H8)	



Attach Bedfoot (P2) to Side Covers (P3) and Side Rails (P4) with 4 x Half Round Nuts (H5) and 4 x Hexagonal Nuts (H7) using Spanner (H8).

Step 5

You will need	
	
4 x Half Round Nuts (H5)	4 x Hexagonal Nuts (H7)
	
1 x Spanner (H8)	




TWO PEOPLE



Attach Bedhead (P1) to Side Covers (P3) and Side Rails (P4) with 4 x Half Round Nuts (H5), and 4 x Hexagonal Nuts (H7) using Spanner (H8).

Step 6


You will need	
	
2 x Long Bolts (H10)	1 x Allen Key (H11)



Attach 2 x Support Legs (P6) to Centre Rail (P5) with 2 x Long Bolts (H10) using Allen Key (H11).

Step 7

You will need	
	
4 x Screws (H2)	Phillips head screwdriver




Attach Centre Rail (P5) to Bedhead (P1) and Bedfoot (P2) as shown. Then screw Centre Rail (P5) with 4 x Screws (H2).


Step 8

You will need	
	
28 x End Connectors	14 x Centre Connectors
	
28 x Fantastic Furniture ComfortSlats™ Double	

HOW TO FIT YOUR COMFORT SLATS




Push 2 End Connectors, 2 Fantastic Furniture ComfortSlats™ Queen and a Centre Connector together.




Insert the full slat into the side rail and centre rail one by one.

3




Sometimes it makes it easier to line up the hole if you press down in the middle of the slat to flatten it out.

4



Repeat for every bed slat until finished.



Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.