




**Fantastic
Furniture**

Version 1.0



Two People



Required

Casa

Single bed

fantasticfurniture.com.au

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love!

WARNING: When moving the bed, lift it from the base
before placing into position. Do not drag the bed.

CAUTION: DO NOT PLAY ON, OR HANG HEAVY
OBJECTS ON ROOF BARS.

Hanging objects on, or playing on the roof bars can
cause the bars to break and may result in injury.



Fantastic Furniture

Love it? Share it!


Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!

@fantasticfurniture


Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.

! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.

! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.

! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used as they may not fit through a door once assembled.

! Never use any glue until you are certain that the parts belong together.

! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.

! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.

! Please see page 2 for any safety requirements or weight restrictions.

What you need

to assemble the product




DO NOT USE



(Tool not provided)
soft head mallet



(Tool not provided)
Phillip head screwdriver




Parts List:

Side posts (P3 & P4)

Slats (P9)

Rails (P1, P2, P5, P6, P7 & P8)

Hardware pack




8 x Steel
Dowels
(H1)



16 x Short Bolts
(H2)




8 x Screws
(H3)




6 x Long Bolts
(H4)



6 x Barrel Nuts
(H5)




22 x Wooden
Dowels
(H6)



8 x Locking
Pins (H7)



1 x Spanner
(H8)



1 x Allen Key
(H9)



22 x Flat Washers
(H10)



8 x Halfmoon Nuts
(H11)



8 x Hex Nuts
(H12)



8 x Locking Lids
(H13)



22 x Spring
Washers
(H14)

Please make sure you have all these parts before you start



Step 1


You will need			
4 x Steel Dowels (H1)		8 x Flat Washers (H10)	
8 x Short Bolts (H2)		1 x Allen Key (H9)	
8 x Spring Washers (H14)			

Fixing Kit: How to screw into a steel dowel?

Make sure the opening of steel dowels face the incoming bolts.


Screw one bolt into the dowel, keep it loose, then screw another bolt.


Screw both sides until tight.



To attach the rails (P1) and (P2) together, insert 2 x steel dowels (H1) into the rails (P1 & P2). Ensure the steel dowels (H1) face the incoming bolts. Insert the 4 x short bolts (H2), the 4 x spring washers (H14) and 4 x flat washers (H10), then tighten with the allen key as shown. Repeat for the other set of panels (P1) & (P2).

Step 2


You will need			
4 x Locking Pins (H7)		1 x Spanner (H8)	
4 x Halfmoon Nuts (H11)		8 x Wooden Dowels (H6)	
4 x Hex Nuts (H12)			



Insert 4 x wooden dowels (H6) into the side posts (P3 & P4) by hand or using a soft head mallet. Screw in 2 x locking pins (H7) into the side posts (P3 & P4) by rotating clockwise. Align the holes of the rail (P5) to the dowels (H6) and locking pins (H7) in the legs (P3 & P4). Attach the rail (P5) to the side posts (P3 & P4) by putting 2 x halfmoon nuts (H11) and 2 x hex nuts (H12) onto the 2 x locking pins (H7) as shown. Tighten the 2 x hex nuts (H12) with a spanner (H8).

Step 3

You will need			
4 x Steel Dowels (H1)		8 x Flat Washers (H10)	
8 x Short Bolts (H2)		1 x Allen Key (H9)	
8 x Spring Washers (H14)			



Insert 2 x steel dowels (H1) into the holes of the side posts (P3 & P4) as shown. Align panels (P1) and (P2) to the steel dowels (H1), ensuring the steel dowels (H1) face the incoming bolts (H2). Insert the short bolts (H2), the spring washers (H14) and the flat washers (H10), and tighten with the allen key (H9) as shown. Repeat for the other set of panels (P1 & P2) and (P3, P4 & P5).


Step 4

Two People



Required

You will need	
2 x Locking Pins (H7)	
4 x Wooden Dowels (H6)	



Insert 4 x wooden dowels (H6) into the side posts (P3 & P4) by hand or using a soft head mallet. Screw in 2 x locking pins (H7) into the side posts (P3 & P4) by rotating clockwise. To attach the side rails (P6) to the side posts (P3 & P4), align the holes of the rails (P6) to the dowel (H6) and locking pins (H7) in the side post (P3 & P4).



Fantastic Furniture

Page 8


Step 5

Two People



Required

You will need	
2 x Halfmoon Nuts (H11)	
2 x Hex Nuts (H12)	
1 x Spanner (H8)	



Attach the rail (P5) to the side posts (P3 & P4) by putting 2 x halfmoon nuts (H11) and 2 x hex nuts (H12) onto the 2 x locking pins (H7) as shown.

Tighten the 2 x hex nuts (H12) with a spanner (H8), but do not fully tighten.



Fantastic Furniture

Page 9


Step 6

Two People



Required


2 x Locking Pins (H7)		2 x Halfmoon Nuts (H11)	
4 x Wooden Dowels (H6)		2 x Hex Nuts (H12)	
1 x Spanner (H8)			



Repeat Steps 4 & 5 for the other end of the bed.
Then tighten all 4 x hex nuts (H12) with the spanner (H8).

Step 7


You will need	
6 x Wooden Dowels (H6)	



Insert 6 x wooden dowels into the holes on all panels (P1), (P2), (P3), (P4).


Step 8

Two People



Required

You will need			
4 x Long Bolts (H4)		4 x Flat Washers (H10)	
4 x Barrel Nuts (H5)		1 x Allen Key (H9)	
4 x Spring Washers (H14)			



Align a top side rail (P7) to each of the dowels at the top of side posts (P3 & P4). As you align each top side rail, you may need to gently bow the frame slightly at the top to attach the rails to the dowels. To ensure each rail stays in place while you do this, insert 4 x barrel nuts (H5) into the top side rails (P7). Ensure the openings of the barrel nuts face the incoming bolts. Then loosely secure the top side rails in place with 2 x long bolts (H4), 2 x flat washers (H10) and 2 x spring washers (H14) with the allen key (H9) before moving to attach to the other top side rail (P7).




Step 9

You will need	
2 x Long Bolts (H4)	
2 x Flat Washers (H10)	
2 x Spring Washers (H14)	
2 x Barrel Nuts (H5)	
1 x Allen Key (H9)	

Two People



Required



Align the top rail (P8) to the dowels on both panels (P1).


As you align the top rail, you may need to gently bow the frame slightly at the top to attach the rail to the dowels. Push the frame together so the dowels and top rails are connected. To ensure the rail stays in place while you do this, insert 2 x barrel nuts (H5) into the top rail (P8). Ensure the openings of the barrel nuts face the incoming bolts. Then loosely secure the top rail in place with 2 x long bolts (H4), 2 x flat washers (H10) and 2 x spring washers (H14) with the allen key (H9).




Step 10

You will need	
1 x Allen Key (H9)	

Two People




Required



Tighten all long bolts (H4) with the allen key (H9)

Step 11

You will need:	
8 x Locking Lids (H13)	



Cover the 8 holes in the side rails and end (P6 & P5) by using the 8 x locking lids (H13).


Step 12

Two People



Required

You will need	
8 x Wood Screws (H3)	



Place end slat of (P9) elastic side down on the side rail ledge, between the wooden blocks and end panel (P5).


Lay out slats along the bed.

Stretch the slats and place the other end slat between the other wooden blocks and the other end panel (P5)

Fix the slats to the support rails with 8 x screws and a phillips head screw driver as shown.



Step 13



Job Complete!

In the interest of our environment
please dispose of all packing thoughtfully.

