




**Fantastic
Furniture**

Version 1.0



Havana
Lowline Medium

fantasticfurniture.com.au

Recommended weight capacity : 80kg.

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love!



Fantastic Furniture

Love it? Share it!


Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!

@fantasticfurniture


Assembly Checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools.
Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What you need

to assemble the product



DO NOT USE




Other tools you need:


Phillips Head Screwdriver;
Hammer

Parts list



Top Panel (P1);
Bottom Panel (P2); Left Divider (P3);
Right Divider (P4);
Side Panel (P5); Shelf Panel (P6);
LF Leg (P7); RF Leg (P8); LR Leg (P9);
RR Leg (P10); Back Panel (P11);
Support Leg (P12);
Left Door (P13); Right Door (P14);




Hardware pack





Step 1


You will need	
	
18 x Cam Bolts (H3)	Phillips Head Screwdriver



Attach 10 x Cam Bolts (H3) into Top Panel (P1).
Attach 8 x Cam Bolts (H3) into Legs (P7,P8,P9,P10).
Tighten Cam Bolts using a Phillips Head Screwdriver




Step 2


You will need	
	
4 x Cam Bolts (H3)	Phillips Head Screwdriver



Attach 2 x Cam Bolts (H3) into Dividers (P3) using a Phillips Head Screwdriver.
Repeat Step 2 for Right Divider (P4).




Step 3



You will need	
	
4 x Small Dowels (H2)	4 x Cam Nuts (H4)
	
Phillips Head Screwdriver	



Insert 4 x Small Dowels (H2) and 4 x Cam Nuts (H4) into Shelf Panel (P6) as shown.
Rotate the cam nuts so the arrows point towards the incoming cam bolts.
Attach Dividers (P3, P4) to Shelf Panel (P6),
then tighten the cam nuts using a Phillips Head Screwdriver.



Step 4


You will need	
	
4 x Dowels (H1)	2 x Cam Nuts (H4)
	
Phillips Head Screwdriver	



Insert 4 x Dowels (H1) into Bottom Panel (P2).
 Insert 2 x Cam Nuts (H4) into the holes of Bottom Panel (P2) as shown.
 Rotate the cam nuts so the arrows point towards the incoming cam bolts.
 Attach Legs (P9, P10) to Bottom Panel (P2),
 then tighten the cam nuts using a Phillips Head Screwdriver.




Step 5


You will need	
	
4 x Cam Nuts (H4)	Phillips Head Screwdriver



Insert 4 x Cam Nuts (H4) into Side Panels (P5).
 Rotate the cam nuts so the arrows point towards the incoming cam bolts.
 Attach Side Panels (P5) to Legs (P9, P10),
 then tighten the cam nuts using a Phillips Head Screwdriver.

Step 6

You will need	
	
4 x Dowels (H1)	2 x Cam Nuts (H4)
	
Phillips Head Screwdriver	






Insert 4 x Dowels (H1) into Bottom Panel (P2).

Insert 2 x Cam Nuts (H4) into the holes of Bottom Panel (P2) as shown.


Rotate the cam nuts so the arrows point towards the incoming cam bolts.

Attach Legs (P7, P8) to Side Panels (P5), then tighten the cam nuts using a Phillips Head Screwdriver.

Step 7

You will need	
	
4 x Small Dowels (H2)	4 x Inside Hexagonal Screws (H11)
	
1 x Allen Key (H12)	

Make sure PVC banding is facing up.




Insert 4 x Small Dowels (H2) into Dividers (P3, P4).

Attach Dividers (P3, P4) to Bottom Panel (P2) with


4 x Inside Hexagonal Screws (H11) using Allen Key (H12).


Step 8



Slide Back Panel (P11) into the groove in Legs (P9,P10) and Bottom Panel (P2).




Step 9


You will need	
	
8 x Dowels (H1)	



Insert 8 x Dowels (H1) into Legs (P7, P8, P9, P10).






Step 10


You will need	
	
8 x Small Dowels (H2)	10 x Cam Nuts (H4)
	
Phillips Head Screwdriver	



Insert 8 x Small Dowels (H2) into Dividers (P3, P4) and Side Panels (P5).
 Insert 10 x Cam Nuts (H4) into the holes of Dividers (P3, P4) and Legs (P7, P8, P9, P10).
 Rotate the cam nuts so the arrows point towards the incoming cam bolts.
 Attach Top Panel (P1) and tighten the cam nuts using a Phillips Head Screwdriver.






Step 11


You will need	
	
1 x Double Ended Screws (H10)	2 x Inside Hexagonal Screws (H11)
	
1 x Allen Key (H12)	5 x Plastic Glides (H5)
	
Hammer	



Screw 2 x Inside Hexagonal Screws (H11) to Bottom Panel (P2) with Allen Key (H12). Attach Support Leg (P12) to Bottom Panel (P2) with 1 x Double Ended Screws (H10), then hammer 5 x Plastic Glides (H5) on Legs (P7, P8, P9, P10) and Support Leg (P12).




Step 12


You will need	
	
4 x Hinges (H6)	8 x Timber Screws (H7)
	
2 x Handles (H8)	4 x Round Head Bolts (H9)
	
Phillips Head Screwdriver	



Attach 2 x Hinges (H6) to Left Door (P13) with 4 x Timber Screws (H7). Attach 1 x Handles (H8) to Left Door (P13) with 2 x Round Head Bolts (H9). Tighten Screws and Bolts using a Phillips Head Screwdriver. Repeat Step 12 for Right Door (P14).


Step 13

You will need	
	
16 x Timber Screws (H7)	2 x Rubber Stickers (H13)
	
Phillips Head Screwdriver	



Attach Left Door (P13) to LF Leg (P7) and Right Door (P14) to RF Leg (P8) with 16 x Timber Screws (H7).
Tighten Screws using a Phillips Head Screwdriver.
Stick 2 x Rubber Stickers (H13) to Dividers (P3, P4) as shown.

Step 14




Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.

TO ADJUST YOUR DOORS TO MAKE THE GAPS MORE EVEN


STEP 1

Open the door.




STEP 2

Adjust the door move in or out a little




Loosen the screw indicated a little, adjust the hinge to right position (see step 2a & 2b), then tighten screw.

STEP 2a MOVE DOOR IN



Push the hinge back a little.


STEP 2b MOVE DOOR OUT



Pull the hinge forward a little.


STEP 3

To adjust the gap between door and leg




Loosen or tighten the screw indicated a little to adjust the gap between door and leg (see step 3a & step 3b)

STEP 3a MOVE DOOR RIGHT



Turn the screw clockwise a little as shown to make the gap big.

STEP 3b MOVE DOOR LEFT



Turn the screw counterclockwise a little as shown to make the gap small.