


APPROVED LP 15/05/2020




**Fantastic  
Furniture**

Version 1.0



TWO PEOPLE



REQUIRED

# Verona

Lift Up Coffee Table White

[fantasticfurniture.com.au](http://fantasticfurniture.com.au)



**CAUTION: ALWAYS ENSURE YOUR HANDS ARE CLEAR OF THE HINGE MECHANISM WHEN IN USE TO AVOID INJURY.**

Children should only operate the mechanism under adult supervision. The mechanism should always be in the closed position when not in use.

Looks like you've found  
your Fantastic!

We're thrilled you've chosen Fantastic Furniture  
to help create a home you'll love!




**Fantastic  
Furniture**


**Love it? Share it!**

Fantastic buy! Share how it looks at home on Instagram for  
your chance to win a \$250 Fantastic Furniture Gift Card!  
[@fantasticfurniture](#)


# Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

## Useful information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.



**Fantastic  
Furniture**


# What you need to assemble the product














Other tools you need  
Phillips Head Screwdriver;  
Mallet

## Parts List




Top Panel (P1);  
2 x Side Panels (P2);  
Left Inside Support Panel (P3);  
Right Inside Support Panel (P4);  
2 x Back Panels (P5);  
2 x Bottom Support Panels (P6);  
Bottom Support Panel (P7);  
Bottom Panel (P8);  
Left Machine (P9);  
Right Machine (P10);  
2 x Connect Tubes (P11);




## Hardware List

							
24 x Large Cam Bolts (H1)	24 x Large Cam Nuts (H2)	4 x Wooden Dowels (H3)	4 x Bolts 20mm (H4)	6 x Bolts 35mm (H5)	10 x Screws 16mm (H6)	8 x Covers (H7)	4 x Protective Foam (H8)
							
4 x Washers (H9)	1 x Allen Key (H10)	8 x Bolts 25mm (H11)					





# Step 1


You will need	
	
12 x Large Cam Bolts (H1)	4 x Protective Foam (H8)
	
Phillips Head Screwdriver	



Use a phillips head screwdriver to insert the 12 x large cam bolts (H1) into 2 x side panels (P2), stick the 4 x protective foams (H8) onto the bottom of 2 x side panels (P2).



# Step 2


You will need	
	
12 x Large Cam Bolts (H1)	4 x Wooden Dowels (H3)
	
Phillips Head Screwdriver	Mallet




Use a phillips head screwdriver to insert the 12 x large cam bolts (H1) into the 2 x back panels (P5). If needed use mallet to insert the 4 x wooden dowels (H3) into the sides of the 2 x back panels (P5).

## Step 3


You will need	
	
12 x Large Cam Nuts (H2)	Phillips Head Screwdriver



This is how a cam nut works.....




The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.



Position the bottom support panels (P6,P7) to the 2 x back panels (P5). Insert 12 x large cam nuts (H2) into the holes on the bottom support panels (P6,P7) as shown. Make sure the opening on cam nut is facing incoming cam bolts. Using a phillips head screwdriver turn clockwise to lock.




## Step 4





Insert the bottom panel (P8) into the grooves of the 2 x back panels (P5).




## Step 5

You will need	
	
12 x Large Cam Nuts (H2)	Phillips Head Screwdriver
	
8 x Covers (H7)	




This is how a cam nut works.....




The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.

Align the 2 x side panels (P2) to the back panels (P5) and bottom support panels (P6,P7) , Insert 12 x large cam nuts (H2) into the holes on panels (P5,P6) as shown. Make sure the opening on cam nut is facing incoming cam bolts. Using a phillips head screwdriver turn clockwise to lock. Place the 8 x covers (H7) onto the large cam nuts (H2) which are on the 2 x back panels (P5).



## Step 6


You will need	
	
6 x Bolts 35mm (H5)	Allen Key(H10)



Make sure the front end of left and right inside support panel (P3,P4) face the same side. Use the allen key (H10) to attach the left inside support panel (P3) and right inside support panel (P4) to the 2 x side panels (P2) with 6 x bolts (H5).




## Step 7


You will need	
	
8 x Bolts 25mm (H11)	Allen Key(H10)



Use the allen key (H10) to attach the connect tubes (P11) to the left machine (P9) and right machine (P10) with 8 x bolts (H11).

## Step 8



You will need	
	
4 x Bolts 20mm (H4)	Allen Key(H10)
	
4 x Washers Ø6 (H9)	




Use the allen key (H10) to attach the left side lift machine (P9) and right side lift machine (P10) to the top panel (P1) with 4 X bolts (H4) and 4 x washers (H9).




## Step 9

You will need	
	
10 x Screws 16mm (H6)	Phillips Head Screwdriver




Use a phillips head screwdriver to attach the left machine (P9) to left inside support panel (P3), right machine (P10) to right inside support panel (P4) with 10 x screws(H6).

## Step 10




Make sure to press down the locker on left and right mechanism before closing the top panel.

## Step 11



If the gap between the top and side panel is not even, please adjust the screw as shown on bracket under top panel accordingly.

## Step 12



# Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.