


Version 1.0









Warning: Ensure the wall strap is attached to avoid serious injury

To avoid any serious or fatal injury, a wall strap has been provided with this product to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Fixing devices are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.

Rattan

Rattan is a natural material that will respond to humidity in the environment. Low humidity may cause the rattan to shrink. High humidity may cause the rattan to absorb moisture and expand, causing the weaving to look loose and wavy.

This is a natural phenomenon and not a defect.

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture to help create a home you'll love!



Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for your chance to win a \$250 Fantastic Furniture Gift Card!


@fantasticfurniture



Assembly Checklist



Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.


What you need

to assemble the product



Other tools you need

Flat Head Screwdriver; Phillips Head Screwdriver; Mallet





Parts list


- 1 x Top Panel (P1)
- 1 x Bottom Panel (P2)
- 2 x Side Panels (P3)
- 1 x Back Panel (P4)
- 1 x Drawer Front (P5)
- 1 x Drawer Left Side (P6)
- 1 x Drawer Right Side (P7)
- 1 x Drawer Back (P8)
- 1 x Drawer Base (P9)
- 4 x Legs (P10)



Hardware Pack









Attach 1 x felt foot (H5) onto each leg (P10) as shown.

Step 2






Attach 1 x leg (P10) onto bottom panel (P2), using 2 x bolts (H8), 2 x flat washers (H9) and 2 x spring washers (H10).

Tighten the bolts with allen key (H12).


Repeat this step for the other 3 x legs (P10).


Turn the assembled unit over.

Step 3




Screw 4 x cam bolts (H1) into bottom panel (P2), using a phillips head screwdriver.





Separate the 2 x slide runners (H19-2) and slide tracks (H19-1) from the slides (H19) by following the steps below: Extend the slide runner (H19-2) all the way out. Press down the plastic release lever on the slide and pull out




Adjust runner to access the screw holes.

H19-1


Please fasten the screws through these holes for this step.

H19-1



Attach 2 \times separated slide tracks (H19-1) onto 2 \times side panels (P3) with 6 \times screws (H18), using a phillips head screwdriver as shown.

Ensure the slide tracks (H19-1) are attached so the rubber stopper is near the gooves on the panels.





Position the $2 \times \text{side}$ panels (P3) onto bottom panel (P2), making sure the grooves on side panels and bottom panel are on the same side.


Insert 4 x large cam nuts (H2) into side panels (P3). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Using a flat head screwdriver, turn clockwise to lock.

Step 6

Slide back panel (P4) into the grooves of the side panels and bottom panel (P3, P2).









Screw 4 x cam bolts (H1) into top panel (P1), using a phillips head screwdriver.

Step 8







Position top panel (P1) onto assembled unit as shown.

Insert 4 x large cam nuts (H2) into panels (P3).

Rotate the cam nuts so the arrows point towards the incoming cam bolts.


Using a flat head screwdriver, turn clockwise to lock.






to assembled unit with 4 x screws (H6) as shown, using a phillips head screwdriver.


Screw 4 x cam bolts (H1) into drawer front (P5), using a phillips head screwdriver as shown.





Insert 2 x dowels (H16) into drawer side panels (P6, P7) as shown. Use a mallet to gently tap the dowels into place if needed.

Step 12




Position drawer sides (P6, P7) onto drawer front (P5).

Insert 4 x small cam nuts (H15) into drawer sides (P6, P7).


Rotate the cam nuts so the arrows face incoming cam bolts.


Using a flat head screwdriver turn clockwise to lock.



Step 13

Slide drawer base (P9) into the grooves of panels (P5, P6, P7).







Ensure the pre-drilled holes on drawer sides (P6, P7) align with the holes on drawer back (P8).

holes P7) (P8) (P7) H17 (P6) (P5)

Attach drawer back (P8) to assembled drawer (P5, P6, P7) with 4 x screws (H17), using a phillips head screwdriver as shown.

Step 15







Please fasten the screws through

Attach 1 x slide runner (H19-2) to each drawer side (P6, P7)


with 3 x screws (H18), using a phillips head screwdriver as shown.


Step 16







Attach 1 x handle (H4) onto drawer front (P5) with 2 x screws (H11), using a phillips head screwdriver as shown.









Move inner ball bearing track to front of slide track (H19-1).





Gently insert drawer slide runner (H19-2) in between the ball bearing track.




Position drawer so that slide runners (H19-2) align with slide tracks (H19-1) as shown. Gently push drawer into the closed position.









Job complete!

In the interest of our environment please dispose of all packaging thoughtfully.