



**Fantastic
Furniture**

Version 1.0



Two People



Required

Giselle

Day Bed

fantasticfurniture.com.au

Look like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love!



Fantastic Furniture

Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!

@fantasticfurniture



**Fantastic
Furniture**

Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful information

! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.

! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.

! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.

! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used as they may not fit through a door once assembled.

! Never use any glue until you are certain that the parts belong together.

! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.

! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.


! Please see page 2 for any safety requirements or weight restrictions.

What you need

to assemble the product



DO NOT USE



Part List:

Box 1:

Back Panel (P1);

Left Panel (P2);

Right Panel (P3);

Cross Bar (P5)


26 x Plastic Slat Caps (P6);

Box 2:


2 x Side Rails (P4);

13 x Slats (P7)


Hardware pack




26 x Plastic Slat Caps
(P6)



13 x Slats
(P7)




8 x Short Bolts
(H1)



4 x Long Bolts
(H2)



1 x Allen Key
(H3)



2 x Medium Bolts
(H4)





2 x Hex Nuts
(H5)




1 x Spanner
(H6)

Please make sure you have all these parts before you start.






Step 1


You will need	
4 x Short Bolts (H1)	
1 x Allen Key (H3)	



Insert 4 x short bolts (H1) into the bottom holes of the left panel (P2) and right panel (P3) using the allen key (H3). Do not fully tighten the bolts and leave a gap of 5mm as shown.



Step 2


You will need	
4 x Short Bolts (H1)	
1 x Allen Key (H3)	
2 x Medium Bolts (H4)	
2 x Hex Nuts (H5)	
1 x Spanner (H6)	



Attach the 2 x side rails (P4) to the left panel (P2) and right panel (P3). Slot the side rails onto the bolts on the left and right panels (P2 & P3) as shown. Then insert 4 x short bolts (H1) into the top holes with the allen key (H3). Attach cross bar (P5) onto 2 x side rails (P4) using 2 x medium bolts (H4) and 2 x hex nuts (H4). Tighten with the allen key (H3) and spanner (H6) as shown.



Step 3


You will need	
4 x Long Bolts (H2)	
1 x Allen Key (H3)	



Attach the back panel (P1) to the left and right panel (P2 & P3) with 4 x long bolts (H2) using an allen key (H3). Now fully tighten all bolts.


Step 4

You will need:	
26 x Plastic Slat Caps (P6)	
13 x Flat LVL Slats (P7)	



Push 26 x plastic slat caps (P6) firmly onto 13 x slats (P6).

Step 5



Lower the slat (P7) with the end caps (P6) to the side rails (P4). Ensure the plastic caps are in place over the side rail holes and apply downward pressure until the plastic caps are fully inserted into the rails. Repeat for every bed slat until finished.

Step 6



IMPORTANT: Fully tighten all bolts on bed. Periodically check to ensure all bolts remain tight.

Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.