





**Fantastic
Furniture**

Version 1.0



Two People



Required

Java
Bed Queen

fantasticfurniture.com.au

Rattan

Rattan is a natural material that will respond to humidity in the environment. Low humidity may cause the rattan to shrink. High humidity may cause the rattan to absorb moisture and expand, causing the weaving to look loose and wavy.

This is a natural phenomenon and not a defect.

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love!



**Fantastic
Furniture**


Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram
for your chance to win a \$250 Fantastic Furniture Gift Card!
@fantasticfurniture


Assembly Checklist



Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information


- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What you need

to assemble the product




DO NOT USE



Other tools you need

Phillips Head Screwdriver;

Mallet



Part list

Carton 1:

- 2 x Side Rails (P2)
- 4 x Legs (P4)
- 4 x Brackets (P5)
- 1 x Centre Rail (P6)
- 1 x Centre Rail Support (P7)
- 3 x Support Legs (P8)
- 6 x Support Rails (P11)

Carton 2:


- 1 x Front Rail (P1)
- 1 x Footboard (P3)
- 1 x Set of Slats (P9)
- 1 x Headboard (P10).



Hardware Pack




42 x Bolts
16mm (H1)



6 x Bolts
40mm (H2)



4 x Felt Feet
(H3)



4 x Bolts
75mm (H4)




8 x Dowels
40mm (H5)



30 x Screws
25mm (H6)



12 x Small Flat
Washers (H7)




10 x Large Flat
Washers (H8)



12 x Small Spring
Washers (H9)



14 x Large Spring
Washers (H10)




12 x Bolts
65mm (H11)




14 x Large Nuts
(H12)




1 x Small
Allen Key (H13)




1 x Large Allen Key
(H14)



18 x Screws
38mm (H15)



1 x Wrench
(H16)



8 x Half Moon
Washers (H17)




4 x Bolts
70mm (H18)



12 x Dowels
20mm (H19)


Step 1


You will need	
	
12 x Dowels 20mm (H19)	Mallet



Insert 12 x dowels (H19) into headboard (P10) as shown.
If needed use a mallet to gently tap the dowels into place.

Step 2




You will need	
	
18 x Screws 38mm (H15)	Phillips Head Screwdriver



Attach 6 x support rails (P11) onto headboard (P10) with 18 x screws (H15) as shown, tightening with a phillips head screwdriver.


Step 3


You will need	
	
12 x Bolts 65mm (H11)	12 x Small Flat Washers (H7)
	
12 x Small Spring Washers (H9)	1 x Small Allen Key (H13)



With assistance, attach 6 x support rails (P11) to front rail (P1) using 12 x bolts (H11), 12 x small spring washers (H9) and 12 x small flat washers (H7). Fully tighten the bolts using small allen key (H13).

Step 4


You will need	
	
8 x Dowels 40mm (H5)	Mallet



Insert 4 x dowels (H5) into each side rail (P2) as shown.
If needed use a mallet to gently tap the dowels into place.

Step 5

You will need	
	
4 x Bolts 70mm (H18)	



Screw 4 x bolts (H18) into footboard (P3) as shown.



Step 6

You will need	
4 x Half Moon Washers (H17)	4 x Large Spring Washers (H10)
4 x Large Nuts (H12)	1 x Wrench (H16)
4 x Bolts 75mm (H4)	4 x Large Flat Washers (H8)
1 x Large Allen Key (H14)	

Two People







Required



With assistance, align 2 x side rails (P2) to the front rail (P1), ensuring the holes on the 2 x side rails (P2) are positioned towards the foot of the bed as shown. Attach side rails (P2) onto front rail (P1) using 4 x bolts (H4), 4 x large flat washers (H8), 4 x half moon washers (H17), 4 x large spring washers (H10) and 4 x large nuts (H12). Tighten with the large allen key (H14) and wrench (H16).

Step 7



You will need	
	
4 x Half Moon Washers (H17)	4 x Large Spring Washers (H10)
	
4 x Large Nuts (H12)	1 x Wrench (H16)



With assistance, attach footboard (P3) to 2 x side rails (P2) using 4 x half moon washers (H17), 4 x large spring washers (H10) and 4 x large nuts (H12) as shown. Tighten nuts (H12) using wrench (H16).

Step 8



You will need	
	
12 x Bolts 16mm (H1)	1 x Small Allen Key (H13)
	
4 x Felt Feet (H3)	



Attach 1 x felt foot (H3) onto each leg (P4) as shown.
Attach bracket (P5) onto 4 x legs (P4) with 12 x bolts (H1) as shown.
Tighten using the small allen key (H13).

Step 9


You will need	
	
24 x Bolts 16mm (H1)	1 x Small Allen Key (H13)



With assistance, carefully turn over the bed frame onto its side.
Attach 4 x brackets (P5) onto bed frame with 24 x bolts (H1) as shown.
Tighten using the small allen key (H13).

Step 10

You will need	
	
6 x Bolts 40mm (H2)	1 x Large Allen Key (H14)
	
6 x Large Flat Washers (H8)	1 x Wrench (H16)
	
6 x Large Spring Washers (H10)	6 x Large Nuts (H12)
	
2 x Bolts 16mm (H1)	



Attach 3 x support legs (P8) onto centre rail (P6) with 2 x bolts (H2), 2 x large spring washers (H10), 2 x large flat washers (H8) and 2 x large nuts (H11) as shown. Tighten using the large allen key (H14) and wrench (H16). Attach centre rail support (P7) onto centre rail (P6) with 1 x bolt (H1), and tighten using the small allen key (H13).


Step 11

Two People



Required

You will need	
	
5 x Bolts 16mm (H1)	1 x Small Allen Key (H13)




With assistance, carefully turn the bed over onto its feet.

Attach centre rail (P6) and centre rail support (P7) to front rail (P1) using 3 x bolts (H1), tightening with the small allen key (H13).

Attach centre rail (P6) to footboard (P3) using 2 x bolts (H1), tightening with the small allen key (H13).



Step 12

Two People




Required

You will need	
	
30 x Screws 25mm (H6)	Phillips Head Screwdriver



Attach set of slats (P9) onto bed frame with 30 x screws (H6) using a phillips head screwdriver as shown. If required, you may need to slightly push in the 2 x side rails (P2) when attaching screws to ensure the gap between the slats (P9) and side rails (P2) are even.

Step 13



Job complete!

In the interest of our environment please dispose
of all packaging thoughtfully.