


APPROVED LP 15/05/2020




**Fantastic
Furniture**

Version 1.0



TWO PEOPLE



REQUIRED

Verona

Console Table 2 Drw White


fantasticfurniture.com.au

**WARNING: ENSURE THE WALL STRAP IS
ATTACHED TO AVOID SERIOUS INJURY.**

To avoid any serious or fatal injury, this product has been provided with a wall strap to prevent toppling. We strongly recommend that this product is permanently fixed to the wall or other suitable surface. Fixing devices are not included since different surface materials require different attachments. Please seek professional advice if you are in doubt of what fixing device to use.

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love!




Fantastic Furniture


Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!
[@fantasticfurniture](https://www.instagram.com/fantasticfurniture)


Assembly checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.



**Fantastic
Furniture**


What you need to assemble the product



DO NOT USE




Other tools you need
Phillips Head Screwdriver;
Mallet








Parts List


Top Panel (P1);
Bottom Panel (P2);
Left Side Panel (P3);
Right Side Panel (P4);
Back Rail (P5);
Middle Side Panel (P6);
Back Panel (P7);
Drawer Front Panel (P8);
Drawer Front Panel (P9);
2 x Drawer Left Side Panels (P10);
2 x Drawer Right Side Panels (P11);
2 x Drawer Bottom Panels (P12);
2 x Drawer Back Panels (P13);

Hardware List










Step 1

You will need	
	
12 x Large Cam Bolts (H1)	8 x Wooden Dowels (H3)
	
3 x Screws 20mm (H11)	Mallet
	
Phillips Head Screwdriver	




Using a mallet if needed, insert 8 x wooden dowels (H3) into the back panel (P7) and bottom panel (P2). Screw 10 x large cam bolts (H1) into the top panel (P1). Screw 1 x large cam bolt (H1) into the back panel (P7). Screw 1 x large cam bolt (H1) into the bottom panel (P2). Position the back rail (P5) and top panel (P1) by using 3 x screws (H11). Tighten all bolts and screws with a phillips head screwdriver.

Step 2






You will need	
	
6 x Large Cam Bolts (H1)	4 x Wooden Dowels (H3)
	
2 x Slide Tracks (H13-1)	6 x Screws 12mm (H6)
	
4 x Protective Foam (H8)	Mallet
	
Phillips Head Screwdriver	


Separate the slide runners (H13-2) and slide tracks (H13-1) from slide (H13) by following the steps below. Extend the slide runner (H13-2) all the way forward. Press the plastic release lever of the slide down and pull the slide runner (H13-2) completely out.



Insert 8 x wooden dowels (H3) into the left side panel (P3) and right side panel (P4). Screw 6 x large cam bolts (H1) into the left side panel (P3) and right side panel (P4). Attach 2 x slide tracks (H13-1) onto the left side panel (P3) and right side panel (P4) by using 6 x small screws (H6), tighten with a phillips head screwdriver.



Step 3


You will need	
	
4 x Wooden Dowels (H3)	6 x Screws 12mm (H6)
	
2 x Slide Tracks (H13-1)	Phillips Head Screwdriver
	
Mallet	




Using a mallet if needed, insert 4 x wooden dowels (H3) into the middle side panel (P6). Attach 2 x slide tracks (H13-1) on both sides of the middle side panel (P6) using 6 x small screws (H6), tighten all bolts and screws with a phillips head screwdriver.

Step 4

You will need	
	
1 x Large Cam Nut (H2)	Phillips Head Screwdriver



This is how a cam nut works.....







The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.

Align the middle side panel (P6) to the bottom panel (P2).


Insert 1 x large cam nut (H2) into the middle side panel (P6), make sure the opening on the cam nuts is facing incoming cam bolt, using a phillips head screwdriver turn clockwise to lock.

Step 5

You will need	
	
1 x Large Cam Nut (H2)	Phillips Head Screwdriver



This is how a cam nut works.....








The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.

Align the bottom panel (P2) and middle side panel (P6) to the back panel (P7).


Insert 1x large cam nut (H2) to the middle side panel (P6), make sure the opening of the cam nut is facing incoming cam bolt, turn clockwise to lock.

Step 6

You will need	
	
6 x Large Cam Nuts (H2)	Phillips Head Screwdriver
	
6 x Covers (H9)	



This is how a cam nut works.....







The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.

Align the panels (P2,P6,P7) with the left side panel (P3) and right side panel (P4).

Insert the 6 x large cam nuts (H2) into the panels (P7,P2), make sure the opening of the cam nuts are facing incoming cam bolt, using a phillips head screwdriver turn clockwise to lock. Place the 6 x covers (H9) over the large cam nuts.

Step 7


You will need	
	
10 x Large Cam Nuts (H2)	Phillips Head Screwdriver
	
4 x Covers (H9)	




TWO PEOPLE



REQUIRED



This is how a cam nut works.....



The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.


Position the top panel (P1) onto the panels (P2,P3,P4,P6).

Insert the 10x large cam nuts (H2) onto the panels (P2,P3,P4,P6) make sure the opening of the cam nuts are facing incoming cam bolt, using a phillips head screwdriver turn clockwise to lock.

Place the 4 x covers (H9) onto the large cam nuts (H2) on back panel (P7).

Step 8

You will need	
	
8 x Small Cam Bolts (H4)	4 x Slide Runners (H13-2)
	
12 x Screws 12mm (H6)	Phillips Head Screwdriver




Using a phillips head screwdriver, screw 8 x small cam bolts into drawer front panels (P8,P9).

Attach 4 x slide runners (H13-2) to the drawer side panels (P10,P11) using 12 x small screws (H6) as shown, tighten with a phillips head screwdriver.


Step 9

You will need	
	
8 x Small Cam Nuts (H5)	Phillips Head Screwdriver





Align 2 x drawer left side panels (P10) and 2 x drawer right side panels (P11) to the drawer front panels (P8,P9). Insert 8 x small cam nuts (H5) into the holes on the side panels (P10,P11) as shown, make sure the opening on cam nuts are facing incoming cam bolts, using a phillips head screwdriver turn clockwise to lock.



Step 10



Insert the drawer bottom panels (P12) into the grooves of the drawer front panels (P8,P9), drawer left side panels (P10) and drawer right side panels (P11).



Step 11

You will need	
	
8 x Screws 30mm (H7)	Phillips Head Screwdriver



Screw the 2x drawer back panels (P13) to the drawer left panels (P10) and drawer right panels (P11) by using 8 x screws (H7), tighten with a phillips head screwdriver.


Step 12



Move Inner Ball Bearing Track outward.








Gently Insert Slide Runner into Ball Bearing Track.



Position drawer box so the slide runners (H13-2) align with the slide tracks (H13-1) as shown. Gently push drawer into the closed position.

Step 13



You will need	
	
1 x Wall strap (H8)	1 x Screw 20mm (H11)
	
1 x Washer (H10)	Phillips Head Screwdriver




We strongly advise that you use the wall safety strap provided to prevent the unit toppling.

Tighten the wall strap (H8) to the back panel (P7) using 1 x screw (H11) and 1 x washer (H10) with a phillips head screwdriver.


Step 14

You will need	
	
1 x Washer (H10)	Phillips Head Screwdriver
Wall Screw and Wall Plug are not provided. Please use appropriate fixtures for your wall.	



Move the console table to the final position and attach the wall strap to the wall securely. Make sure it is firmly attached.

Step 15



Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.