


Version 1.0







Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture to help create a home you'll love!



Love it? Share it!

Fantastic buy! Share how it looks at home on Instagram for your chance to win a \$250 Fantastic Furniture Gift Card!

@fantasticfurniture


Assembly Checklist



Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.




Identify and lay out all of the components before you begin assembly.




Unless instructed, do not fully tighten screws until the item is fully assembled.


Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.




Hardware pack





Attach 4 x Threaded Rod (H6) into Legs (P2x2, P3x2).




Insert 8 x Dowels (H1) into Rails (P4x2). Attach Legs (P2x2, P3x2) to Rail (P4x2) with 4 x Half Round Nuts (H5), and 4 x Hexagonal Nuts (H7) using Spanner (H8).



Step 3






Insert 8 x Dowels (H1) into Rail (P5x2), attach to Legs (P2x2, P3x2). Insert 4 x Half Round Nuts (H5), and 4 x Hexagonal Nuts (H7) using Spanner (H8).


Step 4






Secure 16 x Cam Bolts (H3) to Top Panel (P1) by tightening Cam Bolts (H3) with a Phillips Head Screwdriver.






Step 6




Attach 4 x Bracket (H2) to Rails (P5x2) and Legs and secure with 8 x Screws (H10) by tightening with a Phillips Head Screwdriver.





Attach 4 x Plastic Glides (H9) to the Legs (P2x2&P3x2) by using a hammer to gently tap into place.



In the interest of our environment please dispose of all packaging thoughtfully.