




**Fantastic
Furniture**

Version 1.0



Two People



Required

Havana

Bed King Single MK2 Light Oak

fantasticfurniture.com.au

Looks like you've found your Fantastic!

We're thrilled you've chosen Fantastic Furniture
to help create a home you'll love!



Fantastic Furniture

Love it? Share it!


Fantastic buy! Share how it looks at home on Instagram for
your chance to win a \$250 Fantastic Furniture Gift Card!

@fantasticfurniture


Assembly Checklist




Read through the instructions carefully before you begin.



Make sure you have all the required tools. Never use power tools unless instructed.



Identify and lay out all of the components before you begin assembly.



Unless instructed, do not fully tighten screws until the item is fully assembled.

Useful Information

- ! Never use power tools unless specifically instructed. They can damage your components or hardware if used incorrectly.
- ! The most common mistakes made during assembly are using the wrong hardware or getting components back to front.
- ! Always use a soft surface (such as carpet or cardboard) when assembling your product to avoid scratching or damaging the surface of the product.
- ! Bulky items such as wardrobes and bunk beds should be assembled in the room they will be used in as they may not fit through a door once assembled.
- ! Never use any glue until you are certain that the parts belong together.
- ! Periodically check and re-tighten all fasteners. Check the product care label or website for product care instructions.
- ! If you are having any difficulties assembling your product, missing any hardware or components please visit our website Help Centre for further assistance.
- ! Please see page 2 for any safety requirements or weight restrictions.

What you need

to assemble the product



DO NOT USE




Other tools you need:

Phillips Head Screwdriver;
Hammer

Parts list

Rail (P1);
2 x Rails (P2);
Rail (P3);
Rail (P4);
Back Panel (P5);
2 x Side Rails (P6);
2 x Side Covers (P7);
Rail (P8);
Rail (P9);
Rail (P10);
Back Panel (P11);
13 x Slats (P12);




Hardware pack



32 x Dowels
(H1)



26 x Screws
(H2)



12 x Cam
Bolts
(H3)



12 x Cam
Nuts
(H4)



16 x Half
Round
Nuts
(H5)



12 x Threaded
Rods
(H6)



4 x Hexagonal
Bolts
(H7)



16 x Hexagonal
Nuts
(H8)



4 x Plastic
Glides
(H9)



1 x Allen
Key
(H10)



8 x Nuts
(H11)



1 x Spanner
(H12)



8 x Large
Hole
Stickers
(H13)







8 x Small Hole
Stickers
(H14)



4 x Washers
(H15)





Step 1


| You will need | |
|---|---|
|  |  |
| 4 x Threaded Rods (H6) | 4 x Nuts (H11) |



Insert 4 x nuts (H11) into the holes in rails (P1, P3, P4). Ensure the lines in the nuts (H11) face incoming threaded rods as shown in the image above. Attach 4 x threaded rods (H6) to the 4 x nuts (H11) and hand tighten by turning clockwise.


Step 2

| You will need | |
|---|---|
|  |  |
| 2 x Half Round Nuts (H5) | 2 x Hexagonal Nuts (H8) |
|  |  |
| 4 x Dowels (H1) | 1 x Spanner (H12) |







Insert 4 x dowels (H1) into rail (P2). Attach rails (P3, P4) to rail (P2) and secure using 2 x half round nuts (H5) and 2 x hexagonal nuts (H8), tightening with spanner (H12).


Step 3



Slide back panels (P5) into the grooves of rails (P3, P4).



Step 4


| You will need | |
|---|---|
|  |  |
| 2 x Half Round Nuts (H5) | 2 x Hexagonal Nuts (H8) |
|  |  |
| 4 x Dowels (H1) | 1 x Spanner (H12) |



Insert 4 x dowels (H1) into rails (P3, P4). Attach rail (P1) to rails (P3, P4) and secure using 2 x half round nuts (H5) and 2 x hexagonal nuts (H8), tightening with spanner (H12).



Step 5



| You will need | |
|---|---|
|  |  |
| 2 x Plastic Glides (H9) | Hammer |



Attach 2 x plastic glides (H9) to end of rails (P3, P4) by gently tapping with a hammer.





Step 6


| You will need | |
|---|---|
|  |  |
| 4 x Threaded Rods (H6) | 4 x Nuts (H11) |



Insert 4 x nuts (H11) into the holes in rails (P9, P10). Ensure the lines in the nuts (H11) face incoming threaded rods as shown in the image above. Attach 4 x threaded rods (H6) to the 4 x nuts (H11) and hand tighten by turning clockwise.


Step 7

| You will need | |
|---|---|
|  |  |
| 2 x Half Round Nuts (H5) | 2 x Hexagonal Nuts (H8) |
|  |  |
| 4 x Dowels (H1) | 1 x Spanner (H12) |







Insert 4 x dowels (H1) into rail (P2). Attach rails (P9, P10) to rail (P2) and secure using 2 x half round nuts (H5) and 2 x hexagonal nuts (H8), tightening with spanner (H12).


Step 8



Slide back panel (P11) into the grooves of rails (P9, P10).






Step 9


| You will need | |
|---|---|
|  |  |
| 2 x Half Round Nuts (H5) | 2 x Hexagonal Nuts (H8) |
|  |  |
| 4 x Dowels (H1) | 1 x Spanner (H12) |



Insert 4 x dowels (H1) into rails (P9, P10). Attach rail (P8) to rails (P9, P10) and secure using 2 x half round nuts (H5) and 2 x hexagonal nuts (H8), tightening with spanner (H12).




Step 10


| You will need | |
|---|---|
|  |  |
| 4 x Threaded Rods (H6) | 2 x Plastic Glides (H9) |
|  |  |
| 4 x Small Hole Stickers (H14) | Phillips Head Screwdriver |
|  | |
| Hammer | |



Attach 4 x threaded rods (H6) into rails (P9, P10). Attach 2 x plastic glides (H9) to the end of rails (P9, P10) by gently tapping with a hammer. Attach 4 x small hole stickers (H14) to the holes of rails (P9, P10).



Step 11


| You will need | |
|---|---|
|  |  |
| 4 x Dowels (H1) | 12 x Cam Bolts (H3) |
|  | |
| Phillips Head Screwdriver | |




Insert 2 x dowels (H1) into the side cover (P7). Attach 6 x cam bolts (H3) into 1 x side cover (P7), tightening with a phillips head screwdriver.

Step 12

| You will need | |
|---|---|
|  |  |
| 12 x Cam Nuts (H4) | Phillips Head Screwdriver |







This is how a cam nut works.....




The head of the cam bolt goes into the open mouth of the cam nut. You then turn the cam nut so it tightens over the bolt.

Insert 6 x cam nuts (H4) into the holes on the side rail (P6). Rotate the cam nuts so the arrows point towards the incoming cam bolts. Attach the side rail (P6) to the side cover (P7), then tighten the cam nuts with a phillips head screwdriver. Repeat step 11 and step 12 for the other side cover (P7) and side rail (P6).








Step 13


| You will need | |
|---|---|
|  |  |
| 6 x Dowels (H1) | 4 x Half Round Nuts (H5) |
|  |  |
| 4 x Hexagonal Nuts (H8) | 1 x Spanner (H12) |



Insert 6 x dowels (H1) into 2 x side covers (P7) and 2 x side rails (P6). Attach rails (P9, P10) to 2 x side covers (P7) and 2 x side rails (P6) and secure using 4 x hexagonal nuts (H8) and 4 x half round nuts (H5), tightening with the spanner (H12).



Step 14


| You will need | |
|---|---|
|  |  |
| 4 x Half Round Nuts (H5) | 4 x Hexagonal Nuts (H8) |
|  |  |
| 6 x Dowels (H1) | 1 x Spanner (H12) |
|  |  |
| 4 x Hexagonal Bolts (H7) | 1 x Allen Key (H10) |
|  | |
| 4 x Washers (H15) | |



Insert 6 x dowels (H1) into 2 x side covers (P7) and 2 x side rails (P6). Thread 4 x hexagonal bolts (H7) through the 4 x washers (H15) and push the 4 x hexagonal bolts (H7) through rails (P3, P4). Attach rails (P3, P4) to 2 x side covers (P7) and 2 x side rails (P6), secure using 4 x hexagonal nuts (H8) and 4 x half round nuts (H5) with spanner (H12). Tighten 4 x hexagonal bolts (H7) with allen key (H10).



Step 15


| You will need | |
|---|---|
|  |  |
| 26 x Screws (H2) | Phillips Head Screwdriver |




Attach the 13 x slats (P12) to the 2 x side rails (P6) using 26 x screws (H2), tightening with a phillips head screwdriver.

Step 16

| You will need | |
|---|---|
|  |  |
| 8 x Large Hole Stickers (H13) | 4 x Small Hole Stickers (H14) |



Cover the holes on rails (P2, P3, P4, P8) using 8 x large hole stickers (H13).
Cover the holes on rails (P1, P3, P4) using 4 x small hole stickers (H14).



Job Complete!

In the interest of our environment please dispose of all packaging thoughtfully.